

## **elmeg ICT**

**Operating instructions: IP telephones**  
**English**

These operating instructions can be a helpful guide to assist you in using your new ISDN telecommunications equipment (PABX system).

No matter whether your PABX is for your work or for your personal use, ease of use and enjoyment while using the phone are guaranteed.

Please take a little time to try out the functions that are packed into this ISDN PABX so that you can learn to take advantage of the full range of features provided.

### Declaration of conformity and CE mark



This device meets the requirements of the following EC directive R&TTE 6/1999/EG:

»Directive 1999/5/EC of the European Parliament and of the Council of 9 March 1999 on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity«

You can request this EC declaration of conformity at the following Internet URL: <http://www.bintec-elmeg.com>



The waste container symbol with the »X« through it on the device indicates that the device must be disposed of separately from normal domestic waste at an appropriate waste disposal facility at the end of its useful service life.

© bintec elmeg GmbH- All rights reserved.

Any reprint of this documentation, even excerpts, is prohibited without the prior, express consent of the publisher and exact designation of sources, regardless of the type and form of media used in the process (mechanical or electronic).

Function and logic descriptions for this documentation which refer to software products of other manufacturers are based on the software in use at the time of generation or print. Product and/or company names used in this documentation may be registered trademarks.

## Index

<b>Initial operation of an IP phone at the VoIP VPN Gateway using the DSP module. . . . .</b>	<b>1</b>
Initial startup. . . . .	1
<b>Symbols and buttons . . . . .</b>	<b>2</b>
<b>Operation. . . . .</b>	<b>3</b>
Making phone calls . . . . .	3
Making outside calls. . . . .	3
Specific trunk group seizure . . . . .	3
Defining your own number for the next call . . . . .	3
Making internal calls . . . . .	4
Accepting calls . . . . .	4
Accepting calls (Pick-up) . . . . .	4
Speed dialing from the telephone directory. . . . .	4
Switching the announcement for an external number (Day / Night) . . . . .	5
Inquiry call . . . . .	5
Transferring calls with advance notice . . . . .	5
Broker`s call. . . . .	5
Three-party conference call Call . . . . .	6
Call forwarding . . . . .	6
Teams. . . . .	7
<b>Hotel functions . . . . .</b>	<b>8</b>
<b>Wake-up call . . . . .</b>	<b>8</b>
<b>Door intercom device. . . . .</b>	<b>8</b>
Signaling features . . . . .	9
Switching contacts. . . . .	9
Service access. . . . .	9
RAS dial-in for gateway diagnostics . . . . .	10



These operating instructions describe only the most important routines for using the PABX.

## Initial operation of an IP phone at the VoIP VPN Gateway using the DSP module

Your PABX system comes equipped with a VoIP VPN Gateway module and a DSP module. After the PABX has run up it will recognize the module and you can then begin configuration at the IP telephone.

These brief instructions are based on the DHCP configured in the VoIP VPN Gateway.

The elmeg IP290 IP telephone is used as an example in this description.

### Initial startup

Link the Gateway to the IP telephone using the network cable. Connect the plug-in power supply unit and the telephone and switch the power on.

### Language setting

Select a language using the arrow keys  . Press  to confirm your selection.

```
Select Language:
← English →
```

```
Select Language:
← Deutsch →
```

### Select dial tone

Select the desired country using the arrow buttons  . Press  to confirm.

```
Dial tone:
← Australia →
```

```
Dial tone:
← Deutschland →
```

### Select a time zone

Select a time zone using the arrow keys  . Press  to confirm.

```
Dial time zone:
← -10 USA (Honolulu) →
```














```
Dial time zone:
← +1: Deutschland (Berli) →
```














### First log-in





A subscriber must be configured in the PABX system under the VoIP VPN Gateway. Enter your user ID (for example for MSN 227). This consists of the MSN, followed by the symbol "@" and the address for the VoIP VPN Gateway.

```
Contraction:
227@192.168.1.250
```

Enter an ID for the MSN227 and the IP address 192.168.1.250:

After entering your user ID confirm it by pressing the  key.

If logon was successful you will now see the new number (227) in the display.

```
03.05 (227) 10:22
Idle Telbook Lists
```

## Symbols and buttons

Please note: different terminal devices will not necessarily have the same dial tones, ringing signals or procedures for use.

### Symbols used



Lift up the handset of your telephone.



This symbol indicates the call status. You have lifted the handset of your telephone.



Replace the handset of your phone in the carriage, or the telephone is idle.



Indicates signaling at a terminal device, for example your phone rings.



You can dial the desired number.



One of these symbols indicates that you should dial the digit shown, or a certain character.



These symbols indicate a selection of digits or characters from which you can choose the appropriate one.



This symbol prompts you to select a certain digit or character from a list or table.



Prompts you to press the flash key (signal key).



Indicates that an acknowledgement signal can be heard in the handset.



Indicates a conference call.

### Telephone buttons elmeg IP290



Softkeys



Pressing this button stores a setting in the telephone.



This key opens the programming menu. If you are already located in a menu and then press the key, either menu-specific functions are shown.



Pressing the Esc button during programming returns the telephone to its idle status.

The arrows »\*« and »\*« in the right corner on the top line of the display indicate that you can call up further functions on the lower lines using the arrow buttons.



In the Input mode you can delete individual lines using the C key.



Speaker



Ending a call



Last number redial button





Inquiry button



Programmable function keys with LED

## Operation

For a description of the features please refer to the user information on the CD.

If your phone is set for »Automatic line access« you must first press the **\*** key when you lift the handset  before beginning any internal call procedures. The symbol  , as shown in the example below, is highlighted in color for the corresponding performance feature.




## Making phone calls

Some terminal devices use their own special procedures for the functions described in the following. Refer to the operating instructions for the terminal device being used for detailed information.

The following operating sequences show only an IP phone connection, i.e. a call between PABX subscribers and external subscribers, as an example. These tones may be different for IP- telephones which generate their own dial tones. Other information may also be shown in the display of these telephones.

## Making outside calls


### Making external calls without Direct exchange line access




### Making outside calls with direct exchange line access



## Specific trunk group seizure




## Defining your own number for the next call



## Making internal calls

All phone calls, fax transmissions or data transmissions that take place between internal analog devices are internal connections for which no charges are billed.

### Making internal calls without »Direct exchange line access«



### Making internal calls with »Direct exchange line access«



## Accepting calls



## Accepting calls (Pick-up)

### Picking up calls from within the group

Picking up a call is possible only within the pick-up group to which your terminal device has been assigned via configuration.

A telephone near you begins ringing. You would like to accept the call at your own phone.



### Picking up calls from the answering machine



### Picking up calls for a specific subscriber

Picking up of calls for a specific subscriber applies to the entire PABX system and is not bound to groups.



## Speed dialing from the telephone directory





## Switching the announcement for an external number (Day / Night)

### Day / Night switchable Announcements

	<b>*92*</b>	or	<b>#92*</b>			
Lift up handset	Day		Night		Ack. signal	Replace handset.

## Inquiry call

You can call another party at any time during an ongoing call.



You are conducting a call.  
You would like to call another party.



Press the R key.  
You will hear the Continuous signal in your handset.



If you wish to speak to an external party first dial 0 and then the number for that party.



Please confirm this. You will hear the ringing signal in your handset.

The party will be called.  
The party being called lifts up the handset of his/her phone.



Conduct your call.



Press the Esc key and function key 1 of your IP phone to end an inquiry call.

## Transferring calls with advance notice

You wish to transfer an internal or external call to another internal party and speak with that party beforehand.



You are conducting an internal or external call. You wish to transfer the call to another party.



Press the R key. You hear the call waiting signal.

If you hear a busy signal press »Délect.« and function key 1 to retrieve the call.



Dial the number of the party you wish to call.



Confirm by pressing OK.

You will hear the ringing signal in your handset.  
The party will be called.  
The party being called lifts up the handset of his/her phone.



Conduct this internal call.  
Tell your internal partner that you wish to transfer the call currently on hold to him/her.



Replace the handset.  
The other internal party can then continue with the call.

## Broker`s call









You are conducting a call and wish to speak to a further party, without the first caller being able to hear your conversation with the second caller.



Press the R key.  
You will hear the Continuous signal in your handset.









If you wish to speak to an external party, dial **0** first.  
Dial the number of the party you wish to call.

-  Confirm by pressing OK.
- You will hear the ringing signal in your handset.  
The party will be called.  
The party being called lifts up the handset of his/her phone.
-  You are conducting the call.  
The first call is put on hold.
-  Dial this code to return to your first caller; the second party is put on hold. You can then use this code to switch back and forth between the two callers.
- or
-  You can end an active call by pressing Esc.
-  You can return to the call on hold by pressing the flashing function key.
- or
-  You can end the ongoing call by hanging up the handset.

If you switch back and forth between an internal caller and an external party (broker's call) and then hang up your handset, your call is terminated and the two callers will be connected with one another! When you are conducting a Broker's call (switching back and forth) between two internal parties and hang up the handset your call is terminated and the two other parties are connected with one another.


### Three-party conference call Call

-  You are conducting a call with one party and wish to include a further party in the call.
- R** Press the R key.  
You hear the call waiting signal.
- If you wish to speak to an external party, dial 0 first.
-  Dial the number of the party you wish to call.
-  Confirm by pressing OK.
- You will hear the ringing signal in your handset. The party will be called.  
The party being called lifts up the handset of his/her phone.
-  You would like to include this party in the first call.
- Cnf. on** Press the softkey »Cnf. on«.
-  Conduct your three-party conference call.
- Cnf. off** Three-party conference calls can be terminated using the softkey »Cnf. off« or  and all connections are then terminated.


### Call forwarding

The PABX recognizes automatically by the length of the number whether call forwarding is to be made to an internal or external subscriber. This is why the destination number for call forwarding to an external subscriber is always input without the line access digit (LAD).

### Activating call forwarding



### Call forwarding per time On




### Activating call forwarding »on busy



### Deactivating call forwarding




### Activating team call assignment for one team



### Switching team call assignment for all teams



### door terminal (door intercom device) - Switching call modes for a doorbell button



### door terminal (door intercom device) - Switching call modes for all door terminal modules









### Switching all call modes (all teams and door terminal modules).



## Teams

### Enabling / Inhibiting a subscriber of a team (log-in, log-off)

Proceed as follows in order to enable or inhibit your phone for a team.

 Lift up handset	 Subscriber enable/inhibit	<b>9 4 3</b>	 Team number (00 ...39)		 Ack. signal	 Replace handset
--	--	--------------	---	---	--	--

### Enabling / inhibiting a subscriber for all teams (log-in, log-off)

Proceed as follows in order to enable or inhibit your phone for all teams.






 Lift up handset	 Enable/Inhibit subscribers	<b>9 4 3 *</b>		 Ack. signal	 Replace handset
--	---	----------------	---	--	--

## Hotel functions

This PABX system comes equipped with extensive hotel functions. This function is used from the reception desk phone via the PABX system menu.

### Registering the hotel room status

Dialing a numeric code from the room telephone makes it possible to register the current status of the room. This data collection can be analyzed and displayed only in connection with hotel application software.

 Lift up handset	 <b>7 3</b>	<b>0 / 1 / 2</b> Enter status: 0 = Room not clean 1 = Room clean 2 = Room clean and inspected		 Ack. signal	 Replace handset.
--	--	---	---	--	---

## Wake-up call

### Configuring wake-up calls from the room phone (one-time morning call)

 Lift up handset	 <b>7 2</b>	<b>0 6</b> Hours	<b>3 0</b> Minutes		 Ack. signal	 Replace handset.
--	--	---------------------	-----------------------	---	--	---

**0 6** Enter the hour desired for the morning call between 00 and 23 (in this example 6 am)

**3** Enter the minute for the morning call between 00 and 59 (in this example 6.30 am)





### Clear a wake-up call

 Lift up handset	 <b>7 2</b>		 Ack. signal	 Replace handset.
--	--	---	--	---

### Configuring a wake-up call from the »Reception desk phone«


In addition to configuring wake-up calls using the room phone, wake-up calls can also be defined for several days in advance from the »Reception desk phone«.

### Answering a morning call

 The telephone in your room rings	 Lift up handset	 Music on hold or voice announcement	 Now hang up the handset and the wake-up call is ended
---	--	--	--


## Door intercom device

### Making a door interphone call



## Signaling features

### Activating/ de-activating signalisation call function



### Alarm call list

The terminal device must have been entered into the list during configuration:

**01 ... 36** Alarm call list 01...36.

#### Function:

- 0** Deactivating the alarm call feature.
- 1** Activating the internal alarm call feature.
- 2** Activate external call feature.

### Local alarm call acknowledgement


An alarm call can be confirmed locally at a telephone assigned to the alarm input.




## Switching contacts

In the event of a loss of power and after a reset the switching contacts are idle.

### Activating/ de-activating switching contacts



### Switching contact with button function



## Service access

This feature enables you to have the PABX configured by your dealer's service center or download the current software. You can trigger this function from an internal phone of your PABX.

### Enabling for remote service access

You can release your PABX system for remote access by an external subscriber. Release for remote access of the PABX is effected for 30 minutes.



### Enabling for remote service access (without subaddress check)

You can release your PABX system for remote access by an external subscriber. Release for remote access of the PABX is effected for 30 minutes.



### Deleting authorization for remote service access

You can cancel a programmed release for incoming remote access any time you want. However, an existing connection to a service center is not terminated.



## RAS dial-in for gateway diagnostics

### Enabling for 30 minutes

You can enable your PABX system for dial-in from an external subscriber for up to 30 minutes.



### Enabling for 30 minutes with specified number

You can enable your PABX system for dial-in from a specified external subscriber for up to 30 minutes when the caller's number concurs with the specified number.



### Cancellation of enabling

You can cancel a service connection for dial-in by an external subscriber. This will not terminate an ongoing service connection.



## Index

### A

#### Accepting

of calls . . . . . 4

Alarm call. . . . . 9

Alarm call list. . . . . 9

Announcement. . . . . 5

Answering machine . . . . . 4

Appointment call . . . . . 8

### B

Broker`s call . . . . . 5

Button function . . . . . 9

### C

#### Call

accepting . . . . . 4

Call modes . . . . . 7

Call rerouting. . . . . 6

Conference . . . . . 6

Configuring wake-up call from »Reception desk phone« . . . . . 8

Configuring wake-up calls from the room phone8

### D

Description . . . . . 1

Direct exchange line access . . . . . 3

Door intercom device. . . . . 8,9,10

### F

Flash. . . . . 3

### I

Inquiry call . . . . . 5

### M

#### Making Calls

External . . . . . 3

Internal . . . . . 4

Making outside calls with direct exchange line access

3

Making telephone calls . . . . . 3

### O

#### Own number

defining for the next call. . . . . 3

### P

Pick up . . . . . 4

Picking up calls for a specific subscriber . . . . 4

#### Pick-up

calls from answering machine . . . . . 4

### R

RAS dial-in . . . . . 10

Reception desk phone. . . . . 8

Registering the hotel room status . . . . . 8

Room telephone . . . . . 8

### S

Safety Information. . . . . 1

Service access. . . . . 9

Signaling features . . . . . 9

Speaking simultaneously with two parties . . . 6

Specific trunk group seizure . . . . . 3

Speed dialing from the telephone directory. . . 4

Symbols. . . . . 2

### T

Teams . . . . . 7,8

Telephone directory . . . . . 4

Three-party conference . . . . . 6

Transfer a call . . . . . 5

Transfer in the network (ECT) . . . . . 5

Transferring a call . . . . . 5

Trunk group seizure . . . . . 3

### W

Wake-up call . . . . . 8





## **elmeg ICT**

**Operating instructions: IP telephones  
English**