

**bintec Workshop  
IP Load Balancing**

Copyright © November 8, 2005 Funkwerk Enterprise Communications GmbH  
Version 0.9

<b>Purpose</b>	This document is part of the user's guide to the installation and configuration of bintec gateways running software release 7.1.4 or later. For up-to-the-minute information and instructions concerning the latest software release, you should always read our <b>Release Notes</b> , especially when carrying out a software update to a later release level. The latest <b>Release Notes</b> can be found at <a href="http://www.funkwerk-ec.com">www.funkwerk-ec.com</a> .		
<b>Liability</b>	While every effort has been made to ensure the accuracy of all information in this manual, Funkwerk Enterprise Communications GmbH cannot assume liability to any party for any loss or damage caused by errors or omissions or by statements of any kind in this document and is only liable within the scope of its terms of sale and delivery.  The information in this manual is subject to change without notice. Additional information, changes and <b>Release Notes</b> for bintec gateways can be found at <a href="http://www.funkwerk-ec.com">www.funkwerk-ec.com</a> .		
	As multiprotocol gateways, bintec gateways set up WAN connections in accordance with the system configuration. To prevent unintentional charges accumulating, the operation of the product should be carefully monitored. Funkwerk Enterprise Communications GmbH accepts no liability for loss of data, unintentional connection costs and damages resulting from unsupervised operation of the product.		
<b>Trademarks</b>	bintec and the bintec logo are registered trademarks of Funkwerk Enterprise Communications GmbH.  Other product names and trademarks mentioned are usually the property of the respective companies and manufacturers.		
<b>Copyright</b>	All rights are reserved. No part of this publication may be reproduced or transmitted in any form or by any means – graphic, electronic, or mechanical – including photocopying, recording in any medium, taping, or storage in information retrieval systems, without the prior written permission of Funkwerk Enterprise Communications GmbH. Adaptation and especially translation of the document is inadmissible without the prior consent of Funkwerk Enterprise Communications GmbH.		
<b>Guidelines and standards</b>	bintec gateways comply with the following guidelines and standards:  R&TTE Directive 1999/5/EG  CE marking for all EU countries and Switzerland  You will find detailed information in the Declarations of Conformity at <a href="http://www.funkwerk-ec.com">www.funkwerk-ec.com</a> .		
<b>How to reach Funkwerk Enterprise Communications GmbH</b>	<table border="1"> <tr> <td>Funkwerk Enterprise Communications GmbH Suedwestpark 94 D-90449 Nuremberg Germany  Telephone: +49 180 300 9191 0 Fax: +49 180 300 9193 0 Internet: <a href="http://www.funkwerk-ec.com">www.funkwerk-ec.com</a></td> <td>Bintec France 6/8 Avenue de la Grande Lande F-33174 Gradignan France  Telephone: +33 5 57 35 63 00 Fax: +33 5 56 89 14 05 Internet: <a href="http://www.bintec.fr">www.bintec.fr</a></td> </tr> </table>	Funkwerk Enterprise Communications GmbH Suedwestpark 94 D-90449 Nuremberg Germany  Telephone: +49 180 300 9191 0 Fax: +49 180 300 9193 0 Internet: <a href="http://www.funkwerk-ec.com">www.funkwerk-ec.com</a>	Bintec France 6/8 Avenue de la Grande Lande F-33174 Gradignan France  Telephone: +33 5 57 35 63 00 Fax: +33 5 56 89 14 05 Internet: <a href="http://www.bintec.fr">www.bintec.fr</a>
Funkwerk Enterprise Communications GmbH Suedwestpark 94 D-90449 Nuremberg Germany  Telephone: +49 180 300 9191 0 Fax: +49 180 300 9193 0 Internet: <a href="http://www.funkwerk-ec.com">www.funkwerk-ec.com</a>	Bintec France 6/8 Avenue de la Grande Lande F-33174 Gradignan France  Telephone: +33 5 57 35 63 00 Fax: +33 5 56 89 14 05 Internet: <a href="http://www.bintec.fr">www.bintec.fr</a>		

<b>1</b>	<b>Introduction</b>	<b>3</b>
1.1	Scenario	3
1.2	Requirements	3
<b>2</b>	<b>Configuration of Metric</b>	<b>5</b>
<b>3</b>	<b>Configuration of IP Load Balancing</b>	<b>7</b>
<b>4</b>	<b>Result</b>	<b>9</b>
4.1	Monitoring	9
4.2	Overview of Configuration Steps	10




# 1 Introduction

The configuration of IP load balancing for a Bintec **VPN Access 25** gateway is described in the following chapters.

Load balancing allows the data traffic to be distributed between the available lines. In the event of a fault, one line naturally takes over all the traffic automatically. The traffic can be distributed according to various criteria, e.g. half the data traffic can be distributed to each line. The Setup Tool is used for the configuration.

## 1.1 Scenario

In this scenario, the interface ETH1 is used for the LAN, the third interface ETH3 for the xDSL access and the ISDN S0 interface for the ISDN connection.



## 1.2 Requirements

The following are required for the configuration:

- A Bintec **VPN Access 25** gateway.
- xDSL Internet connection.
- ISDN Internet connection.
- At least release 7.1.2.
- Connect your LAN to the ETH1 interface of your gateway.



## 2 Configuration of Metric

**Note**

Load balancing is only activated for equivalent routes. The default routes of the two WAN partners must have the same metric.

- Go to **IP → ROUTING**.

VPN Access 25 Setup Tool							Bintec Access Networks GmbH
[IP] [ROUTING] : IP Routing							Gateway
The flags are: U (Up), D (Dormant), B (Blocked), G (Gateway Route), I (Interface Route), S (Subnet Route), H (Host Route), E (Extended Route)							
Destination      Gateway      Mask      Flags      Met.      Interface      Pro 192.168.0.0      192.168.0.254      255.255.255.0      0      en0-1      loc default            0.0.0.0          DI      1      freenet      loc default            0.0.0.0          I      1      tonline      loc							
ADD		ADDEXT			DELETE		EXIT

**Note**

Proceed as follows if the two WAN partners do not have the same metric.

- Go to **IP → ROUTING → WAN PARTNER**.

VPN Access 25 Setup Tool		Bintec Access Networks GmbH
[IP] [ROUTING] [EDIT]		Gateway
Route Type	Default route	
Network	WAN without transit network	
Partner / Interface	freenet	
Metric	2	
SAVE		CANCEL

The following field is relevant:

Field	Meaning
Metric	Priority of route.

Table 2-1: Relevant field in **IP** → **ROUTING** → **WAN PARTNER**

Proceed as follows to define the necessary settings:

- Enter **1** under **METRIC**.
- Leave all the other settings as they are.
- Press **SAVE** to confirm your settings.

### 3 Configuration of IP Load Balancing

- Go to **IP → BANDWIDTH MANAGEMENT (LOAD BALANCING/BOD) → IP LOAD BALANCING OVER MULTIPLE INTERFACES → ADD.**

VPN Access 25 Setup Tool		Bintec Access Networks GmbH
[IP] [IP LOAD BALANCING] [EDIT]		Gateway
Description	DSL-ISDN Balancing	
Interface Group ID	0	
Distribution Policy	session round-robin	
Distribution Mode	always (use operational up and dormant interfaces)	
Distribution Ratio	individual for all interfaces of the group	
Interface 1	tonline	
Distribution Fraction (in percent)	50	
Interface 2	freenet	
Distribution Fraction (in percent)	50	
Interface 3	none	
<b>SAVE</b>		<b>CANCEL</b>

The following fields are relevant:

Field	Meaning
Description	Description of load balancing.
Interface Group ID	The ID of the interface group. This is issued automatically by the system.
Distribution Policy	Policy according to which the data is distributed.
Distribution Mode	Interfaces to be used according to state.
Distribution Ratio	Defines how the data is to be distributed.
Interface 1	First WAN partner.
Distribution Fraction	Percentage utilization.

Field	Meaning
Interface 2	Second WAN partner.
Distribution Fraction	Percentage utilization.

Table 3-1: Relevant fields in **IP → BANDWIDTH MANAGEMENT (LOAD BALANCING/BOD)**  
**→ IP LOAD BALANCING OVER MULTIPLE INTERFACES → ADD**

Proceed as follows to define the necessary settings:

- Enter a unique name under **DESCRIPTION**, e.g. *DSL-ISDN Balancing*.
- Leave **INTERFACE GROUP ID** set to 0.
- Set **POLICY** to *session round-robin*.
- Set **DISTRIBUTION MODE** to *always (use operational up and dormant interfaces)*.
- Set **DISTRIBUTION RATIO** to *individual for all interfaces of the group*.
- Set **INTERFACE 1** to your first WAN partner, e.g. your xDSL connection.
- Enter 50 under **DISTRIBUTION FRACTION**.
- Set **INTERFACE 2** to your second WAN partner, e.g. your ISDN connection.
- Press **SAVE** to confirm your settings.



The name "interface" does not refer to the physical interfaces.

**Note**

Return to the main menu and finally save your new configuration in the flash memory with **EXIT** and **SAVE AS BOOT CONFIGURATION AND EXIT**.

## 4 Result

These settings cause your transmitted data to be distributed evenly to the two Internet connections.

### 4.1 Monitoring

Monitoring is possible with the command `iploadbiftable`. Enter the following in the command line of the gateway for this purpose:

```
Gateway:> iploadbiftable
```

inx	Index(*rw)	GroupId(rw)	Ratio(rw)
	Mode(-rw)	ActAssignedSessions(ro)	TotAssignedSessions(ro)
	ActLoad(ro)	ActDownLoad(ro)	ActUpLoad(ro)
00	10002	0	50
	enabled	0	0
	0	0	0
01	10001	0	50
	enabled	0	0
	0	0	0

```
Gateway:ipLoadBIfTable>
```

## 4.2 Overview of Configuration Steps

Field	Menu	Description	Compulsory field
Metric	<b><i>IP → ROUTING → INTERFACE</i></b>	e.g. 1	Yes
Description	<b><i>IP → BANDWIDTH MANAGEMENT → IP LOAD BALANCING OVER MULTIPLE INTERFACES → ADD</i></b>	e.g. <i>DSL-ISDN Balancing</i>	
Distribution Policy	<b><i>IP → BANDWIDTH MANAGEMENT → IP LOAD BALANCING OVER MULTIPLE INTERFACES → ADD</i></b>	<i>session Round-Robin</i>	Yes
Distribution Mode	<b><i>IP → BANDWIDTH MANAGEMENT → IP LOAD BALANCING OVER MULTIPLE INTERFACES → ADD</i></b>	<i>always (use operational up and dormant interfaces)</i>	Yes
Distribution Ratio	<b><i>IP → BANDWIDTH MANAGEMENT → IP LOAD BALANCING OVER MULTIPLE INTERFACES → ADD</i></b>	e.g. 50 - 50	Yes
Interface 1	<b><i>IP → BANDWIDTH MANAGEMENT → IP LOAD BALANCING OVER MULTIPLE INTERFACES → ADD</i></b>	e.g. your DSL connection	Yes
Distribution Fraction	<b><i>IP → BANDWIDTH MANAGEMENT → IP LOAD BALANCING OVER MULTIPLE INTERFACES → ADD</i></b>	e.g. 50	Yes
Interface 2	<b><i>IP → BANDWIDTH MANAGEMENT → IP LOAD BALANCING OVER MULTIPLE INTERFACES → ADD</i></b>	e.g. your ISDN connection	Yes
Distribution Fraction	<b><i>IP → BANDWIDTH MANAGEMENT → IP LOAD BALANCING OVER MULTIPLE INTERFACES → ADD</i></b>	e.g. 50	Yes