

bintec Workshop
Network Address Translation Configuration

Copyright © November 8, 2005 Funkwerk Enterprise Communications GmbH
Version 0.9

Purpose	This document is part of the user's guide to the installation and configuration of bintec gateways running software release 7.1.4 or later. For up-to-the-minute information and instructions concerning the latest software release, you should always read our Release Notes , especially when carrying out a software update to a later release level. The latest Release Notes can be found at www.funkwerk-ec.com .		
Liability	While every effort has been made to ensure the accuracy of all information in this manual, Funkwerk Enterprise Communications GmbH cannot assume liability to any party for any loss or damage caused by errors or omissions or by statements of any kind in this document and is only liable within the scope of its terms of sale and delivery. The information in this manual is subject to change without notice. Additional information, changes and Release Notes for bintec gateways can be found at www.funkwerk-ec.com .		
	As multiprotocol gateways, bintec gateways set up WAN connections in accordance with the system configuration. To prevent unintentional charges accumulating, the operation of the product should be carefully monitored. Funkwerk Enterprise Communications GmbH accepts no liability for loss of data, unintentional connection costs and damages resulting from unsupervised operation of the product.		
Trademarks	bintec and the bintec logo are registered trademarks of Funkwerk Enterprise Communications GmbH. Other product names and trademarks mentioned are usually the property of the respective companies and manufacturers.		
Copyright	All rights are reserved. No part of this publication may be reproduced or transmitted in any form or by any means – graphic, electronic, or mechanical – including photocopying, recording in any medium, taping, or storage in information retrieval systems, without the prior written permission of Funkwerk Enterprise Communications GmbH. Adaptation and especially translation of the document is inadmissible without the prior consent of Funkwerk Enterprise Communications GmbH.		
Guidelines and standards	bintec gateways comply with the following guidelines and standards: R&TTE Directive 1999/5/EG CE marking for all EU countries and Switzerland You will find detailed information in the Declarations of Conformity at www.funkwerk-ec.com .		
How to reach Funkwerk Enterprise Communications GmbH	<table border="1"> <tr> <td>Funkwerk Enterprise Communications GmbH Suedwestpark 94 D-90449 Nuremberg Germany Telephone: +49 180 300 9191 0 Fax: +49 180 300 9193 0 Internet: www.funkwerk-ec.com</td> <td>Bintec France 6/8 Avenue de la Grande Lande F-33174 Gradignan France Telephone: +33 5 57 35 63 00 Fax: +33 5 56 89 14 05 Internet: www.bintec.fr</td> </tr> </table>	Funkwerk Enterprise Communications GmbH Suedwestpark 94 D-90449 Nuremberg Germany Telephone: +49 180 300 9191 0 Fax: +49 180 300 9193 0 Internet: www.funkwerk-ec.com	Bintec France 6/8 Avenue de la Grande Lande F-33174 Gradignan France Telephone: +33 5 57 35 63 00 Fax: +33 5 56 89 14 05 Internet: www.bintec.fr
Funkwerk Enterprise Communications GmbH Suedwestpark 94 D-90449 Nuremberg Germany Telephone: +49 180 300 9191 0 Fax: +49 180 300 9193 0 Internet: www.funkwerk-ec.com	Bintec France 6/8 Avenue de la Grande Lande F-33174 Gradignan France Telephone: +33 5 57 35 63 00 Fax: +33 5 56 89 14 05 Internet: www.bintec.fr		

1	Introduction	3
1.1	Scenario	3
1.2	Requirements	3
2	Configuration	5
2.1	Settings in Network Address Translation Menu	5
2.2	NAT Sessions from OUTSIDE	6
2.2.1	NAT Entries for Telnet	7
2.2.2	NAT Entries for Web Server	8
2.2.3	NAT Entries for Terminal Server	9
2.3	NAT Sessions from INSIDE	11
2.3.1	NAT Entries for Administration	12
3	Result	15
3.1	Test	15
3.2	Overview of Configuration Steps	16

1 Introduction


The configuration of Network Address Translation is described in the chapters below.

You have a permanent 2-Mbps connection to the Internet with 8 IP addresses. Your Ethernet interface 3 (eth3) is connected to the access router. This has the IP address 62.10.10.1/29, whereas the remaining IPs from 62.10.10.2 to 62.10.10.6 are entered on Ethernet interface 3. You configure NAT enables for accessing your router with Telnet.

You would also like to access your terminal server and the corporate Web server over the Internet. For administration at partner companies from your internal computer, you always need a certain external IP address.

The Setup Tool is used for the configuration.

1.1 Scenario



1.2 Requirements

The following requirements must be fulfilled for the configuration:

- Basic configuration of router. The basic configuration using the Wizard is recommended.
- A boot image of version 7.1.1 or later.
- A working Internet access. For example, *Company Connect* with 8 IP addresses.

2 Configuration

2.1 Settings in Network Address Translation Menu

You must make settings in the following menu for configuring Network Address Translation:

- Go to **IP → NETWORK ADDRESS TRANSLATION → INTERFACE**.

VPN Access 25 Setup Tool		Bintec Access Networks GmbH
[IP] [NAT] [EDIT]: NAT Configuration (en0-3)		Head_Office
Network Address Translation on Silent Deny no PPTP Passthrough no		
Enter configuration for sessions: requested from OUTSIDE requested from INSIDE		
<input type="button" value="SAVE"/> <input type="button" value="CANCEL"/>		

The following fields are relevant:

Field	Meaning
Silent Deny	If you enable Silent Deny, the router does not answer incoming ICMP packets.
requested from OUT-SIDE	For configuring which connections initialized from outside are allowed to pass through the router.
requested from INSIDE	For configuring whether certain internal PCs receive a permanent external IP address.

Table 2-1: Relevant fields in **IP → NETWORK ADDRESS TRANSLATION → INTERFACE**



If you would like to increase the security of your Internet access, it is advisable to enable **SILENT DENY**.

Note

2.2 NAT Sessions from OUTSIDE

Go to the following menu to configure NAT entries:

■ **IP → NETWORK ADDRESS TRANSLATION → INTERFACE → REQUESTED FROM OUTSIDE → ADD**

VPN Access 25 Setup Tool		Bintec Access Networks GmbH
[IP] [NAT] [EDIT] [OUTSIDE] [ADD]	: NAT -	Head_Office
		sessions from OUTSIDE (en0-3)
Service Protocol	user defined icmp	
Remote Address		
Remote Mask		
External Address		
External Mask		
External Port	any	
Internal Address		
Internal Mask	255.255.255.255	
Internal Port	any	
SAVE	CANCEL	
Use <Space> to select		

The following fields are relevant:

Field	Meaning
Protocol	For configuring the protocol used by the service.

Field	Meaning
Remote Address	If you have a permanent IP address from which you can access the device, you can define restrictions here.
Remote Mask	The subnet mask that belongs to the remote address. This must always be 255.255.255.255 for a single IP.
External Address	The external IP address of the router you access if you have a static IP address.
External Mask	The subnet mask that belongs to the external address. This must always be 255.255.255.255 for a single IP.
External Port	This is the router port you reach from outside.
Internal Address	The IP address to which you wish to be forwarded when you reach the router.
Internal Mask	The subnet mask that belongs to the internal address. This must always be 255.255.255.255 for a single IP.
Internal Port	For configuring the port you wish to reach on the internal system. Leave the entry set to ANY if the internal and external port are the same.

Table 2-2: Relevant fields in **IP → NETWORK ADDRESS TRANSLATION → INTERFACE → REQUESTED FROM OUTSIDE → ADD**

2.2.1 NAT Entries for Telnet

It should be possible to administrate your router using Telnet over the Internet router with the permanent IP address 62.10.10.2.

- Go to **IP → NETWORK ADDRESS TRANSLATION → INTERFACE → REQUESTED FROM OUTSIDE → ADD**

VPN Access 25 Setup Tool		Bintec Access Networks GmbH
[IP] [NAT] [EDIT] [OUTSIDE] [ADD]		Head_Office
sessions from OUTSIDE (en0-3)		
Service Protocol	user defined tcp	
Remote Address		
Remote Mask		
External Address	62.10.10.2	
External Mask	255.255.255.255	
External Port	specify	Port 23
Internal Address	127.0.0.1	
Internal Mask	255.255.255.255	
Internal Port	any	
SAVE		CANCEL

Proceed as follows to configure the enable:

- Set **PROTOCOL** to *tcp*.
- Enter your router's IP address *62.10.10.2* under **EXTERNAL ADDRESS**.
- **EXTERNAL MASK** is set to *255.255.255.255*.
- Set **EXTERNAL PORT** to *specify/23*.
- Configure the **INTERNAL ADDRESS** for the router to the loopback address *127.0.0.1*.
- The **INTERNAL MASK** remains set to *255.255.255.255*.

2.2.2 NAT Entries for Web Server

The internal Web server is to be reachable under the IP address *62.10.10.3*.

- Go to **IP** → **NETWORK ADDRESS TRANSLATION** → **INTERFACE** → **REQUESTED FROM OUTSIDE** → **ADD**

VPN Access 25 Setup Tool		Bintec Access Networks GmbH
[IP]	[NAT]	[EDIT] [OUTSIDE] [ADD] : NAT - Head_Office
		sessions from OUTSIDE (en0-3)
Service Protocol	user defined tcp	
Remote Address		
Remote Mask		
External Address	62.10.10.3	
External Mask	255.255.255.255	
External Port	specify	Port 80
Internal Address	192.168.100.2	
Internal Mask	255.255.255.255	
Internal Port	any	
SAVE		CANCEL

Proceed as follows to configure the enable:

- Set **PROTOCOL** to *tcp*.
- Enter the external IP address for the Web server under **EXTERNAL ADDRESS**, i.e. *62.10.10.3*.
- **EXTERNAL MASK** is set to *255.255.255.255*.
- Set **EXTERNAL PORT** to *specify 80*.
- Configure **INTERNAL ADDRESS** to *192.168.100.2*.
- The **INTERNAL MASK** remains set to *255.255.255.255*.

2.2.3 NAT Entries for Terminal Server

The internal terminal server is to be reachable under the IP address *62.10.10.4*. To prevent attackers easily recognizing from the open port 3389 that you are using a terminal server, you reach port 5000 from outside with the remote desktop.

- Go to **IP → NETWORK ADDRESS TRANSLATION → INTERFACE → REQUESTED FROM OUTSIDE → ADD.**

VPN Access 25 Setup Tool		Bintec Access Networks GmbH
[IP] [NAT] [EDIT] [OUTSIDE] [ADD] : NAT -		Head_Office
sessions from OUTSIDE (en0-3)		
Service	user defined	
Protocol	tcp	
Remote Address		
Remote Mask		
External Address	62.10.10.4	
External Mask	255.255.255.255	
External Port	specify	Port 5000
Internal Address	192.168.100.1	
Internal Mask	255.255.255.255	
Internal Port	specify	Port 3389
SAVE	CANCEL	

Proceed as follows to configure the enable:

- Set **PROTOCOL** to *tcp*.
- Enter the external IP address used for the terminal server under **EXTERNAL ADDRESS**, i.e. *62.10.10.4*.
- **EXTERNAL MASK** is set to *255.255.255.255*.
- Set **EXTERNAL PORT** to *specify 5000*.
- Configure **INTERNAL ADDRESS** to *192.168.100.1*.
- The **INTERNAL MASK** remains set to *255.255.255.255*.
- Set **INTERNAL PORT** to *specify 3389*.

2.3 NAT Sessions from INSIDE

Go to the following menu to configure NAT entries:

- ***IP → NETWORK ADDRESS TRANSLATION → INTERFACE → REQUESTED FROM INSIDE → ADD***

VPN Access 25 Setup Tool		Bintec Access Networks GmbH
[IP] [NAT] [EDIT] [OUTSIDE] [ADD] : NAT Configuration - Head_Office sessions from INSIDE (en0-3)		
Service Protocol	user defined icmp	
Remote Address		
Remote Mask		
Remote Port	any	
External Address		
External Mask	255.255.255.255	
External Port	any	
Internal Address		
Internal Mask		
Internal Port	any	
SAVE	CANCEL	
Use <Space> to select		

The following fields are relevant:

Field	Meaning
Protocol	For configuring the protocol used by the service.
Remote Address	If you have a permanent IP address you are allowed to access, you can define restrictions here.
Remote Mask	The subnet mask that belongs to the remote address. This must always be 255.255.255.255 for a single IP.
Remote Port	The remote port you access if you wish to make restrictions.

Field	Meaning
External Address	The external IP address of the router to which you translate if you have a static IP address.
External Mask	The subnet mask that belongs to the external address. This must always be 255.255.255.255 for a single IP.
External Port	The sender port to which you translate, if applicable.
Internal Address	The IP address of the internal PC.
Internal Mask	The subnet mask that belongs to the internal address. This must always be 255.255.255.255 for a single IP.
Internal Port	For configuring the port used by the PC as sender port.

Table 2-3: Relevant fields in ***IP → NETWORK ADDRESS TRANSLATION → INTERFACE → REQUESTED FROM INSIDE → ADD***

2.3.1 NAT Entries for Administration

The internal PC 192.168.100.3 is used for administrative purposes to access external partner companies over the Internet. The PC here must always use the same IP address as the sender. In this case, for example, 62.10.10.5.

- Go to **IP → NETWORK ADDRESS TRANSLATION → INTERFACE → REQUESTED FROM OUTSIDE → ADD.**

VPN Access 25 Setup Tool		Bintec Access Networks GmbH
[IP] [NAT] [EDIT] [OUTSIDE] [ADD] : NAT Configuration - Head_Office sessions from INSIDE (en0-3)		
Service Protocol	user defined	
Remote Address	any	
Remote Mask		
Remote Port	any	
External Address	62.10.10.5	
External Mask	255.255.255.255	
External Port	any	
Internal Address	192.168.100.3	
Internal Mask	255.255.255.255	
Internal Port	any	
SAVE	CANCEL	

Proceed as follows to configure the entries:

- Set **PROTOCOL** to *any*.
- Enter the external IP address used for the terminal server under **EXTERNAL ADDRESS**, e.g. *62.10.10.5*.
- **EXTERNAL MASK** is set to *255.255.255.255*.
- Configure **INTERNAL ADDRESS**, e.g. to *192.168.100.3*.
- The **INTERNAL MASK** remains set to *255.255.255.255*.

3 Result

You have configured NAT enables so that you can access the router with Telnet over the Internet. You also allow access to your internal Web server and the terminal server over the Internet. In addition, you have assigned your administration PC a permanent IP address for the Internet.

3.1 Test

To check the settings, activate debug mode in the shell with the command `debug all&`. Run Telnet on the router (62.10.10.2) from an external PC on the Internet.

The following message must appear if you are from the IP address 80.65.48.135:

```
12:14:20 DEBUG/INET: NAT: new incoming session on ifc 300 prot 6  
127.0.0.1:23/62.10.10.2:23 <- 80.65.48.135:1024
```

Run Telnet from the administration PC to an external IP address (e.g. 80.65.48.135).

The following message must appear if you access the IP address 80.65.48.135 with Telnet:

```
12:14:20 DEBUG/INET: NAT: new outgoing session on ifc 300 prot 6  
192.168.100.3:1039/62.10.10.5:32788 -> 80.65.48.135:23
```

3.2 Overview of Configuration Steps

Telnet

Field	Menu	Description
Protocol	REQUESTED FROM OUTSIDE ➔ ADD	<i>tcp</i>
External Address	REQUESTED FROM OUTSIDE ➔ ADD	e.g. 62.10.10.2
External Mask	REQUESTED FROM OUTSIDE ➔ ADD	255.255.255.255
External Port	REQUESTED FROM OUTSIDE ➔ ADD	<i>specify 23</i>
Internal Address	REQUESTED FROM OUTSIDE ➔ ADD	127.0.0.1
Internal Mask	REQUESTED FROM OUTSIDE ➔ ADD	255.255.255.255

Web Server

Field	Menu	Description
Protocol	REQUESTED FROM OUTSIDE ➔ ADD	<i>tcp</i>
External Address	REQUESTED FROM OUTSIDE ➔ ADD	e.g. 62.10.10.3
External Mask	REQUESTED FROM OUTSIDE ➔ ADD	255.255.255.255
External Port	REQUESTED FROM OUTSIDE ➔ ADD	<i>specify 80</i>
Internal Address	REQUESTED FROM OUTSIDE ➔ ADD	e.g. 192.168.100.2
Internal Mask	REQUESTED FROM OUTSIDE ➔ ADD	255.255.255.255

Terminal Server

Field	Menu	Description
Protocol	REQUESTED FROM OUTSIDE ➔ ADD	<i>tcp</i>
External Address	REQUESTED FROM OUTSIDE ➔ ADD	e.g. 62.10.10.4
External Mask	REQUESTED FROM OUTSIDE ➔ ADD	255.255.255.255

Field	Menu	Description
External Port	REQUESTED FROM OUTSIDE → ADD	e.g. specify 5000
Internal Address	REQUESTED FROM OUTSIDE → ADD	e.g. 192.168.100.1
Internal Mask	REQUESTED FROM OUTSIDE → ADD	255.255.255.255
External Port	REQUESTED FROM OUTSIDE → ADD	specify 3389

Administration PC

Field	Menu	Description
Protocol	REQUESTED FROM INSIDE → ADD	any
External Address	REQUESTED FROM INSIDE → ADD	e.g. 62.10.10.5
External Mask	REQUESTED FROM INSIDE → ADD	255.255.255.255
Internal Address	REQUESTED FROM INSIDE → ADD	e.g. 192.168.100.3
Internal Mask	REQUESTED FROM INSIDE → ADD	255.255.255.255

