

bintec Workshop

**IPSec VPN with Callback (IP-Address in
B/D channel)**

Copyright © November 8, 2005 Funkwerk Enterprise Communications GmbH
Version 0.9

Purpose	This document is part of the user's guide to the installation and configuration of bintec gateways running software release 7.1.4 or later. For up-to-the-minute information and instructions concerning the latest software release, you should always read our Release Notes , especially when carrying out a software update to a later release level. The latest Release Notes can be found at www.funkwerk-ec.com .		
Liability	While every effort has been made to ensure the accuracy of all information in this manual, Funkwerk Enterprise Communications GmbH cannot assume liability to any party for any loss or damage caused by errors or omissions or by statements of any kind in this document and is only liable within the scope of its terms of sale and delivery. The information in this manual is subject to change without notice. Additional information, changes and Release Notes for bintec gateways can be found at www.funkwerk-ec.com .		
	As multiprotocol gateways, bintec gateways set up WAN connections in accordance with the system configuration. To prevent unintentional charges accumulating, the operation of the product should be carefully monitored. Funkwerk Enterprise Communications GmbH accepts no liability for loss of data, unintentional connection costs and damages resulting from unsupervised operation of the product.		
Trademarks	bintec and the bintec logo are registered trademarks of Funkwerk Enterprise Communications GmbH. Other product names and trademarks mentioned are usually the property of the respective companies and manufacturers.		
Copyright	All rights are reserved. No part of this publication may be reproduced or transmitted in any form or by any means – graphic, electronic, or mechanical – including photocopying, recording in any medium, taping, or storage in information retrieval systems, without the prior written permission of Funkwerk Enterprise Communications GmbH. Adaptation and especially translation of the document is inadmissible without the prior consent of Funkwerk Enterprise Communications GmbH.		
Guidelines and standards	bintec gateways comply with the following guidelines and standards: R&TTE Directive 1999/5/EG CE marking for all EU countries and Switzerland You will find detailed information in the Declarations of Conformity at www.funkwerk-ec.com .		
How to reach Funkwerk Enterprise Communications GmbH	<table border="1"> <tr> <td>Funkwerk Enterprise Communications GmbH Suedwestpark 94 D-90449 Nuremberg Germany Telephone: +49 180 300 9191 0 Fax: +49 180 300 9193 0 Internet: www.funkwerk-ec.com</td> <td>Bintec France 6/8 Avenue de la Grande Lande F-33174 Gradignan France Telephone: +33 5 57 35 63 00 Fax: +33 5 56 89 14 05 Internet: www.bintec.fr</td> </tr> </table>	Funkwerk Enterprise Communications GmbH Suedwestpark 94 D-90449 Nuremberg Germany Telephone: +49 180 300 9191 0 Fax: +49 180 300 9193 0 Internet: www.funkwerk-ec.com	Bintec France 6/8 Avenue de la Grande Lande F-33174 Gradignan France Telephone: +33 5 57 35 63 00 Fax: +33 5 56 89 14 05 Internet: www.bintec.fr
Funkwerk Enterprise Communications GmbH Suedwestpark 94 D-90449 Nuremberg Germany Telephone: +49 180 300 9191 0 Fax: +49 180 300 9193 0 Internet: www.funkwerk-ec.com	Bintec France 6/8 Avenue de la Grande Lande F-33174 Gradignan France Telephone: +33 5 57 35 63 00 Fax: +33 5 56 89 14 05 Internet: www.bintec.fr		

1	Introduction	3
1.1	Scenario	3
1.2	Requirements	3
2	Configuration of ISDN Interface	5
3	Configuration of Internet Connection (WAN Partner)	7
4	Configuration of IPSec Connection	9
4.1	Configuration of IPSec Peer	9
4.2	Configuration of Virtual Interface	10
4.3	Configuration of ISDN Callback Mechanism	12
4.4	Configuration of Parameters for IPSec Phase 1	14
5	Result	17
5.1	Test of Connection and ISDN Callback	17
5.2	Overview of Configuration Steps	19

1 Introduction

The configuration of IPSec callback with IP address transfer in the B/D-channel is described in the following chapters using two Bintec VPN Access 25 gateways (software version 7.1.6 patch 3).

This feature has only been available since firmware version 7.1.4. It enables dynamically assigned IP addresses to be transferred in the B/D-channel.

1.1 Scenario

A branch office of a company is to be connected to the head office over an IP-Sec tunnel. An ISDN connection is available for the Internet connection in both the branch office and head office. Both devices receive their IP address dynamically from the ISP.



1.2 Requirements

- Two Bintec VPN Access 25 gateways.
- At least firmware version 7.1.4.
- An ISDN S0 connection per Bintec VPN Access 25 gateway.
- Connect your LAN to the ETH1 interface of your gateway.
- ISDN Internet connection.

2 Configuration of ISDN Interface

You must configure "Incoming Call Answering" so that for a call to a certain number, this is used for ISDN callback.

- Go to **ISDN S0 → INCOMING CALL ANSWERING → ADD**.

VPN Access 25 Setup Tool		Bintec Access Networks GmbH
[SLOT 0 UNIT 4 ISDN BRI] [INCOMING] [EDIT]		vpn25
Item	IPSec	
Number	100	
Mode	right to left	
Bearer	any	
SAVE		CANCEL
Use <Space> to select		

The following fields are relevant:

Field	Meaning
Item	Service for which this number is to be used.
Number	Number for the service.
Mode	Type of number check.
Bearer	Is to respond to a voice or data call or both.

Table 2-1: Relevant fields in **ISDN S0 → INCOMING CALL ANSWERING → ADD**

Proceed as follows to define the necessary settings:

- Set **ITEM** to **IPSec**.
- Enter the desired number under **NUMBER**, e.g. **100**.
- Set **MODE** to **right to left**.



If your gateway is connected to a point-to-point ISDN connection, it may be necessary to set to *left to right!*

Note

- Set **BEARER** to *any*.
- Press **SAVE** to confirm your settings.

You have now configured the gateway for using calls via the number 100 for IP-Sec.

3 Configuration of Internet Connection (WAN Partner)

Use the Bintec manual or Bintec FAQs for this configuration.

4 Configuration of IPSec Connection

This workshop describes the relevant configuration steps for ISDN callback. A more detailed description of configuring an IPSec connection can be found in the Bintec User's Guide or the relevant FAQs.

4.1 Configuration of IPSec Peer

- Go to **IPSEC → CONFIGURE PEERS → APPEND.**

VPN Access 25 Setup Tool [IPSEC] [PEERS] [EDIT] : Configure Peer	Bintec Access Networks GmbH vpn25
Description: Branch office Admin Status: up Oper Status: dormant Peer Address: Peer IDs: Branch office Pre Shared Key: *	
IPSec Callback > Peer specific Settings > Virtual Interface: yes Interface IP Settings >	
SAVE	CANCEL
Enter string, max. length = 255 chars	

The following fields are relevant:

Field	Meaning
Description	Freely selectable description of peer.
Peer Address	IP address of remote terminal.
Peer IDs	Identity (name) of remote terminal.
Pre Shared Key	Secret key for IPSec negotiation.

Field	Meaning
Virtual Interface	Virtual interfaces can be used.

Table 4-1: Relevant fields in **IPSEC → CONFIGURE PEERS → APPEND**

Proceed as follows to define the necessary settings:

- Enter a name under **PEER ADDRESS**, e.g. *branch office*.
- Enter a **PRE SHARED KEY**, e.g. *test*.
- Set **VIRTUAL INTERFACE**, e.g. *yes*.
- Press **SAVE** to confirm your settings.



Note

The **PRE SHARED KEY** should be at least 25 to 30 characters long in actual operation and not contain any known words or number combinations. A random sequence of upper and lower case letters, numbers and special characters should preferably be used.

You have now completed the basic configuration of an IPSec peer.

4.2 Configuration of Virtual Interface

- Go to **IPSEC → CONFIGURE PEERS → RELEVANT PEER → INTERFACE IP SETTINGS → BASIC IP SETTINGS**.

VPN Access 25 Setup Tool		Bintec Access Networks GmbH
[IPSEC] [PEERS] [EDIT] [IP] [BASIC] : IP Settings (Head Office)		vpn25
IP Transit Network	no	
Local IP Address	192.168.1.1	
Default Route	no	
Remote IP Address	192.168.0.0	
Remote Netmask	255.255.255.0	
SAVE	CANCEL	
Use <Space> to select		

The following fields are relevant:

Field	Meaning
IP Transit Network	Is a transit network to be used?
Local IP Address	Local IP address of virtual interface.
Default Route	Is the virtual interface to be used as default gateway?
Remote IP Address	IP address or network to be reached over the tunnel.
Remote Netmask	Netmask of host or network.

Table 4-2: Relevant fields in **IPSEC → CONFIGURE PEERS → RELEVANT PEER → INTERFACE IP SETTINGS → BASIC IP SETTINGS**

Proceed as follows to define the necessary settings:

- Set **IP TRANSIT NETWORK** to *no*.
- Enter your local IP address under **LOCAL IP ADDRESS**, e.g. *192.168.1.1*.
- Set **DEFAULT ROUTE** to *no*.
- Enter the network address of the remote terminal under **REMOTE IP ADDRESS**, e.g. *192.168.0.0*.

- Enter the netmask of the remote terminal under **REMOTE NETMASK**, e.g. 255.255.255.0.
- Press **SAVE** to confirm your settings.

- Go to **IP → ROUTING**.

VPN Access 25 Setup Tool						Bintec Access Networks GmbH
[IP] [ROUTING]: IP Routing						vpn25
The flags are: U (Up), D (Dormant), B (Blocked), G (Gateway Route), I (Interface Route), S (Subnet Route), H (Host Route), E (Extended Route)						
Destination	Gateway	Mask	Flags	Met.	Interface	Pro
192.168.1.0	192.168.1.1	255.255.255.0		0	en0-1	loc
192.168.0.0	192.168.1.1	255.255.255.0	DG	0	Branch Of	loc
default		0.0.0.0	DI	1	Internet	loc
ADD	ADDEXT	DELETE	EXIT			
Press <Ctrl-n>, <Ctrl-p> to scroll, <Space> tag/untag DELETE, <Return> to edit						

You can see that an additional entry has been created in the routing table. This enables the network 192.168.0.0 to reach the branch office over the IPSec interface.

You have now configured a virtual IPSec interface, over which a remote network can be reached.

4.3 Configuration of ISDN Callback Mechanism

- Go to **IPSEC → CONFIGURE PEERS → IPSEC CALLBACK**.

VPN Access 25 Setup Tool		Bintec Access Networks GmbH
[IPSEC] [PEERS] [EDIT] [CALLBACK] : ISDN Callback Peer		vpn25
(Head Office)		
ISDN Callback: both		
Incoming ISDN Number:101		
Outgoing ISDN Number:101		
Transfer own IP Address over ISDN: yes		
Mode : autodetect best possible mode (D or B channel)		
SAVE		CANCEL
Use <Space> to select		

The following fields are relevant:

Field	Meaning
ISDN Callback	Activates or deactivates ISDN callback.
Incoming ISDN Number	Number that arrives when the peer initiates the callback.
Outgoing ISDN Number	Number that is dialed when an ISDN callback is initiated.
Transfer own IP Address over ISDN	Determines whether the IP address is transferred over ISDN or not.
Mode	Determines how the IP address is transferred over ISDN.

Table 4-3: Relevant fields in **IPSEC → CONFIGURE PEERS → IPSEC CALLBACK**

Proceed as follows to define the necessary settings:

- Set **ISDN CALLBACK** to *both*.
- Enter the number coming from the remote terminal under **INCOMING ISDN NUMBER**, e.g. *101*.
- Enter the number on which the remote terminal can be reached under **OUTGOING ISDN NUMBER**, e.g. *101*.

- Set **TRANSFER OWN IP ADDRESS OVER ISDN** to yes.
- Set **MODE** to *autodetect best possible mode (D or B channel)*.
- Press **SAVE** to confirm your settings.


Note

If you wish to transfer the IP address only in the D-channel, you must ensure that LLC (Low Layer Compatibility) and/or SUBADDR (SubAddress) are transferred over the ISDN network. If this is not the case, you must switch to transmission in the B-channel. You should therefore set the **MODE** to *autodetect best possible mode (D or B channel)*, as a B-channel is set up as an alternative if D-channel transmission fails.

You have now activated the ISDN callback mechanism, so that both ends can transfer their IP addresses to set up an IPSec tunnel.

4.4 Configuration of Parameters for IPSec Phase 1

- Go to **IPSEC → IKE (PHASE 1) DEFAULTS → EDIT**.

Select the desired configuration, e.g. ** autogenerated**.

VPN Access 25 Setup Tool		Bintec Access Networks GmbH
[IPSEC] [PHASE1] [EDIT]		vpn25
Description (Idx 1)	:	<i>* autogenerated*</i>
Proposal	:	1 (Blowfish/MD5)
Lifetime	:	use default
Group	:	2 (1024-bit MODP)
Authentication Method	:	Pre Shared Keys
Mode	:	id_protect
Heartbeats	:	none
Block Time	:	0
Local ID	:	Head Office
Local Certificate	:	none
CA Certificates	:	
Nat Traversal	:	enabled
View Proposals >		
Edit Lifetimes >		
SAVE		CANCEL
Enter string, max. length = 255 chars		

The following field is relevant:

Field	Meaning
Mode	Mode of IPSec Phase 1 negotiation.

Table 4-4: Relevant field in **IPSEC → IKE (PHASE 1) DEFAULTS → EDIT**

Proceed as follows to define the necessary settings:

- Set **MODE** to *id_protect*.
- Configure the other parameters according to your requirements.
- Press **SAVE** to confirm your settings.



Note

As the IP addresses are exchanged by the ISDN callback mechanism, *id_protect* can be entered here as mode. This achieves higher security in the authentication of the IPSec connection.

Return to the main menu and finally save your new configuration in the flash memory with **EXIT** and **SAVE AS BOOT CONFIGURATION AND EXIT**.

5 Result

5.1 Test of Connection and ISDN Callback

The connection is set up by the head office with a ping. You can follow the set-up of the connection and the ISDN callback by entering the command `debug all` in the command line.

```

00:02:28 INFO/INET: dialup if 100001 prot 1 192.168.1.2:2048->192.168.0.2:3420
00:02:28 INFO/INET: dialup if 10001 prot 17 0.0.0.0:500->0.0.0.0:500
00:02:28 DEBUG/PPP: Internet: dial number <00101901929>
00:02:31 DEBUG/PPP: Layer 1 protocol hdlc, 64000 bit/sec
00:02:31 DEBUG/PPP: Internet: set ifSpeed, number of active connections: 0/0/0
00:02:31 DEBUG/PPP: Internet: set ifSpeed, number of active connections: 1/1/1
00:02:31 DEBUG/PPP: Internet: outgoing connection established
00:02:31 INFO/PPP: Internet: local IP address is 213.7.46.137, remote is 62.104.219.41
00:02:31 DEBUG/INET: NAT: new outgoing session on ifc 10001 prot 17
192.168.1.1:4500/213.7.46.137:32769 -> 213.7.0.117:32769
00:02:31 INFO/IPSEC: IPSEC CB - need callback from Peer "branch office"
00:02:31 INFO/IPSEC: IPSEC CB - trigger callback at Peer "branch office" (do call "*->"101")
00:02:31 INFO/IPSEC: IPSEC CB - Peer "branch office", trigger call "*" -> "101" is ALERTING
00:02:41 INFO/IPSEC: IPSEC CB - Trigger Call by Peer "branch office" successfully transmitted IP
213.7.46.137 / Token 4203 via B channel
00:02:41 DEBUG/INET: NAT: new incoming session on ifc 10001 prot 17
213.7.46.137:4500/213.7.46.137:4500 <- 213.7.0.117:32770
00:02:41 DEBUG/IPSEC: P1: peer 0 () sa 2 (R): new ip 213.7.46.137 <- ip 213.7.0.117
00:02:41 INFO/IPSEC: P1: peer 0 () sa 2 (R): Vendor ID: 213.7.0.117:32770 (No Id) is 'BINTEC'
00:02:41 INFO/IPSEC: P1: peer 0 () sa 2 (R): Vendor ID: 213.7.0.117:32770 (No Id) is 'BINTEC
Heartbeats Version 1'
00:02:41 INFO/IPSEC: P1: peer 0 () sa 2 (R): Vendor ID: 213.7.0.117:32770 (No Id) is 'RFC XXXX'
00:02:41 INFO/IPSEC: P1: peer 0 () sa 2 (R): Vendor ID: 213.7.0.117:32770 (No Id) is 'draft-ietf-
ipsec-nat-t-ike-03'
00:02:41 INFO/IPSEC: P1: peer 0 () sa 2 (R): Vendor ID: 213.7.0.117:32770 (No Id) is 'draft-ietf-
ipsec-nat-t-ike-02'
00:02:41 INFO/IPSEC: P1: peer 0 () sa 2 (R): Vendor ID: 213.7.0.117:32770 (No Id) is 'draft-ietf-
ipsec-nat-t-ike-02'
00:02:41 INFO/IPSEC: P1: peer 0 () sa 2 (R): Vendor ID: 213.7.0.117:32770 (No Id) is 'draft-ietf-
ipsec-nat-t-ike-00'
00:02:41 DEBUG/IPSEC: P1: peer 0 () sa 2 (R): token payload: received token 4203
00:02:41 DEBUG/IPSEC: P1: peer 1 (branch office) sa 2 (R): identified ip 213.7.46.137 <- ip
213.7.0.117
00:02:41 INFO/ACCT: ISDN: 01.01.1970,00:02:31,00:02:41,0,50,66,6,6,,0,100,101,7/0,90,0,ipsec
callback
00:02:41 DEBUG/ISDN: stack 0: disconnect cause: normal call clearing (0x90)
00:02:42 INFO/IPSEC: New Bundle -2 (Peer 1 Traffic -1)
00:02:42 INFO/IPSEC: P1: peer 1 (branch office) sa 2 (R): done id fqdn(any:0,[0..7]=head office)
<- id fqdn(any:0,[0..6]=branch office) IP[b08aff69 52147e68 : 2e024f96 ed2eae37]
00:02:42 INFO/IPSEC: P2: peer 1 (branch office) traf 0 bundle -2 (I): created
192.168.1.0/192.168.1.0:0 < any > 192.168.0.0/192.168.0.0:0 rekeyed 0
00:02:42 DEBUG/IPSEC: P2: peer 1 (branch office) traf 0 bundle -2 (I): SA 3 established
ESP[75fc1b68] in[0] Mode tunnel enc blowfish-cbc(16) auth md5(16)
00:02:42 DEBUG/IPSEC: P2: peer 1 (branch office) traf 0 bundle -2 (I): SA 4 established
ESP[4fcbcfdd] out[0] Mode tunnel enc blowfish-cbc(16) auth md5(16)
00:02:42 INFO/IPSEC: Activate Bundle -2 (Peer 1 Traffic -1)
00:02:42 INFO/IPSEC: P2: peer 1 (branch office) traf 0 bundle -2 (I): established
(213.7.46.137<->213.7.0.117) with 2 SAs life 28800 Sec/0 Kb rekey 23040 Sec/0 Kb Hb none

```

Here the IP address has been successfully transferred in the B-channel and the IPSec tunnel has been set up.

5.2 Overview of Configuration Steps

Field	Menu	Description	Compulsory field
Item	ISDN S0 → INCOMING CALL ANSWERING → ADD	IPSec	Yes
Number	ISDN S0 → INCOMING CALL ANSWERING → ADD	e.g. 100	Yes
Mode	ISDN S0 → INCOMING CALL ANSWERING → ADD	right to left	Yes
Bearer	ISDN S0 → INCOMING CALL ANSWERING → ADD	any	Yes
Description	IPSEC → CONFIGURE PEERS → APPEND	e.g. branch office	Yes
Peer IDs	IPSEC → CONFIGURE PEERS → APPEND	e.g. branch office	Yes
Pre Shared Key	IPSEC → CONFIGURE PEERS → APPEND	e.g. Test	Yes
Virtual Interface	IPSEC → CONFIGURE PEERS → APPEND	e.g. yes	Yes
IP Transit Network	IPSEC → CONFIGURE PEERS → RELEVANT PEER → INTERFACE IP SETTINGS → BASIC IP SETTINGS	no	Yes
Local IP Address	IPSEC → CONFIGURE PEERS → RELEVANT PEER → INTERFACE IP SETTINGS → BASIC IP SETTINGS	e.g. 192.168.1.1	Yes
Default Route	IPSEC → CONFIGURE PEERS → RELEVANT PEER → INTERFACE IP SETTINGS → BASIC IP SETTINGS	no	Yes
Remote IP Address	IPSEC → CONFIGURE PEERS → RELEVANT PEER → INTERFACE IP SETTINGS → BASIC IP SETTINGS	e.g. 192.168.0.0	Yes
Remote Netmask	IPSEC → CONFIGURE PEERS → RELEVANT PEER → INTERFACE IP SETTINGS → BASIC IP SETTINGS	e.g. 255.255.255.0	Yes

Field	Menu	Description	Compulsory field
ISDN Callback	IPSEC → CONFIGURE PEERS → IPSEC CALLBACK	<i>both</i>	Yes
Incoming ISDN Number	IPSEC → CONFIGURE PEERS → IPSEC CALLBACK	e.g. 101	Yes
Outgoing ISDN Number	IPSEC → CONFIGURE PEERS → IPSEC CALLBACK	e.g. 101	Yes
Transfer own IP Address over ISDN	IPSEC → CONFIGURE PEERS → IPSEC CALLBACK	yes	Yes
Mode	IPSEC → CONFIGURE PEERS → IPSEC CALLBACK	<i>autodetect best possible mode (D or B channel)</i>	Yes
Authentication Method	IPSEC → IKE (PHASE 1) DEFAULTS → EDIT → AUTOGENERATED	<i>ip_protect</i>	Yes