



PRIME Gateway

Teldat-Dm 823-I

Copyright© Version 11.06 Teldat SA

Legal Notice

Warranty

This publication is subject to change.

Teldat offers no warranty whatsoever for information contained in this manual.

Teldat is not liable for any direct, indirect, collateral, consequential or any other damage connected to the delivery, supply or use of this manual.

Table of Contents

I	Related Documents	1
Chapter 1	Introduction	2
1.1	PLC PRIME	2
1.2	PRIME Base Node	4
1.3	PRIME Service Node	4
1.4	PRIME topology	5
1.5	DLMS-COSEM over TCP	5
1.6	Firmware Upgrade Protocol	6
1.7	PHY Layer Extension feature	7
1.8	PRIME Sniffer	8
1.9	SNMP management	9
Chapter 2	Configuration	10
2.1	Getting the PRIME Interface	10
2.2	Configuration Commands for the PRIME Gateway	10
2.2.1	BN-CHANNEL	11
2.2.2	FUP-PORT	12
2.2.3	LIST	12
2.2.4	LOCAL-IP	13
2.2.5	LOCAL-PORT	14
2.2.6	NO	14
2.2.7	NODE-MODE	15
2.2.8	PHY-LAYER-EXTENSION	15
2.2.9	PLC-SIGNAL	18
2.2.10	PRIME-RELEASE	19
2.2.11	SNIFFER	19
2.2.12	TOPOLOGY	21
2.2.13	TRACE-LEVEL	26
2.2.14	VRF	27
Chapter 3	Monitoring	28
3.1	Accessing the interface monitoring	28
3.2	Interface monitoring	29
3.2.1	CLEAR STATISTICS	30
3.2.2	FUP	30
3.2.3	LIST	35
3.2.4	RESET	54
3.2.5	UPGRADE-FIRMWARE	55
Chapter 4	Upgrading PRIME Firmware	56

4.1	Introduction	56
4.2	Procedure	56
4.2.1	Obtaining the upgrade.	56
4.2.2	Transferring to the device	58
4.2.3	Upgrading the module	59
Chapter 5	Examples	61
5.1	PRIME basic with Sniffer enabled.	61
Chapter 6	Annex A. SNMP data formats	63
6.1	Sniffer format for SNMP managed TCP sessions	63
6.2	Topology format for SNMP managed TCP sessions	65
Chapter 7	Annex B. Topology file	67
7.1	File format	67

I Related Documents

Teldat-Dm 704-I Configuration and Monitoring

Teldat-Dm 772-I Common Configuration Interfaces

Chapter 1 Introduction


1.1 PLC PRIME

In the past few years, some European governments have been passing legislation that forces electrical utilities to provide customers with readings of their electrical consumption.

This new legislation requires that all domestic electricity meters can be remotely managed and include a real-time reading system. These new electricity meters, which will need to be permanently connected to centralized control centers (SCADA), are called smart meters and are now part of the so-called smart grid.

Power Line Communication (PLC) technology is gaining widespread acceptance as one of the preferred technologies for the implementation of smart grids. PLC uses the electricity transmission lines themselves to deploy the telecommunications functionalities. Since the grid itself provides the physical communication channel needed to implement the smart grid concept, there is no need to invest in additional infrastructure.


The PRIME (PowerLine Intelligent Metering Evolution) standard emerged in response to the new Spanish legislation ruling. The aim of PRIME was to create an open, non-proprietary public standard. The PRIME Alliance was created to provide a discussion forum aimed at defining the standard. It brings together the different key players in the electricity distribution industry: distribution companies, meter manufacturers, semiconductor companies, telecommunications companies and research institutions.



PRIME is based on PLC technology for low voltage electrical networks. It is a PLC system for narrowband data transmission, based on Orthogonal Frequency Division Multiplexing (OFDM). Its main features are:

- Operates on CENELEC A-B-C, FCC and ARIB bands
- OFDM-based technology.
- Several types of digital coding: DBPSK, DQPSK, D8PSK

PRIME defines several layers at the communications layer:



Convergence layer (CL)

This layer classifies traffic by associating it with its MAC connection address. This layer performs the mapping of any kind of data traffic and may include header suppression functions. The convergence layer is divided into two sublayers:

- **Common Part Convergence Sublayer (CPCS)**. This provides a set of generic services: Segmentation and Reassembly.
- **Service Specific Convergence Sublayer (SSCS)**. This defines the type of communication between the different

subnet nodes. It is responsible for delivering the data exchanged between nodes to the management application layer of the smart grid.

PRIME specifies 4 kinds of SSCS:

- NULL
- IEC-61334-4-32
- IPv4
- IPv6

The PRIME MAC layer provides core MAC functionalities such as:

- Channel access
- Bandwidth allocation
- Connection establishment/maintenance.
- Topology resolution.

This layer provides two interfaces: an interface to the CL named MAC SAP (Service Access Point) and an interface to the Management Plane called MLME (MAC Layer Management Entity) SAP. The first one is mainly used for data transmissions over a PRIME network, while the second is used to externally modify the configuration and the behavior of this layer.

Each node has a universal MAC address - 48 bits (the EUI-48; IEEE Std 802-2001). Each manufacturer assigns this address during the manufacturing process. Said address is used to universally identify a node during network registration. Each subnetwork only has one Base Node, so the EUI-48 of the Base Node identifies its subnetwork uniquely. This EUI-48 is called the Subnetwork Address (SNA).

A Base Node is primarily responsible for setting up and maintaining a subnetwork. In order to execute its task, the Base Node performs the following:

- Beacon transmission at fixed intervals of time
- Promotion and demotion of terminals and switches
- Device registration management
- Connection setup and management
- Channel access arbitration
- Distribution of random sequences to obtain encryption keys
- Multicast group management

Implements the transmission and reception physical layer between neighboring nodes using OFDM technology. It adapts data connection speeds based on the signal.

The PRIME PHY layer is designed to transmit and receive over power lines originally intended for power distribution at 50-60 Hz AC.

Using this medium for communications at higher frequencies poses some technically challenging problems:

- Distribution networks are usually made up of a random variety of conductor types, which translates into loads of different impedances. Such a network has an amplitude and phase response that varies widely with frequency. Furthermore, the channel characteristics can also vary with time as the loads on the network change.
- Interference also affects power lines. Electric appliances with different kind of motors, as well as switching power supplies and halogen lamps, create impulse noises that reduce the reliability of communication signals. The noise is also location-dependent due to attenuation.

Thanks to its combination of approaches, the PRIME PHY layer allows for robust high speed and low cost communications over power lines. This simple yet powerful scheme is based on adaptively modulated Orthogonal Frequency Division Multiplexing (OFDM), along with forward error correction and data interleaving.

The frequency band used depends on local regulations, which ranges from 3 kHz to 500 kHz. Its application is subject to the local regulations in force, e.g., EN 50065 1:2001+A1:2010 in Europe or FCC part 15 in the US.

Region	Regulator	Freq. Band	Comments
Europe	CENELEC	3-95 KHz	A- Energy Providers
		95--125 KHz	B- Open for users
		125-140 KHz	C- Open for users; regulated CSMA access
		140-148,5 KHz	D- Open for users
USA	FCC	10-490 KHz	
Japan	ARIB	10-145 KHz	
China	EPRI	3-95 KHz	Not Regulated
		3-500 KHz	

PRIME 1.3 release can operate in the CENELEC-A band only.

Differential modulations are used, with one of three possible constellations: DBPSK, DQPSK or D8PSK. An additive scrambler is used to prevent long sequences of identical bits from arising. Finally, $\frac{1}{2}$ rate convolutional coding and repetition code will be used along with bit interleaving.

The topology generated by a PRIME communications network has a tree structure. There are two kinds of nodes defined by PRIME to develop this structure type:

- BASE NODE
- SERVICE NODE

Communication between the Base node and the Service nodes is carried out in accordance with a master/slave model.

The PRIME Alliance has defined two release of the standard PRIME:

- PRIME 1.3
- PRIME 1.4

The PRIME 1.4 release include some improvements which allow to increase network performance and reliability. Both releases are not compatible, this means that all elements in a PRIME network must have the same PRIME release.

1.2 PRIME Base Node


The Base Node (also known as hub or PRIME data hub) represents the center or root of the system, with all communications originating there. Base nodes are usually connected to secondary substations (electrical infrastructures where the voltage is stepped down to lower values). Base nodes are responsible for controlling all dependent subnets, including all the service nodes.

The PRIME Gateway can operate as a Base Node and a Service Node. The most common mode of operation is Base Node.

1.3 PRIME Service Node

Each node in a PRIME subnet is called a Service Node. Among other functionalities, service nodes are responsible for implementing the smart meters. In order to cover greater distances and improve performance in the PRIME subnet, service nodes can have two states in the PRIME subnet environment:

- **TERMINAL:** A service node is in TERMINAL state when it is the last device in the PRIME subnet tree structure (that is, no other service node depends on it to gain access to the Base Node).
- **SWITCH:** In certain circumstances, service nodes can be promoted to SWITCH state. When a service node is promoted to SWITCH state, it relays data exchanged between the Base Node and a Service Node connected to the subnet. The service node changes its state in real time, depending on the network conditions (attenuation, noise, etc.). This change in state is dynamic, so it can change back and forth over time.



The PRIME Gateway acts as Service Node only to provide IP connection between a Base Node and a PRIME sub-network. That is, the Service Node operates always in SWITCH mode and transfers all PLC PRIME traffic from the local subnet to the Base Node. This functionality mode is known as PHY layer extension or TICKET-65 on PRIME Alliance.




Note

PRIME Gateway as Service Node is not available in all PRIME devices. Please contact our Technical Service for more information on the devices that support this feature.

1.4 PRIME topology

PRIME uses the grid to create and maintain the subnet topology. It allows the smart grid to be monitored in real time. A PRIME subnet is mainly used to access the smart meters.

A PRIME subnetwork is a tree with the two types of nodes: a Base Node and several Service Nodes.




The PRIME Gateway offers a variety of tools that help monitor the subnetwork topology in real time, as well as store changes using events. This information can be accessed through CLI, SNMP or FTP sessions.

1.5 DLMS-COSEM over TCP


PRIME has adopted the IEC 62056 suite (DLMS-COSEM) as the preferred choice of application layer for smart grid deployments.

DLMS is a suite of open standards developed and maintained by the DLMS User Association. COSEM is part of the

DLMS protocol stack. DLMS primarily covers two protocols (the Application protocol and the Transport protocol) that define the standard method to model and transfer metered data and other classified functions of the energy meter. These protocols are officially endorsed and registered by the International Electrotechnical Commission (IEC) under IEC 62056.



The PRIME Gateway allows the Data Concentrator Unit for Smart Meters to communicate with the meters connected to the PRIME subnetwork on the Base Node. The PRIME Gateway provides transparent access to meters (Service Nodes) through the PRIME Convergence Link Layer (LLC) with IEC-61334-4-32 connections. Connection between the application and the PRIME Gateway is obtained through a TCP/IP session.




PRIME define DLMS-COSEM over TCP as Ticket#67.

1.6 Firmware Upgrade Protocol

When in Base Node mode, the PRIME Gateway can upgrade the firmware of all service nodes connected to the PRIME network. To make this task easier, the Base Node implements the Firmware Upgrade Protocol.

The purpose of the Firmware Upgrade Protocol is to manage firmware upgrade operations in PRIME Base Nodes from any external application, such as Data Concentrators or Network Management Systems. The connection between the Management System and the Base Node is done through a TCP/IP session.

The protocol used to exchange the messages between the Base Node and the Management System is a custom simple binary protocol. When the application wants to start a Firmware Upgrade process, it establishes a TCP/IP connection with the FUP port configured in the Base Node. This connection remains open until the process is completed.



The Firmware Upgrade Protocol defines a set of messages that enable the configuration and firmware updating of Service Nodes.

The Service Nodes to upgrade are selected based on a list which includes the PRIME MAC address of selected Nodes. This list is sent to the Base Node in a FUP command.

The most important features of the Firmware Upgrade mechanism are the following

- Ability to work in unicast and multicast.
- May change the size of data packets depending on channel conditions.
- Ability to request basic information from the Service Nodes at any time (such as device model, firmware version, etc.).
- Can be canceled at any time.
- Can check the integrity of the downloaded FW once reception is complete.
- The new firmware is executed in the Service Nodes only when commanded to do so.
- Ability to reject the new firmware after a “test” period and switch to the former version.

In environments where a Firmware Upgrade Protocol application is not available, the PRIME Gateway implements a way to initiate and cancel a limited FUP process.

The FUP command in the monitoring menu helps trigger a local FUP process. See [FUP](#) on page 30 under the monitoring menu.

For more information on FUP implementation, please contact our support department.

1.7 PHY Layer Extension feature

The PHY Layer Extension is a feature designed to increase the number of Service Nodes that a Base Node can control in a Multi-transformer Secondary Substation scenario.

Generally speaking, in secondary substations with multiple transformers (and where low voltage lines are independent of each other), there is not enough power transfer of PRIME PLC signal between low voltage busbars. Service Nodes that are electrically connected to a different transformer to the one the Base Node is connected to are not able to communicate properly. For them to behave well in a PRIME network, a Base Node will need to be installed for each transformer.


Thanks to the PHY layer extension feature, installing several Base Nodes in a substation with multiple transformers

is not necessary.

For it to work, a repeater must be installed in each of the additional busbars found on the secondary transformers. The repeater reproduces Base Node messages addressed to any Service Node connected to the secondary busbars. This repeater can be found in a special Service Node known as an Auxiliary Node.

From the point of view of the PRIME PLC network, the Auxiliary Node always behaves as a PRIME SWITCH. It always registers in the Base Node as a SWITCH. The PHY layer communication between the Base Node and the Auxiliary Node is carried out through UDP/IP datagrams.

The following image depicts a scenario where a Base Node is able to manage the Service Nodes connected to two different transformers in a substation.



The PRIME Gateway, in Base Node mode, may connect to several Service Nodes that work as Auxiliary Nodes.

The PRIME Gateway, in Service Node mode, is able to work as an Auxiliary Node.

The PHY layer extension for the Multi-transformer Secondary Substation feature is also known as Ticket#65.

Note

The PHY Layer Extension feature is not available in all PRIME devices. Please contact our Technical Service for more information on the devices that support this feature.

1.8 PRIME Sniffer

From the PRIME Node, the PRIME Gateway can monitor the PRIME packets in the PLC network transferred between connected nodes.

The Sniffer protocol has been developed to monitor data traffic on power line networks. This tool focuses on the PRIME (versions 1.3 and 1.4) protocol. The PRIME Gateway snoops the power line to catch the PRIME packets at the PHY layer. The PRIME Gateway will send the packet sent over the network through a TCP/IP connection. The sniffer tool can be used to:

- Analyze network problems
- Gather network statistics and report on them
- Monitor network usage
- Debug network protocols
- Improve network understanding

Sniffer frames contain the received PDU and some extra information related to the PHY layer, which is included in

the header part:

- Sniffer frame version: 2 bytes
- Sniffer type version
- Modulation scheme of the received frame
- Length of the PDU in PHY symbols
- PRIME-defined measurement of the SNR
- Channel in which the frame has been received
- TimeStart/TimeEnd: high precision internal counter to measure the length (time) of the PDUs in hundredths of microseconds
- RSSI in dBuV
- CRC flag to indicate if the PLC frame has a valid CRC.
- Length of the PDU in bytes

The Sniffer data can be sent to a Sniffer application or a TCP server controlled by SNMP commands.

The information gathered from the PRIME Sniffer Protocol by the PRIME Gateway can be sent through a TCP session to a Sniffer application. The Sniffer application must open the TCP session to the Gateway.

The Gateway supports several SNMP commands allowing TCP transfer of Sniffer data. For SNMP Sniffer control, the Gateway opens a TCP session in a TCP server configured by SNMP.

The format of sniffer data varies depending on the transfer method. For Sniffer applications, the data format is the one used with the Microchip PLC Sniffer tool. For SNMP commands, the data format is the one described in [Sniffer format for SNMP managed TCP sessions](#) on page 63.

1.9 SNMP management

PRIME gateway devices support the SNMP management protocol. To fully manage the PRIME network, the PRIME Gateway includes a SNMP MIB for the PRIME interface.

The PRIME MIB may be loaded from `teldat-mon-interf-prime-mib.mib`

This MIB may provide the following information about the PRIME network:

- Network uptime.
- Statistics about the number of terminals, number of switches, switching levels, nodes per levels, a list of active connections and their type.
- Periodic statistical information. Integrated values for a period defined by three superframes duration (approx. 1 minute). Periodic information for 60 periods and the global accumulated value for:
 - Number of topology changes: Promotion, demotions, registrations and deregistrations.
 - Coverage: ALIVE messages successful, Total ALIVE messages.
 - Availability.
- Instantaneous "image" of the subnetwork topology. Table including all Service Nodes connected to the network and some relevant parameters.
- PLC channel occupation. Integrated values for a period defined by three superframes (approx. 1 minute). Periodic information for 60 periods and the global accumulated value for:
 - PHY level: CFP, SCP and ERROR packets.
 - MAC level: Beacons, Control and Data packets.

Several commands stemming from the SNMP protocol can make the Gateway start a TCP session in order to transfer specific information. When enabled, the PRIME Gateway sends selected information to a SNMP-configured TCP server. The following session types can be handled through SNMP commands:

- Topology events in real time.
- PRIME PHY layer sniffer. It sends information about the PLC messages exchanged between Nodes, as well as the PLC PHY PDU.

[Sniffer format for SNMP managed TCP sessions](#) on page 63 describes what the data format is for this kind of transfers.

Chapter 2 Configuration

2.1 Getting the PRIME Interface

The PRIME Interface is the configuration menu where all configuration options for the PRIME Gateway can be set.

To access the PRIME interface configuration menu, first access the general configuration menu. From there, access the PRIME interface.

```
Config>list devices

Interface      Connector      Type of interface
ethernet0/0    EXP/SWITCH     SOFTETH Switch Ethernet
prime0/0       PLC-PW         PRIME interface
cellular1/0    SLOT1          AT SOFTUSB COM
cellular1/1    SLOT1          SOFTNIC Interface
direct-ip1     ---           Generic DirectIP encapsulation
Config>
```

In this example, the PRIME interface appears as prime0/0.

PRIME configuration commands must be entered in the configuration menu associated with the PRIME interface (*PRIME-primeX/Y Config>*). To access this menu, enter the **NETWORK primeX/Y** command from the general configuration menu (*Config>*).

```
Config>network prime0/0

-- PRIME Interface Configuration --
PRIME-prime0/0 Config>
```



Note

The PRIME interface is only available in some devices and a license could be necessary to enable it. Please contact our Technical Service for more information on the devices that support this feature.

2.2 Configuration Commands for the PRIME Gateway

PRIME configuration commands must be entered in the configuration menu associated with the PRIME interface (*PRIME-primeX/Y Config>*). To access this menu, enter the **NETWORK primeX/Y** command from the general configuration menu (*Config>*).

```
Config>network prime0/0

-- PRIME Interface Configuration --
PRIME-prime0/0 Config>
```

Once you have accessed the PRIME configuration menu, you can use the commands below:

```
PRIME-prime0/0 Config>?
bandwidth          Intended bandwidth, in kilobits per second (kbps)
bn-channel         BN Frequency channel operation
description        Enter interface description
fup-port           Configure TCP local port for Firmware Upgrade
                  Prot.(FUP)
iflinkup-down-traps Enable ifLinkUp and ifLinkDown traps
input-low          Set low water mark for input buffers
list              List configuration
local-ip           Configure local IP address
local-port         Configure TCP local port(remote)
no                Negate a command or set its defaults
node-mode          Configure the type of operational PRIME node (BASE or
                  SERVICE)
output-fair        Set fair share value for output buffers
phy-layer-extension Configure parameters for PHY layer extension over UDP
plc-signal         Enable/disable PLC signal
```

```

prime-release      Configure the PRIME standard release
shutdown          Change state to administratively down
sniffer           Configure Sniffer parameters
topology          Configure parameters to manage topology files
trace-level       Configure debugging trace level bit mask
update            Update a level indicator
vrf               Configure link to VRF
exit
PRIME-prime0/0 Config>

```

Command	Function
<i>BANDWIDTH</i>	This is a global command. For more information, please refer to "Dm 772-I Common Configuration Interfaces".
<i>BN-CHANNEL</i>	Specifies the frequency channel used by BN to establish the PLC PRIME network.
<i>DESCRIPTION</i>	This is a global command. For more information, please refer to "Dm 772-I Common Configuration Interfaces".
<i>FUP-PORT</i>	Specifies the local TCP port to establish "listen", used for the incoming connections from Firmware Upgrade application to perform FUP (Firmware Upgrade Protocol) over Service Nodes.
<i>INPUT-LOW</i>	This is a global command. For more information, please refer to "Dm 772-I Common Configuration Interfaces".
<i>LIST</i>	Shows a list of main configuration parameters.
<i>LOCAL-IP</i>	Specifies the local IP address for all TCP/UDP data connections related to the PRIME Gateway.
<i>LOCAL-PORT</i>	Specifies the local TCP port to establish "listen", used for the incoming connections from Data Concentrator.
<i>NO</i>	Clears a configuration parameter or sets its default value.
<i>NODE-MODE</i>	Specifies the type of operational PRIME node in the device. The device can operate as a BASE or SERVICE Node.
<i>OUTPUT-FAIR</i>	This is a global command. For more information, please refer to "Dm 772-I Common Configuration Interfaces".
<i>PHY-LAYER-EXTENSION</i>	Sets the configuration parameters related to the "PHY layer extension over UDP" feature, known as Ticket#65. This feature helps deploy the PRIME network through an IP connection.
<i>PLC-SIGNAL</i>	Allows the PLC signal to transmit, from an internal PRIME Base Node, over the power line. This command also enables/disables the Base Node functionality.
<i>PRIME-RELEASE</i>	Specifies the PRIME technology used by BN to establish the PLC PRIME network. PRIME 1.3 or PRIME 1.4 can be selected.
<i>SHUTDOWN</i>	This is a global command. For more information, please refer to "Dm 772-I Common Configuration Interfaces".
<i>SNIFFER</i>	Sets the configuration parameters related to the Sniffer feature. This feature allows for the monitoring of PLC data activity at the physical layer level.
<i>TOPOLOGY</i>	Sets the configuration parameters to monitor topological changes. This feature allows files that include topological changes to be created in the PLC network.
<i>TRACE-LEVEL</i>	Allows several types of traces related to PRIME interface processes to be enabled.
<i>UPDATE</i>	This is a global command. For more information, please refer to "Dm 772-I Common Configuration Interfaces".
<i>VRF</i>	Establishes a link to a configured VRF.
<i>EXIT</i>	Exits the PRIME configuration menu.

2.2.1 BN-CHANNEL

This parameter configures the frequency channel used by the BN to build the PRIME network. All SNs connected to the network must be able to detect or configure the frequency selected. This functionally only affects PRIME 1.4 operation. The frequency used for each channel is defined under PRIME 1.4 specifications.

It accepts values ranging from 1 to 8. The default value is 1.

Syntax:

```
PRIME-primeX/Y Config>bn-channel ?
```

```
<1..8> Channel number
```

Example:

```
PRIME-prime0/0 Config>bn-channel 5
PRIME-prime0/0 Config>
```



Note

- This command is not necessary when in Service Node mode.
- This command is not necessary when the PRIME 1.3 release is configured. In such cases, the command is ignored and channel 1 is used.
- BN channel selection is not available in all PRIME devices. Some devices only support channel 1. Please contact our Technical Service for more information on the devices that support this feature.

Command history:

Release	Modification
11.01.08	The "bn-channel" command was introduced as of version 11.01.08.

2.2.2 FUP-PORT

This parameter configures the local listening TCP port for incoming TCP sessions from a Firmware Upgrade Protocol (FUP) remote application. This port provides the input path needed to access the FUP on the PRIME Gateway. FUP performs firmware updates on Service Nodes connected to the PRIME network that can be accessed by the Gateway. FUP is designed to carry out easier and faster firmware updates of Service Nodes.

It accepts values ranging from 1 to 65535. Default is 502.

Syntax:

```
PRIME-primeX/Y Config>fup-port ?
<0..65535> Enter local TCP port value for FUP
```

Example:

```
PRIME-prime0/0 Config>fup-port 3452
PRIME-prime0/0 Config>
```



Note

- There is no need for this command when Service Node mode is configured.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.3 LIST

Lists the current values of the main configuration parameters.

Syntax:

```
PRIME-primeX/Y Config>list
```

Example:

```
PRIME-prime0/0 Config>list
PRIME node type      : BASE-NODE
PRIME standard release : 1.3
PLC signal          : Enabled
Frequency channel    : 1
Local IP address     : 0.0.0.0
Local TCP port       : 502
VRF tag              : <main>
```



```

FUP TCP local port      : 21400

Topology Parameters:
File management        : Enabled
FTP server ip address  : 192.168.212.33
FTP server port        : 21
File send time         : 60 seconds
File max lines         : 100
File FTP remote path   : prime
File name prefix       : topology
FTP connection user    : admin
FTP connection password : hdsudx

PHY layer extension over UDP parameters:
PHY layer extension    : Enabled
UDP local port         : 4567
Remote slaves SN info:
SN ID name             : REMOTE
UDP port               : 40038
IP address              : 192.168.213.165

Sniffer Parameters:
Sniffer control        : Enabled
Local port             : 24300
Max. connection time   : 0

Debug trace level: 0x1080

PRIME-prime0/0 Config>

```

This command shows values for the following parameters:

- MODE-NODE
- PRIME-RELEASE
- PLC-SIGNAL
- BN-CHANNEL
- LOCAL-IP
- LOCAL-PORT
- VRF
- FUP-PORT
- TOPOLOGY MONITORING PARAMETERS
- PHY-LAYER-EXTENSION PARAMETERS
- SNIFFER PARAMETERS
- TRACE-LEVEL

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.
11.01.08	The "update" option has been added as of version 11.01.08.

2.2.4 LOCAL-IP

This parameter helps configure the local IP address. For incoming TCP sessions, the destination IP sent by the originator of the TCP session is compared to the local IP address. The session is rejected if the addresses don't match. For outgoing TCP sessions, this value is sent as a local IP address when establishing the TCP session.

This applies to all TCP connections linked to the PRIME Gateway. That is, the DLMS/COSEM Data Concentrator and Sniffer.

A value of 0.0.0.0 indicates that this parameter is not used. The router automatically assigns the IP address used for outgoing sessions.

The default value is: 0.0.0.0.

Syntax:

```
PRIME-primeX/Y Config>local-ip ?
<a.b.c.d>      Ipv4 format
```

Examples:

```
PRIME-prime0/0 Config>local-ip 192.168.1.123
PRIME-prime0/0 Config>
```



Note

- The local IP Address must be one of the addresses configured on the router for any addressable interface (i.e., Ethernet, PPP, loopback, etc.).

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.5 LOCAL-PORT

This parameter configures the local listening TCP port for incoming TCP sessions from the DLMS-COSEM Data Concentrator (DC). The DC must establish TCP sessions with the port configured for this parameter. The latter accepts values ranging from 1 to 65535. Default is 502.

Syntax:

```
PRIME-prime0/0 Config>local-port ?
<0..65535>      Enter local TCP port value
```



Note

- When configuring the local TCP port, make sure you do not configure the same TCP port in two different functionalities.

Examples:

```
PRIME-prime0/0 Config>local-port 502
PRIME-prime0/0 Config>
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.6 NO

This command clears a configuration parameter or sets its default value.

Syntax:

```
GPS-Apps Config>no <command>
```

Example:

```
PRIME-prime0/0 Config>no ?
bandwidth          Intended bandwidth, in kilobits per second (kbps)
description        Enter interface description
iflinkup-down-traps Enable ifLinkUp and ifLinkDown traps
input-low          Set low water mark for input buffers
```

```

output-fair      Set fair share value for output buffers
shutdown        Change state to administratively down
update          Update a level indicator
vrf             Configure link to VRF
PRIME-prime0/0 Config> no vrf

```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.
11.01.08	The "update" option has been added as of version 11.01.08.

2.2.7 NODE-MODE

This command helps set the role for the PRIME Gateway on the PRIME network. The two possible roles are Base Node and Service Node.

The most commonly used mode for the PRIME Gateway on a PRIME network is Base Node mode. It provides access to all Service Nodes connected to the network.

Service Node mode is intended to be used as a PLC PRIME switch on the PHY layer extension feature (Ticket#65). This mode provides access to all Service Nodes connected to a power line, but links the PRIME PHY layer to a Base Node through an IP/UDP connection.

The default mode is Base Node.

Syntax:

```

PRIME-primeX/Y Config>node-mode ?
base-node      Set PRIME EN mode
service-node   Set PRIME SN mode

```

Example:

Enable the PRIME Gateway to send PLC signal.

```
PRIME-prime0/0 Config>node-mode base-node
```



Note

- Enabling some configuration and monitoring commands is not necessary under Service Node mode.
- Operation under Service Node mode is not available in all PRIME devices. Please contact our Technical Service for more information on the devices that support this feature.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.
11.01.08	Note added for Service Node mode operation.

2.2.8 PHY-LAYER-EXTENSION

The PRIME Gateway includes a feature that makes it possible to deploy the PRIME network through a power line that is not directly connected to the Base Node. This feature is known as PRIME PHY layer extension or Ticket#65.

To do this, you must add a Service Node to the network that supports the PHY layer extension feature.

Communication between the Base Node and the Service Node for the expansion of the PRIME PHY layer is performed through UDP/IP datagrams.

The PRIME Gateway can operate as Base Node or Service Node. Both operation modes support the PRIME PHY layer extension feature.

Immediately after registering on the Base Node, the PRIME Gateway in Service Node mode becomes a SWITCH. The Service Node acts as a repeater for PHY PLC messages sent from the Base Node over the power line where it is connected.

PHY-LAYER-EXTENSION commands help configure the parameters to establish PRIME PHY connectivity between a Base Node and several Service Nodes via an IP connection.

Syntax:

```
PRIME-primeX/Y Config>phy-layer-extension ?
  control          Enable/disable PHY layer extension feature
  local-udp-port   Configure local UDP port
  no               Negate a command or set its defaults
  remote-sn       Name for remote SN included in PHY layer extension
```

Data messages for PHY layer extension are exchanged through UDP/IP datagrams.



Note

- For PHY-LAYER-EXTENSION to operate properly, the communication delays between the BN and the SNs must have low latency (< 1 msec.). We recommend using an Ethernet LAN connection.
- PHY-LAYER-EXTENSION operation is not available in all PRIME devices. Please contact our Technical Service for more information on the devices that support this feature.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.
11.01.08	Notes added.

2.2.8.1 CONTROL

This parameter enables/disables the PRIME PHY layer extension feature. When the disable option is configured, any attempt to establish a TCP session is rejected.

It is disabled by default.

Syntax:

```
PRIME-primeX/Y Config>phy-layer-extension control ?
  enable          Enable PHY layer extension feature
  disable         Disable PHY layer extension feature
```

Example:

This example shows how to configure the control option:

```
PRIME-prime0/0 Config>phy-layer-extension control enable
PRIME-prime0/0 Config>
```



Note

- For the "PHY layer extension" to work, *control* must be enabled on the Base Node and the Service Nodes.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.8.2 LOCAL-UDP-PORT

This parameter helps configure the local UDP port to receive any incoming UDP datagrams that contain the PHY layer information. This UDP port is the one the PHY layer extension feature has as UDP listen.

The local UDP port must be configured in the Base Node and Service Nodes that are part of a PHY layer extension.

Syntax:

```
PRIME-primeX/Y Config>phy-layer-extension local-udp-port ?
<0..65535>       Configure local UDP port
```

Example:

This example shows how to configure the local UDP port:

```
PRIME-prime0/0 Config>phy-layer-extension local-udp-port 5678
PRIME-prime0/0 Config>
```

**Note**

- When configuring the local UDP port, make sure you do not configure the same port in two different functionalities.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.8.3 NO

This command clears a configuration parameter or sets its default value.

Syntax:

```
PRIME-primeX/Y Config>phy-layer-extension no ?
remote-sn      Name for remote SN entry
```

Example:

This example shows how to remove a remote SN:

```
PRIME-prime0/0 Config>phy-layer-extension no remote-sn REMOTE
PRIME-prime0/0 Config>
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.8.4 REMOTE-SN

This command helps create and modify the necessary parameters to send UDP datagrams to the associated nodes. Since it may be necessary to access multiple nodes, this command creates records to configure parameters that grant access to each remote node.

In Base Node mode, when the PHY layer extension feature is enabled, the PRIME Gateway can access several Service Nodes via UDP. The commands listed in this section configure the parameters that are necessary to send data to those Service Nodes via UDP/IP. The Base Node sends all datagrams to the registered Service Nodes.

In Service Node mode, only the associated Base Node may be accessed. The commands listed in this paragraph section configure the parameters needed to send data to the Base Node via UDP/IP. The Service Node sends all datagrams to its associated Base Node only. Its access parameters must be included in the only configurable record for this mode.

To configure the parameters for several Service Nodes, a record must be created for each one. Records are created automatically when the first command is added.

To erase a record for a node, please use the "NO" command.

Syntax:

```
PRIME-primeX/Y Config>phy-layer-extension remote-sn ?
<1..20 chars>      Name for remote SN entry
PRIME-primeX/Y Config>phy-layer-extension remote-sn <rec-name> ?
remote-udp-port    Configure remote UDP port
remote-ip-addr     Configure remote IP address
```

Example:

```
PRIME-prime0/0 Config>phy-layer-extension remote-sn RECORD remote-udp-port 4354
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.8.4.1 REMOTE-UDP-PORT

This parameter configures the remote UDP port in the record. The node will then send the outgoing UDP datagrams that include the PHY layer information to the node's remote UDP port.

Syntax:

```
PRIME-primeX/Y Config>phy-layer-extension remote-sn <rec-name> remote-udp-port ?
<0..65535>    Configure remote UDP port
```

Example:

This example shows how to configure the remote UDP port:

```
PRIME-prime0/0 Config>phy-layer-extension remote-sn REMOTE remote-udp-port 43434
PRIME-prime0/0 Config>
```

**Note**

- When configuring the local UDP port, make sure you do not configure the same port in two different functionalities.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.8.4.2 REMOTE-IP-ADDR

This parameter configures the remote IP address that appears in the record. The node will then send the outgoing UDP datagrams that include the PHY layer information to the node's configured IP address.

Syntax:

```
PRIME-primeX/Y Config>phy-layer-extension remote-sn <rec-name> remote-ip-addr ?
<a.b.c.d>    Ipv4 format
```

Example:

This example shows how to configure the remote IP address:

```
PRIME-prime0/0 Config>phy-layer-extension remote-sn REMOTE remote-ip-addr 192.168.21.56
PRIME-prime0/0 Config>
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.9 PLC-SIGNAL

This command enables/disables the sending of PLC signals from the PRIME Gateway. When this option is "disabled", the PRIME Gateway functionality is completely deactivated. For the PRIME Gateway to work, it is essential that this command is entered in the configuration. The PLC signal is disabled by default.

Syntax:

```
PRIME-primeX/Y Config>plc-signal ?
enable    Enable PLC signal
disable   Disable PLC signal
```

Example:

Enable the PRIME Gateway to send PLC signal.

```
PRIME-prime0/0 Config>plc-signal enable
```



Note

- While the PLC signal is disabled, the PRIME Gateway functionality will remain in an inoperative state.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.10 PRIME-RELEASE

This command configures the PRIME release of standard PRIME that is operative in the PLC network. PRIME 1.3 and PRIME 1.4 are configurable. The PRIME GW operates in the configured release automatically, load a FW it is not necessary. PRIME 1.3 and PRIME 1.4 don't allow inter interoperability. The PRIME GW creates a PLC network according to PRIME release, this means all Services Nodes connected to the network must be able to operate under the configured release. The default value for PRIME-RELEASE is 1.3.

Syntax:

```
PRIME-primeX/Y Config>prime-release ?
  1.3  Set PRIME 1.3 standard operation
  1.4  Set PRIME 1.4 standard operation
```

Example:

This example shows how to configure PRIME 1.4 release.

```
PRIME-prime0/0 Config>prime-release 1.4
```



Note

- The PRIME-RELEASE command is not available in all PRIME devices. Please contact our Technical Service for more information on the devices that support this feature.
- Devices that don't support the PRIME-RELEASE command can operate under PRIME 1.3 or PRIME 1.4, depending on the firmware installed. These devices, however, cannot automatically change the PRIME release.

Command history:

Release	Modification
11.01.08	The "prime-release" command was introduced as of version 11.01.08.

2.2.11 SNIFFER

The PRIME Gateway can act as a sniffer of PLC PRIME traffic. The information collected by the PRIME Gateway can be sent through a TCP session to a Sniffer application.

SNIFFER commands help configure the parameter that grants remote access to the Sniffer data. These commands provide the configuration options to allow access by a proprietary application. For more info about proprietary applications, please contact your dealer.



Note

SNMP-specific commands, which are independent of the *Sniffer* command, can also provide access to Sniffer data.

Syntax:

```
PRIME-prime0/0 Config>sniffer ?
local-tcp-port  Configure local TCP port
```

connection-time	Configure TCP session max. connection time
control	Enable/disable Sniffer access

The Sniffer application accesses data through incoming TCP sessions.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.11.1 LOCAL-TCP-PORT

This parameter helps configure the local TCP port for incoming Sniffer TCP sessions. This TCP port is the one the Sniffer feature has as TCP listen.

Syntax:

```
PRIME-primeX/Y Config>sniffer local-tcp-port ?
<0..65535>    Configure local TCP port
```

Example:

This example shows how to configure the local TCP port:

```
PRIME-prime0/0 Config>sniffer local-tcp-port 3245
PRIME-prime0/0 Config>
```



Note

- When configuring the local TCP port, make sure you do not configure the same TCP port in two different functionalities.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.11.2 CONNECTION-TIME

This parameter configures the maximum time a Sniffer TCP session will be active. When the configured time expires, the Sniffer TCP session will end.

The value configured is in minutes and can range from 0 to 65535. Value 0 disables the connection time functionality. The default value is 0.

Syntax:

```
PRIME-primeX/Y Config>sniffer connection-time ?
<0..65535>    Connection time value in minutes
```

Example:

This example shows how to configure the connection time:

```
PRIME-prime0/0 Config>sniffer connection-time 30
PRIME-prime0/0 Config>
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.11.3 CONTROL

This parameter enables/disables the Sniffer TCP access feature. When the disable option is configured, any attempt to establish a TCP session is rejected.

It is disabled by default.

Syntax:

```
PRIME-prime0/0 Config>sniffer control ?
enable      Enable sniffer access
disable     Disable sniffer access
```

Example:

This example shows how to configure the control option:

```
PRIME-prime0/0 Config>sniffer control enable
PRIME-prime0/0 Config>
```

**Note**

- *Control* must be enabled for the Sniffer feature to work.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.12 TOPOLOGY

The PRIME Gateway can collect, in real time, topological data of the PRIME network associated with the Base Node. This information contains all state change events in the Service Nodes of PLC networks and is stored in files that can be sent to a server via FTP.

The main purpose of the TOPOLOGY feature is to keep the information about the state of all network Service Nodes updated in a management server. Changes in data are updated periodically, based on the time configured. If, between two periods of file saving, the number of stored events reaches the number configured on "file-max-lines parameter", the file will be updated too.

The file name will have the following format:

```
prefix_yyyymmdd_hhmmss.csv
```

The meaning of each field is the following:

- prefix: configured file prefix. All files include the same prefix.
- yyyy: year when file sending starts.
- mm: month when file sending starts.
- dd: day when file sending starts.
- hh: hour when file sending starts.
- mm: minute when file sending starts.
- ss: second when file sending starts.

The Gateway will send as many files as needed until the functionality is disabled.

If file sending fails, the Gateway will try again after 10 minutes. It will try 5 times before discarding the file.

When this functionality is enabled, the Gateway generates a special file every 24 hours which contains the Service Nodes currently registered on the Base Node.

While the functionality is enabled, files will not be sent if there are no changes in the PLC network topology .

Topological data can be shown through a monitoring CLI tool. See the monitoring section for more information.

The TOPOLOGY commands configure the parameters to enable, collect and send topological data.

Syntax:

```
PRIME-prime0/0 Config>topology ?
enable      Enable topology files generation and FTP send
disable     Disable topology files generation and FTP send
ftp-server-ip  Configure the IP address for the topology FTP server
ftp-server-port  Configure the TCP port for the topology FTP server
```

file-max-lines	Configure the max number of topology changes (lines) included in file
file-time	Configure the time between sending two consecutive files
file-path	Configure remote FTP server path to put topology file
file-prefix	Configure prefix for the topology files name
ftp-cnx-user	Configure username for FTP connection
ftp-cnx-password	Configure password for FTP connection
no	Negate a command or set its defaults

The format of the topological data file is defined in ANNEX B.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.12.1 ENABLE

This parameter enables the topology functionality. This means that, if there are Service Nodes registered on the PLC network, the sending of files starts and CLI topology monitoring is updated.

When this functionality is enabled, the Gateway generates a special file every 24 hours which contains the Service Nodes currently registered on the Base Node.

It is disabled by default.

Syntax:

```
PRIME-prime0/0 Config>topology enable ?
<cr>
```

Example:

This example shows how to enable the "Topology" functionality:

```
PRIME-prime0/0 Config>topology enable
PRIME-prime0/0 Config>
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.12.2 DISABLE

This parameter disables the topology functionality. This means that the sending of files ends and CLI topology monitoring is not updated.

When the functionality is disabled, a topology file that includes stored changes is sent to the FTP server.

It is disabled by default.

Syntax:

```
PRIME-prime0/0 Config>topology disable ?
<cr>
```

Example:

This example shows how to disable the "Topology" functionality:

```
PRIME-prime0/0 Config>topology disable
PRIME-prime0/0 Config>
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.12.3 FTP-SERVER-IP

This parameter configures the IP address of the topology server. For the FTP topology functionality to work properly, this parameter must be configured.

Syntax:

```
PRIME-prime0/0 Config>topology ftp-server-ip ?
<a.b.c.d>    Configure the IP address for the topology FTP server
```

Examples:

```
PRIME-prime0/0 Config>topology ftp-server-ip 192.168.1.24
PRIME-prime0/0 Config>
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.12.4 FTP-SERVER-PORT

This parameter configures the TCP port in the topology server. For the FTP topology functionality to work properly, this parameter must be configured.

Syntax:

```
PRIME-prime0/0 Config>topology ftp-server-port ?
<0..65535>    Configure the TCP port for the topology FTP server
```

Examples:

```
PRIME-prime0/0 Config>topology ftp-server-port 1234
PRIME-prime0/0 Config>
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.12.5 FILE-MAX-LINES

This parameter configures the maximum number of topology changes to include in an FTP file (lines). This means that, when the number of topology changes stored in the Gateway reaches the configured number, a topology file is generated and the process to send it via FTP is triggered.

This parameter can take values ranging from 1 to 4000. The default value is 1000.

Syntax:

```
PRIME-prime0/0 Config>topology file-max-lines ?
<1..4000>    Lines number
```

Example:

This example shows how to configure the maximum lines parameter:

```
PRIME-prime0/0 Config>topology file-max-lines 500
PRIME-prime0/0 Config>
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.12.6 FILE-TIME

This parameter configures the time to save the topology file. The value configured is the time between two consecutive file-saving actions. When a file is saved, the previous file is removed and the information must be updated in the server.

Time is configured in seconds. This parameter can take values ranging from 10 to 65535. The default value is 1800.

Syntax:

```
PRIME-prime0/0 Config>topology file-time ?
<10..65535>    Time in seconds
```

Example:

This example shows how to configure the file time parameter:

```
PRIME-prime0/0 Config>topology file-time 1800
PRIME-prime0/0 Config>
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.12.7 FILE-PATH

This parameter is linked to the path where topology files will be saved on the remote FTP server. The path to the destination directory on the server may be defined using this command.

The path name must be a text string ranging from 1 to 12 characters.

Syntax:

```
PRIME-prime0/0 Config>topology file-path ?
<1..12 chars>    Path name
```

Example:

This example shows how to configure the file path parameter:

```
PRIME-prime0/0 Config>topology file-path topology
PRIME-prime0/0 Config>
```

In this example, the destination file path will be:

/topology/prime_20160612_142254.csv

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.12.8 FILE-PREFIX

This parameter has to do with the name of the files to be sent to the remote FTP server.

The first characters for the topology files name may be defined using this command. All topology files generated automatically by the Gateway will have, in the first characters of their name, the characters configured in this command.

The prefix name must be a text string ranging from 1 to 20 characters.

Syntax:

```
PRIME-prime0/0 Config>topology file-prefix ?
<1..20 chars>    Prefix for file name
```

Example:

This example shows how to configure the file prefix parameter:

```
PRIME-prime0/0 Config>topology file-prefix prime
PRIME-prime0/0 Config>
```

In this example, the destination path for the file will be:

```
/topology/prime_20160612_142254.csv
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.12.9 FTP-CNX-USER

This command configures the authentication parameters needed in order to access the remote FTP server (which is where the topology files have to be saved).

This command configures the user name that grants access to the FTP server.

The path name must be a text string ranging from 1 to 12 characters.

Syntax:

```
PRIME-prime0/0 Config>topology ftp-cnx-user ?
<1..12 chars> Username
```

Example:

This example shows how to configure the FTP user parameter:

```
PRIME-prime0/0 Config>topology ftp-cnx-user admin
PRIME-prime0/0 Config>
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.12.10 FTP-CNX-PASSWORD

This command configures the authentication parameters to access the remote FTP server (which is where the topology files have to be saved).

This command configures the password that grants access to the FTP server.

The path name must be a text string ranging from 1 to 12 characters.

Syntax:

```
PRIME-prime0/0 Config>topology ftp-cnx-password ?
<1..12 chars> Password
```

Example:

This example shows how to configure the FTP user parameter:

```
PRIME-prime0/0 Config>topology ftp-cnx-password hsdudx
PRIME-prime0/0 Config>
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

2.2.12.11 NO

This command clears a configuration parameter or sets its default value.

Syntax:

```
PRIME-primeX/Y Config>topology no ?
ftp-server-ip      Configure the IP address for the topology FTP server
ftp-server-port    Configure the TCP port for the topology FTP server
file-max-lines     Configure the max number of topology changes(lines)
                  included in file
file-time          Configure the time between sending two consecutives
                  files
file-path          Configure remote FTP server path to put topology file
file-prefix        Configure prefix for the topology files name
ftp-cnx-user       Configure username for FTP connection
ftp-cnx-password   Configure password for FTP connection
```

Example:

This example shows how to delete the FTP connection password:

```
PRIME-prime0/0 Config>topology no ftp-cnx-password
PRIME-prime0/0 Config>
```

Command history:

Release	Modification
11.01.08	The "no" command was introduced as of version 11.01.08.

2.2.13 TRACE-LEVEL

This command enables/disables the debugging of traces in the PRIME Gateway and selects their level.

The following types of traces can be enabled:

- MNG_FSM: Enables traces for the management of the state machine for PRIME (0x0001)
- TK67: Enables DLMS overt TCP(Ticket#67) traces (0x0002)
- TPOLOGY: Enables topology management traces (0x0004)
- TPL_FILE: Enables traces related to the topology files management process (0x0008)
- FTP_PUT: Enables FTP topology transfer files traces (0x0010)
- SN_VER: Enables traces to monitor the process of obtaining firmware versions for Service Nodes (0x0020)
- FUP: Enables traces to monitor the Firmware Upgrade Protocol (0x0040)
- TK65: Enables traces to monitor the PHY layer extension (Ticket#65) process (0x0080)
- USI: Enables traces to monitor PLC modem communication (0x0100)
- USI_DAT: Enables traces to analyze all PLC modem data (0x0200)
- API_DAT: Enables traces to analyze PRIME API data of the PLC modem (0x0400)
- SNIF_DAT: Enables traces to analyze SNIFFER data (0x0800)
- TK65_DAT: Enables traces to analyze the PHY layer extension (Ticket#65) data (0x1000)
- SNIFFER: Enables SNIFFER management traces (0x2000)
- PLC modem debug report traces (0x4000)

Different types of traces can be activated simultaneously by means of an OR operation that uses the desired trace values. These values are in HEX format. To disable all traces, use the 0x0000 value.

Syntax:

```
PRIME-prime0/0 Config>trace-level ?
<hex 0..ffff> Trace level bit mask: MNG_FSM(0x0001) TK67(0x0002)
TPOLOGY(0x0004) TPL_FILE(0x0008) FTP_PUT(0x0010)
SN_VER(0x0020) FUP(0x0040) TK65(0x0080) USI(0x0100)
USI_DAT(0x0200) API_DAT(0x0400) SNIF_DAT(0x0800)
TK65_DAT(0x1000) SNIFFER(0x2000) PLC_DBG(0x4000)
```

Example:

```
PRIME-prime0/0 Config>trace-level 0802
PRIME-prime0/0 Config>
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.
11.00.07, 11.01.03	New option added. (PLC_DBG(0x4000))

2.2.14 VRF

This command allows you to select the VRF to which the PLC PRIME interface that is being configured belongs.

Syntax:

```
PRIME-prime0/0 Config>vrf
<1..32 chars>      VPN Routing/Forwarding instance name
```

Example:

```
PRIME-prime0/0 Config>vrf NODEQ
PRIME-prime0/0 Config>
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

Chapter 3 Monitoring

3.1 Accessing the interface monitoring

To access the PRIME interface monitoring menu, you first need to access the general monitoring menu. From there, please access the PRIME interface.

The “configuration” command lets you obtain a list of available interfaces, among other things.

```
+configuration

Teldat's Router, Regesta-Smart-PLC S/N: 914P/00101
SWL:BASE PLC_2000SN UART USB_INTERNAL
Profile: none
ID: Regesta-Smart-PLC

Boot ROM release:
  BIOS CODE VERSION: 01.07 Nov 25 2019 13:26:09 L0

System Info:
PCB:0x411 Regesta-Smart-PLC SYS:0x000B REV:0x2
CLKs: CPU=500 FBS1=250 FBS2=250 DDR(clk)=250 LBUS=250
Watchdog:Enabled
Cache:ON Write-Back
Time Base: frequency = 250000 KHz period = 4.000 ns
CPU temperature: 43 C
BOARD temperature: 31 C

Software release: 11.01.08 Nov 22 2019 08:56:37
Compiled by integrator on ares.id.teldat.com
Loaded from primary partition

Hostname: Active user:
Date: Saturday, 01/01/00 Time: 02:13:57
Router uptime: 2h13m27s

Name Protocol
IP Internet Protocol
IP6 IPv6
ARP Address Resolution Protocol
CFM Connectivity Fault Management
ASRT Adaptive Source Routing Transparent Enhanced Bridge
DLS Data Link Switching
dot1X Extensible Authentication Protocol Over LAN
RIP Route Information Protocol
OSPF Open SPF-Based Routing Protocol
BGP BGP
BFD Bidirectional Forwarding Detection
NHRP Next Hop Resolution Protocol
DHCP Dynamic Host Configuration Protocol
L2TP L2TP
SNMP SNMP
IGMP Internet Group Management Protocol
PIM Protocol Independent Multicast
MSDP Multicast Source Discovery Protocol
GW104 Gateway IEC 104/101
SIP SIP
H323 H323
NOE UA/NOE
SCCP SCCP
RPNG RIPng
OSPFv3 OSPFv3
DHCPv6 DHCPv6

9 interfaces:
```



```

Connector      Interface      MAC/Data-Link      Status
SFP-WAN        ethernet0/0     Ethernet/IEEE 802.3 Up
LAN            ethernet0/1     Ethernet/IEEE 802.3 Testing
PLC-PW         prime0/0        PRIME interface     Up
SERIAL1        uart1/0         AHDLc               Testing
SERIAL2        uart1/1         AHDLc               Testing
ANT1           cellular1/0     Async serial line    Down
ANT1           cellular1/1     NIC interface        Down
ANT1           cellular1/2     NIC interface        Down
---           direct-ip1      DirectIP interface   Down

```

SNMP OperStatus:

```

Interface      OperStatus
ethernet0/0     Up
ethernet0/1     Down
prime0/0        Up
uart1/0         Down
uart1/1         Down
cellular1/0     Down
cellular1/1     Down
cellular1/2     Down
direct-ip1      Lower layer down

```

Hardware Encryption Engine: LTQ-DEU xRX200 Family, Revision 5

Cellular Driver Version:

WLAN Driver Version: 9.5.0.35.1

+

The PRIME interface appears as prime0/0 in this example, therefore:

```
+network prime0/0
```

```
-- PRIME Console --
```

```
PRIME-prime0/0+
```

3.2 Interface monitoring

This section describes the monitoring commands for the PRIME interface.

The monitoring commands are as follows:

```

PRIME-prime0/0+?
  clear          Initialize statistics
  fup            Statistics for FW Upgrade Prot.(FUP) monitoring
                connection
  list          Display monitoring information
  reset         PRIME module hardware reset control
  upgrade-firmware PRIME module firmware upgrade
  exit
PRIME-prime0/0+

```

Once you have accessed the PRIME monitoring menu, you can enter the commands below:

Command	Function
<i>CLEAR</i>	Sets the statistics counter to its reset state.
<i>FUP</i>	Shows Firmware Upgrade Protocol (FUP) process evolution.
<i>LIST</i>	Displays the PLC PRIME monitoring information.
<i>RESET</i>	Performs a PLC PRIME module reset.
<i>UPGRADE-FIRMWARE</i>	Upgrades the firmware of the PLC PRIME module.
<i>EXIT</i>	Returns to the previous menu.

3.2.1 CLEAR STATISTICS

Deletes the interface statistics that correspond to the packets and bytes exchanged by the PRIME interface.

Syntax:

```
PRIME-prime0/0+clear statistics ?
<cr>
```

Example:

```
PRIME-prime0/0+clear statistics
PRIME-prime0/0+
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

3.2.2 FUP

The Firmware Upgrade Protocol (FUP) is designed to upgrade the Service Nodes that are connected to the Base Node in the PRIME local network. FUP is defined to launch and control the firmware upgrade by a remote application, through a TCP session.

In environments where FUP is not available, this command helps launch and cancel a limited FUP process.

Syntax:

```
PRIME-prime0/0+fup ?
cancel    Cancel FUP process in progress
set       Set FUP parameters
start     Starts FUP process for added SNs
```



Note

- This command is not necessary when the PRIME Gateway is configured in Service Node mode.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.
11.01.08	The "set" command option was added as of version 11.01.08.

3.2.2.1 CANCEL

The CANCEL command ends the running FUP session. This command cancels a session initiated by an FUP remote application or by the FUP START local console command.

Syntax:

```
PRIME-prime0/0+fup cancel ?
<cr>
```

Example:

```
PRIME-prime0/0+fup cancel
PRIME-prime0/0+
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

3.2.2.2 SET

The SET command allows you to configure several parameters that are necessary for the FUP session. These parameters must be set before a session is initiated. The command option only works when the FUP START local console command is responsible for launching the FUP session.

Syntax:

```
PRIME-prime0/0+fup set ?
  signature-length      Signature length for signed FW (For PRIME 1.4 only)
  signature-algorithm   Algorithm type for signed FW (For PRIME 1.4 only)
```

Command history:

Release	Modification
11.01.08	The "set" command was introduced as of version 11.01.08.

3.2.2.2.1 SIGNATURE-LENGTH

The SIGNATURE-LENGTH command allows you to configure the length of the signature for a specific FW. PRIME version 1.4 defines an encrypted signature to allow the FW to be used for Service Nodes. This signature may use several types of encryption and may be of variable length.

This parameter must be configured before the FW is sent to the Service Nodes. That is, the command must be set before a FUP session is initiated. It is only valid when the FUP START local console command launches the FUP session.

This parameter must only be configured for Service Nodes that use PRIME version 1.4 and when the algorithm used is not NONE.

The FW algorithm and its length are defined by the Service Node manufacturer, who is responsible for providing these parameters.

Syntax:

```
PRIME-prime0/0+fup set signature-length ?
<0..255>      Signature length
```

Example:

```
PRIME-prime0/0+fup set signature-length 8
PRIME-prime0/0+
```

Command history:

Release	Modification
11.01.08	The "signature-length" command was introduced as of version 11.01.08.

3.2.2.2.2 SIGNATURE-ALGORITHM

The SIGNATURE-ALGORITHM command allows you to configure the algorithm used to decrypt the signature for a specific FW. PRIME version 1.4 defines an encrypted signature to allow the FW to be used for Service Nodes. This signature may use several types of encryption and may be of variable length.

This parameter must be configured before the FW is sent to the Service Nodes. That is, the command must be set before a FUP session is initiated. It is only valid when the FUP START local console command is responsible for launching the FUP session.

This parameter must only be configured for Service Nodes that use PRIME version 1.4 and when the algorithm used is not NONE.

The FW algorithm and its length are defined by the Service Node manufacturer, who is responsible for providing these parameters.

The following signature types are allowed:

- NONE. FW does not include an encrypted signature.
- RSA. FW includes an encrypted signature (with RS3072 algorithm).

- ECDSA. FW includes an encrypted signature (with ECDSA256 algorithm).

Syntax:

```
PRIME-prime0/0+fup set signature-algorithm ?
none      None algorithm, not signed FW
RSA       RSA3072 algorithm, for signed FW
ECDSA     ECDSA256 algorithm, for signed FW
```

Example:

```
PRIME-prime0/0+fup set signature-algorithm RSA
PRIME-prime0/0+
```

Command history:

Release	Modification
11.01.08	The "signature-algorithm" command was introduced as of version 11.01.08.

3.2.2.3 START

The START command initiates a local FUP session for multiple Service Nodes. Up to 14 Service Nodes may be upgraded using this command.

A new session cannot be started while one is in progress.

The LIST FUP monitoring command displays information about a running process or the last finished process. This command may be used to monitor the FUP process.

Syntax:

```
PRIME-prime0/0+fup start ?
<1..256 chars>  SNs MAC list separated by semicolon:
                00:A0:26:00:01:FF;00:A0:26:00:01:32
```

Example:

```
PRIME-prime0/0+fup start 40:40:22:68:D4:01;40:40:22:68:D4:04
Reading upgrading file from /MEM/FW_NM_PRIME_V2203, 69760 bytes
PRIME-prime0/0+
```

To launch an FUP process, follow these steps:

- Obtain the upgraded software.
- Transfer the Service Node software to the PRIME Gateway through FTP.
- Launch the FUP process over the desired Service Nodes.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

3.2.2.3.1 Obtain Service Node firmware

To upgrade Service Node firmware, you must obtain the loading file for the Service Nodes that need upgrading. Similarly, you also need information about the type and version of Service Node installed to determine which firmware versions are compatible.

The user may obtain firmware for several Service Node models, together with the possible versions for each, from Service Node manufacturers. Please contact your Service Node provider and give them all the information about your Service Node. Information about the current firmware version can be found on the PRIME Gateway monitoring console.

Example:

```
PRIME-prime0/0+list topology firmware-sn

Service Nodes FW VERSION LIST:
-----
```

State	MAC	SERIAL/NUMBER	FW VERSION
terminal	40:40:22:68:D4:07	ZIV0040424455	9.2.0.3.4403
terminal	40:40:22:68:D4:06	ZIV0040424454	9.2.0.3.4403
terminal	40:40:22:70:58:AC	ZIV0040917164	9.2.0.3.4403
terminal	40:40:22:70:58:AD	ZIV0040917165	9.2.0.3.4403
terminal	40:40:22:68:D4:08	ZIV0040424456	9.2.0.3.4403
terminal	40:40:22:68:D4:05	ZIV0040424453	9.2.0.3.4403
terminal	40:40:22:70:58:AE	ZIV0040917166	9.2.0.3.4403
terminal	00:80:E1:34:E1:5F	LGZ0031458326	00-2403t
switch	00:80:E1:34:E1:AF	LGZ0031458327	00-2403t
terminal	40:40:22:68:D4:01	ZIV0040424449	2.2.0.3.4403
terminal	40:40:22:68:D4:04	ZIV0040424452	2.2.0.3.4403
terminal	40:40:22:68:D4:02	ZIV0040424450	9.2.0.3.4403
terminal	00:80:E1:2F:9A:AC	CIR0141604122	00-2201a
terminal	00:80:E1:2F:B0:87	CIR0141604121	00-2201a
switch	00:A0:26:92:00:0D		01.03.10.02-A-S

Total listed SN: 15

PRIME-prime0/0+

3.2.2.3.2 Transfer Service Node firmware

When it comes to upgrading device software or loading firmware for internal devices, the PRIME Gateway has an FTP server it can transfer files to.

This server is only accessible if the device has initiated correctly (application executed).

The firmware of the Service Nodes to be upgraded using the FUP command must be uploaded to PRIME Gateway through FTP before the FUP process starts. Only one firmware can be loaded at a time (meaning that only the Service Nodes that are compatible with this firmware will be upgraded).

Follow these steps to upgrade:

- (1) Save the upgrade file in a directory that belongs to the device from which you are going to launch the FTP session.
- (2) Connect to the FTP server (default is user **root** and no password).
- (3) Configure the binary mode through the **bin** command.
- (4) Transfer the file containing the firmware using the **put myfmwr.zzz** command. The .bin and .img file extensions are not allowed. Rename file extensions if necessary.
- (5) Once the transfer is complete, disconnect using the **bye** command.

```
C:\tmp>ftp 172.24.79.12
Conectado a 172.24.79.12.
220 FTP server ready, 1 active clients of 1 simultaneous clients allowed.
Name (172.24.79.12:(none)): root
331 User name accepted, need password.
Password:
230 User login complete.
ftp> bin

200 TYPE is set to IMAGE.
ftp> hash
Hash mark printing on (1024 bytes/hash mark).
ftp> put myfmwr.zzz

200 PORT is set to IP ADDR = 172.24.51.96 PORT = 5001
150 Data connection open, file transfer in process...
#####
226 STOR completed, 69760 bytes processed, data connection is closed.
ftp: 69760 bytes sent in 0,04 secs 1550.22 kB/s.
ftp> bye
230 Goodbye.

C:\tmp>
```

The transferred file is stored in the volatile memory (i.e., it will disappear once the device is restarted).

3.2.2.3.3 FUP process

Once this is done:

- (1) Configure FUP parameter with the SET commands if necessary.
- (2) Execute FUP START to start loading. If you have not preloaded the upgrade file in RAM, you will receive an error message.

```
PRIME-prime0/0+fup start 40:40:22:68:D4:01;40:40:22:68:D4:04

Reading upgrading file from /MEM/FW_NM_PRIME_V2203, 69760 bytes
PRIME-prime0/0+
```

- (3) The FUP process can take several hours depending on the number of Service Nodes to load and on the PRIME network requirements.
- (4) The firmware upgrade ends when the processing status goes to IDLE. You can monitor how the FUP process progresses through the LIST FUP monitoring command:

```
PRIME-prime0/0+list fup

---- PRIME FUP MONITORING COMMUNICATION -----

---- PLC STATISTICS -----
Process status           : UPGRADING(3)
FUP control process status : RUNNING(11)
Bytes received from PLC   : 618
Packets received from PLC : 152
Bytes received from PLC discarded : 0
Packets received from PLC discard.: 0
Packets sent to PLC      : 150
Retransmitted packets to PLC : 4

---- TCP DATA STATISTICS -----
Bytes sent to TCP        : 0
Bytes received from TCP  : 0
Packets sent             : 0
Packets received        : 0
Error packets received   : 0
Error bytes received     : 0
Errors or congestion detected : 0

---- TCP CONNECTION STATISTICS -----
Connection status       : DISCONN.(2)
TCP listen port         : 21400
Opened sessions         : 0
Disconnects received    : 0
Disconnects transmitted : 0

---- TCP SESSIONS INFO -----
STATE  REMOTE IP ADDR.  REM.PORT  ESTABLISH TIME  ORIG.
-----
ESTAB   192.168.213.157  60448    14:27:13 11/12/16  remote

FUP CURRENT SESSION CONFIGURATION:
-----
FW image CRC           : 0x07c63cbc
FW image length        : 69760
Page size              : 64
Reflash mode          : Unicast
Seg. unicast timeout   : 3600
Packet time            : 0
Sending process timeout: 18000
Switches delay execut. : Disabled[0]
Activation timeout     : 600

SN INCLUDED IN LAST FU PROCESS:
-----
```

```

Process elapsed time: 81
MAC                ROLE        LEV.  STATE      STATUS      PROGRESS
-----
40:40:22:68:D4:04  TERMINAL    0  UPGRADING  RECEIVING   712/1090
40:40:22:68:D4:01  TERMINAL    0  UPGRADING  RECEIVING    0/1090

Total listed SN: 2

PRIME-prime0/0+

```

- (5) When FUP ends, you can check whether the correct firmware version has been loaded in each Service Node through the LIST TOPOLOGY FIRMWARE-SN command.

```

PRIME-prime0/0+list topology firmware-sn

Service NodeS FW VERSION LIST:
-----
State  MAC                SERIAL/NUMBER  FW VERSION
-----
terminal 40:40:22:68:D4:07  ZIV0040424455  9.2.0.3.4403
terminal 40:40:22:68:D4:06  ZIV0040424454  9.2.0.3.4403
terminal 40:40:22:70:58:AC  ZIV0040917164  9.2.0.3.4403
terminal 40:40:22:70:58:AD  ZIV0040917165  9.2.0.3.4403
terminal 40:40:22:68:D4:08  ZIV0040424456  9.2.0.3.4403
terminal 40:40:22:68:D4:05  ZIV0040424453  9.2.0.3.4403
terminal 40:40:22:70:58:AE  ZIV0040917166  9.2.0.3.4403
terminal 00:80:E1:34:E1:5F  LGZ0031458326  00-2403t
switch  00:80:E1:34:E1:AF  LGZ0031458327  00-2403t
terminal 40:40:22:68:D4:01  ZIV0040424449  2.2.0.3.4403
terminal 40:40:22:68:D4:04  ZIV0040424452  2.2.0.3.4403
terminal 40:40:22:68:D4:02  ZIV0040424450  9.2.0.3.4403
terminal 00:80:E1:2F:9A:AC  CIR0141604122  00-2201a
terminal 00:80:E1:2F:B0:87  CIR0141604121  00-2201a
switch  00:A0:26:92:00:0D      01.03.10.02-A-S

Total listed SN: 15

PRIME-prime0/0+

```

3.2.3 LIST

This command helps monitor several PRIME interface functionalities:

- IEC 61334-4-32 active connections.
- Service Node availability statistics.
- PRIME network channel occupation.
- Data Concentrator TCP connection
- Firmware Upgrade Protocol (FUP) information
- Global PRIME status connection
- PLC modem debug report
- PHY layer extension feature information
- Sniffer protocol connection
- Topological information

Syntax:

```

PRIME-prime0/0+list ?
 432-connections      List IEC 61334-4-32 active connections
availability          PRIME SN availability statistics
channel-occupation    PRIME network channel occupation
dc-communication      Statistics for PRIME data connection
fup                   FUP(Firmware Upgrade Protocol) control options
global                Global PRIME interface statistics
modem-debug-report    PLC modem debug report

```

phy-layer-extension	Statistics for PHY layer extension over UDP monitoring connection
sniffer	Statistics for Sniffer monitoring connection
topology	PRIME network topology monitoring

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.
11.00.07, 11.01.03	New command (<i>modem-debug-report</i>) added.

3.2.3.1 432-CONNECTIONS

The *432-connections* option displays the list of PRIME Service Nodes that have an active data connection to the Base Node. The command displays all 432 connections or a specific number thereof.

Syntax:

```
PRIME-prime0/0+list 432-connections ?
<1..749>   Max. number of 432 connections to display
<cr>      Display all 432 connections
```

Example:

This example shows a list of several Service Nodes with an active IEC 61334-4-32 data connection:

```
PRIME-prime0/0+list 432-connections

IEC 61334-4-32 ACTIVE CONNECTIONS:
-----
ADDRESS          SERIAL/NUMBER    MAC
-----
1009(0x03f1)     ZIV0040917166  40:40:22:70:58:AE
1015(0x03f7)     ZIV0040917164  40:40:22:70:58:AC
1007(0x03ef)     ZIV0040424455  40:40:22:68:D4:07
1004(0x03ec)     ZIV0040424450  40:40:22:68:D4:02
1008(0x03f0)     LGZ0031458326  00:80:E1:34:E1:5F
1012(0x03f4)     LGZ0031458327  00:80:E1:34:E1:AF
1006(0x03ee)     CIR0141604122  00:80:E1:2F:9A:AC
1013(0x03f5)     ZIV0040917165  40:40:22:70:58:AD
1014(0x03f6)     ZIV0040424454  40:40:22:68:D4:06
1011(0x03f3)     ZIV0040424453  40:40:22:68:D4:05
1001(0x03e9)     ZIV0040424452  40:40:22:68:D4:04
1010(0x03f2)     ZIV0040424456  40:40:22:68:D4:08
1005(0x03ed)     ZIV0040424449  40:40:22:68:D4:01
1003(0x03eb)     CIR0141604121  00:80:E1:2F:B0:87

Total listed SN: 14

PRIME-prime0/0+
```

**Note**

- This command is not necessary when the PRIME Gateway is configured in Service Node mode.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.
11.01.08	Address hex format added.

3.2.3.2 AVAILABILITY

The availability command shows the quality and stability of the PRIME network. It is a list that includes statistical information on several key network parameters.

The Gateway integrates the statistical values for each period defined by three superframes (duration: ~1 minute).

The Gateway keeps the information for 60 periods (180 superframes). On top of this, the node also saves the accumulated values generated since the last network reset. The first listed element is the accumulated value, the second is the last period, the third is the period before that and so on.

The statistical information is displayed in a table with 61 rows and 9 columns. The first row (it. acc) shows the accumulated value since Base Node initialization or reset.

The availability parameters listed are the following:

- It.: Item listed (the first is the accumulated value) based on their period. The periods are listed from most to least recent.
- Promo.: Number of promotions that have occurred during the period.
- Demot.: Number of demotions that have occurred during the period.
- Reg.: Number of registrations that have occurred during the period.
- Unreg.: Number of unregistrations that have occurred during the period.
- Suc Alv.: Number of success alive sequences that have occurred during the period.
- Tot Alv.: Total number of live sequences sent during the period.
- Avail.: Average availability.

The accumulated value (first value in the table) is calculated as the average availability of the different nodes registered (at least once in that period) in the subnetwork. The accumulated value (row 1) will take into account every data registered since the last reset.

Period availability (from it.values 0 to -59) is calculated as the average availability of the different nodes registered, at least once, in the subnetwork.

- num.SN: Number of Service Nodes detected in the period, used when calculating availability.

This information can also be obtained by means of the SNMP protocol.

Syntax:

```
PRIME-prime0/0+list availability ?
<cr>
```

Example:

This example shows the availability statistics for the Gateway:

```
PRIME-prime0/0+list availability

It. Promo. Demot. Reg.  Unreg. Suc.Alv Tot.Alv Avail.  nun.SN
-----
Acc      2      0     30     27  11825  10983  99.50    11
 0      0      0      0      0      7      7 100.00    11
-1      0      0      0      0      8      8 100.00    11
-2      0      0      0      0     12     11 100.00    11
-3      0      0      0      0     10      9 100.00    11
-4      0      0      1      0     11      7  97.27    11
-5      0      0      0      0     10      9 100.00    10
-6      0      0      0      0     10      9 100.00    10
-7      0      0      0      1      7      7 100.00    10
-8      0      0      0      2     11      9  93.18    11
-9      0      0      0      0      7      7 100.00    11
-10     0      0      0      0      9      9 100.00    11
-11     0      0      0      0      9      9 100.00    11
-12     0      0      0      0     13     10 100.00    11
-13     0      0      0      0      8      8 100.00    11
-14     0      0      0      0      9      8 100.00    11
-15     0      0      0      0      8      7 100.00    11
```

```

-16  0  0  0  0  12  11 100.00  11
-17  0  0  0  0  10  8 100.00  11
-18  0  0  0  0  7   7 100.00  11
-19  0  0  0  0  9   9 100.00  11
-20  0  0  0  0  12  10 100.00  11
-21  0  0  0  0  6   6 100.00  11
-22  0  0  0  0  13  9 100.00  11
-23  0  0  0  0  7   7 100.00  11
-24  0  0  0  0  10  10 100.00  11
-25  0  0  0  0  11  10 100.00  11
-26  0  0  0  0  9   8 100.00  11
-27  0  0  0  0  8   8 100.00  11
-28  0  0  0  0  10  8 100.00  11
-29  0  0  0  0  9   9 100.00  11
-30  0  0  0  0  13  10 100.00  11
-31  0  0  0  0  6   6 100.00  11
-32  0  0  0  0  9   9 100.00  11
-33  0  0  0  0  10  9 100.00  11
-34  0  0  0  0  8   7 100.00  11
-35  0  0  0  0  10  10 100.00  11
-36  0  0  0  0  10  9 100.00  11
-37  0  0  0  0  7   7 100.00  11
-38  0  0  1  0  17  10 94.54  11
-39  0  0  0  0  8   8 100.00  10
-40  0  0  0  1  11  9 100.00  10
-41  0  0  0  1  7   7 92.12  11
-42  0  0  0  0  8   8 100.00  11
-43  0  0  0  0  12  9 100.00  11
-44  0  0  0  0  8   8 100.00  11
-45  0  0  0  0  10  10 100.00  11
-46  0  0  0  0  8   7 100.00  11
-47  0  0  0  0  10  9 100.00  11
-48  0  0  0  0  10  9 100.00  11
-49  0  0  0  0  11  9 100.00  11
-50  0  0  0  0  7   7 100.00  11
-51  0  0  0  0  10  10 100.00  11
-52  0  0  0  0  9   8 100.00  11
-53  0  0  0  0  11  9 100.00  11
-54  0  0  0  0  8   8 100.00  11
-55  0  0  0  0  9   9 100.00  11
-56  0  0  0  0  9   9 100.00  11
-57  0  0  0  0  9   8 100.00  11
-58  0  0  0  0  10  9 100.00  11
-59  0  0  0  0  9   9 100.00  11

```

PRIME-prime0/0+

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

3.2.3.3 CHANNEL-OCCUPATION

The channel-occupation command shows the data flow performance in the PLC network. It is a list of statistical information on several key network parameters.

Two separate options can be introduced to obtain data at PHY and MAC levels:

The PRIME Gateway supports several commands to obtain channel occupation data at PHY and MAC levels:

Syntax:

```

PRIME-prime0/0+list channel-occupation ?
  mac-layer    Display MAC layer channel occupation

```

```
phy-layer    Display PHY layer channel occupation
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

3.2.3.3.1 MAC-LAYER

This command displays the PLC PRIME network occupation at the MAC level.

The Gateway integrates the statistical values of each period, defined by three superframes (~1 minute).

The Gateway keeps the information for 60 periods (180 superframes). On top of this, the node also saves the accumulated values generated since the last network reset. The first listed element is the accumulated value, the second is the last period, the third is the period before that and so on.

The statistical information is displayed in a table with 61 rows and 10 columns. The first row (it. acc) includes the accumulated value since the Base Node has been running or reset.

The MAC layer channel occupation parameters listed are:

- It.: Item listed (the first is the accumulated value) based on their period. The periods are listed from most to least recent.
- Beacons: Number of beacon packets transmitted.
- CTR Tx pk: Number of control packets transmitted.
- CTR Tx tm: Channel time occupation of control packets transmitted (ms).
- CTR Rx pk: Number of control packets received.
- CTR Rx tm: Channel time occupation of control packets received (ms).
- DAT Tx pk : Number of data packets transmitted.
- DAT Tx tm: Channel time occupation of data packets transmitted (ms).
- DAT Rx pk: Number of data packets received.
- DAT Rx tm: Channel time occupation of data packets received (ms).

Syntax:

```
PRIME-prime0/0+list channel-occupation phy-layer ?
<cr>
```

Example:

This example shows channel occupation at the MAC layer:

```
PRIME-prime0/0+list channel-occupation mac-layer

MAC layer occupation information:
It. Beacons   CTR Tx pk CTR Tx tm   CTR Rx pk CTR Rx tm   DAT Tx pk DAT Tx tm   DAT Rx pk DAT Rx tm
-----
Acc  1348434   359810   4535381   268924   3757485   395651   4779749   325493   4310162
 0    194      42      534       37      533       66      777       52      746
-1   194      44      562       33      453       67      788       54      724
-2   194      42      528       35      483       63      750       52      694
-3   194      39      510       33      429       64      761       52      642
-4   194      52      635       41      541       72      834       58      736
-5   192      33      444       29      393       63      750       49      649
-6   194      50      610       39      499       62      742       52      654
-7   194      43      548       34      444       65      769       52      666
-8   194      46      572       39      515       65      772       52      666
-9   194      46      572       37      509       66      777       53      709
-10  194      42      534       36      474       66      777       52      690
-11  192      46      572       37      501       63      750       52      694
-12  194      41      526       35      487       63      750       52      694
-13  194      43      542       36      494       65      769       53      709
```

-14	194	49	599	39	499	66	780	52	662
-15	194	39	510	32	422	66	777	53	669
-16	194	50	613	41	549	67	788	53	669
-17	194	38	502	30	416	68	793	54	724
-18	194	39	507	32	442	65	772	53	709
-19	194	46	578	38	528	64	758	52	694
-20	194	50	607	40	546	65	766	53	709
-21	194	47	586	38	504	70	815	54	716
-22	194	35	466	32	418	65	772	50	620
-23	194	42	534	36	466	66	780	52	666
-24	196	45	564	38	496	64	758	52	674
-25	194	44	550	36	502	65	772	52	694
-26	194	42	534	32	434	62	742	52	694
-27	194	40	524	34	468	65	766	52	694
-28	194	57	672	45	601	62	742	52	694
-29	194	34	458	29	397	68	796	54	724
-30	194	44	550	36	474	63	750	52	694
-31	194	41	532	35	459	64	758	52	674
-32	194	39	504	33	457	65	766	52	694
-33	194	45	564	38	484	64	758	54	684
-34	194	44	550	37	505	65	772	52	694
-35	194	46	572	38	492	63	750	52	638
-36	194	42	534	35	479	64	758	52	694
-37	194	44	553	36	466	67	782	53	681
-38	194	43	542	36	486	65	766	52	702
-39	192	46	572	39	535	69	807	53	709
-40	194	51	624	38	512	67	791	54	724
-41	194	44	556	35	459	78	888	59	735
-42	194	39	498	34	440	62	742	48	606
-43	194	41	532	34	452	67	785	54	680
-44	195	43	542	36	494	65	766	52	694
-45	195	50	610	40	538	64	758	52	694
-46	194	40	518	33	429	67	785	54	680
-47	194	43	542	37	477	62	742	52	674
-48	194	50	616	40	546	65	766	52	694
-49	194	41	526	35	463	83	946	61	809
-50	194	34	452	30	412	59	744	46	604
-51	194	45	567	37	485	64	758	52	654
-52	194	48	594	39	531	67	788	53	709
-53	194	43	542	37	505	64	758	52	694
-54	194	45	558	38	484	65	766	52	646
-55	194	48	594	38	505	68	796	53	685
-56	194	46	572	38	525	67	785	53	685
-57	194	36	480	30	408	65	769	53	709
-58	194	43	542	37	473	64	758	52	662

PRIME-prime0/0+

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

3.2.3.3.2 PHY-LAYER

This command displays the PLC PRIME network occupation at the MAC level.

The Gateway integrates the statistical values of each period, defined by three superframes (~1 minute).

The Gateway keeps the information for 60 periods (180 superframes). On top of this, the node also saves the accumulated values generated since the last network reset. The first listed element is the accumulated value, the second is the last period, the third is the period before that and so on.

The statistical information is displayed in a table with 61 rows and 7 columns. The first row (it. acc) includes the accumulated value since the Base Node has been running or reset.

The PHY layer channel occupation parameters listed are:

- It.: Item listed (the first is the accumulated value) based on their period. Periods are listed from most to least recent.
- CFP pkts: Number of CFP packets transmitted or received.
- CFP time: Channel time occupation of CFP packets transmitted or received (ms).
- SCP pkts: Number of SCP packets transmitted or received.
- SCP time: Channel time occupation of SCP packets transmitted or received (ms).
- ERR pkts: Number of error packets received.
- ERR time: Channel time occupation of error packets received (ms).

Syntax:

```
PRIME-prime0/0+list channel-occupation phy-layer ?
<cr>
```

Example:

This example shows channel occupation at the PHY layer:

```
PRIME-prime0/0+list channel-occupation phy-layer

PHY PLC channel occupation information:
It.  CFP pkts  CFP time  SCP pkts  SCP time  ERR pkts  Err time
-----
Acc      0        0    1350477  17390372    1182     22298
  0      0        0       219     2741         0         0
 -1      0        0       186     2376         0         0
 -2      0        0       188     2412         0         0
 -3      0        0       197     2590         0         0
 -4      0        0       198     2527         0         0
 -5      0        0       192     2455         2         30
 -6      0        0       188     2342         0         0
 -7      0        0       223     2746         0         0
 -8      0        0       174     2236         2         30
 -9      0        0       203     2505         0         0
-10      0        0       194     2427         0         0
-11      0        0       202     2525         0         0
-12      0        0       202     2567         0         0
-13      0        0       196     2475         0         0
-14      0        0       198     2517         0         0
-15      0        0       191     2457         0         0
-16      0        0       197     2514         0         0
-17      0        0       206     2540         0         0
-18      0        0       190     2378         0         0
-19      0        0       211     2619         0         0
-20      0        0       190     2435         0         0
-21      0        0       189     2430         2         38
-22      0        0       200     2558         0         0
-23      0        0       208     2628         0         0
-24      0        0       209     2621         0         0
-25      0        0       182     2276         0         0
-26      0        0       196     2446         0         0
-27      0        0       199     2492         0         0
-28      0        0       197     2518         0         0
-29      0        0       188     2404         0         0
-30      0        0       191     2452         0         0
-31      0        0       216     2709         2         30
-32      0        0       185     2375         0         0
-33      0        0       195     2468         0         0
-34      0        0       192     2423         0         0
-35      0        0       189     2421         0         0
-36      0        0       201     2490         2         22
-37      0        0       198     2521         2         38
-38      0        0       199     2452         0         0
```

```

-39      0      0      193      2465      0      0
-40      0      0      200      2482      0      0
-41      0      0      196      2496      0      0
-42      0      0      207      2623      0      0
-43      0      0      210      2651      0      0
-44      0      0      216      2638      0      0
-45      0      0      183      2286      0      0
-46      0      0      196      2449      0      0
-47      0      0      196      2496      0      0
-48      0      0      206      2600      0      0
-49      0      0      194      2412      0      0
-50      0      0      194      2435      0      0
-51      0      0      207      2622      0      0
-52      0      0      220      2744      2      30
-53      0      0      169      2212      0      0
-54      0      0      198      2464      2      38
-55      0      0      207      2622      2      30
-56      0      0      196      2499      0      0
-57      0      0      200      2454      0      0
-58      0      0      207      2580      0      0
-59      0      0      204      2567      0      0

```

PRIME-prime0/0+

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

3.2.3.4 DC-COMMUNICATION

The DC-COMMUNICATION list option displays information on the communication between the PRIME Gateway and the DLMS/COSEM Data Concentrator. This communication is also known as "DLMS over TCP" or TICKET-67.

The PRIME Gateway keeps two communications: one to the Data Concentrator via TCP session and another to the internal PLC PRIME module.

The list command option shows, separately, information for each data communication path and information about current TCP active connections (whenever they are established).

Enabling this command makes no sense when PRIME Gateway is configured as Service Node, since a direct connection between the Data Concentrator and the Service Node is not possible in this mode.

Syntax:

```
PRIME-primeX/Y+list dc-communication
```

Example:

This example shows the statistics and connection state of an established Data Concentrator session:

```

PRIME-prime0/0+list dc-communication

---- PRIME DATA TO DC COMMUNICATION ----

---- PLC STATISTICS ----
Data protocol           : TICKET-67
Connection status      : CON(3)
Connection drops       : 0
Bytes received from PLC : 14331
Packets received from PLC : 312
Bytes sent to PLC      : 12937
Packets sent to PLC    : 290
Bytes received from PLC discarded : 422
Packets received from PLC discard.: 38
PLC 4-32 communication:
- Data packets sent    : 289

```

```

- Data packets confirmed OK      : 288
- Data packets confirmed ERROR   : 0
- Data packets not confirmed     : 0
- Data packets retransmissions   : 0
- Tx Data packets queued        : 1
- Release packets sent           : 1
- Release/Joint packets confirmed : 1
- Release packets not confirmed  : 0
- Release packets retransmissions: 0

---- TCP DATA STATISTICS -----
Bytes sent to TCP                : 14287
Bytes received from TCP         : 13604
Packets sent                    : 310
Packets received                : 403
Error packets received          : 0
Error bytes received            : 0
Errors or congestion detected   : 0

---- TCP CONNECTION STATISTICS -----
TCP listen port                 : 502
Opened sessions                 : 2
Current sessions                : 1
Max simultaneous sessions      : 1
Disconnects received           : 1
Disconnects transmitted        : 0

---- TCP SESSIONS INFO -----
STATE  REMOTE IP ADDR.  REM.PORT  ESTABLISH TIME  ORIG.
-----
ESTAB   192.168.213.157 48560    09:34:32 19/11/25 remote

PRIME-prime0/0+
```



Note

- This command is not necessary when the PRIME Gateway is configured in Service Node mode.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.
11.01.08	4-32 connection statistics added.

3.2.3.5 FUP

The FUP option displays statistical information on the Firmware Upgrade Protocol (FUP) process. When FUP is running, this command displays information about the current process. If the FUP process is not running but was previously executed, this command shows information on the last process executed.

The PRIME Gateway keeps two communications: one to the FUP application via a TCP session and another to the internal PLC PRIME modem.

The list command option shows, separately, information for each data communication path and information about current TCP active connections (whenever they are established).

Enabling this command makes no sense when PRIME Gateway is configured as Service Node, since a direct connection between the FUP application and the Service Node is not possible in this mode.

Syntax:

```
PRIME-primeX/Y+list fup
```

Example:

This example shows the statistics and connection state of an established FUP session, as well as the status of the Service Nodes involved in the process:

```
PRIME-prime0/0+list fup

---- PRIME FUP MONITORING COMMUNICATION -----

---- PLC STATISTICS -----
Process status           : UPGRADING(3)
FUP control process status : RUNNING(11)
Bytes received from PLC   : 618
Packets received from PLC : 152
Bytes received from PLC discarded : 0
Packets received from PLC discard.: 0
Packets sent to PLC      : 150
Retransmitted packets to PLC : 4

---- TCP DATA STATISTICS -----
Bytes sent to TCP        : 0
Bytes received from TCP  : 0
Packets sent             : 0
Packets received         : 0
Error packets received   : 0
Error bytes received     : 0
Errors or congestion detected : 0

---- TCP CONNECTION STATISTICS -----
Connection status        : DISCONN. (2)
TCP listen port          : 21400
Opened sessions          : 0
Disconnects received    : 0
Disconnects transmitted : 0

---- TCP SESSIONS INFO -----
  STATE  REMOTE IP ADDR.  REM.PORT  ESTABLISH TIME  ORIG.
-----
ESTAB    192.168.213.157  60448    14:27:13 11/12/16  remote

FUP CURRENT SESSION CONFIGURATION:
-----
FW image CRC           : 0x07c63cbc
FW image length        : 69760
Page size              : 64
Reflash mode           : Unicast
Seg. unicast timeout   : 3600
Packet time            : 0
Sending process timeout: 18000
Switches delay execut. : Disabled[0]
Activation timeout     : 600

FUP CURRENT SESSION STATISTICS:
-----
Num. Tx unicast data packets : 0
Num. Tx multicast data packets: 1132
Num. Tx STATUS packets       : 6
Num. Rx STATUS packets       : 19
Num. Tx MISS packets         : 14
Num. Rx MISS packets         : 7
Num. Tx CONTROL packets     : 15
Num. Rx CONTROL packets     : 16

SN INCLUDED IN LAST FU PROCESS:
-----
Process elapsed time: 81
MAC                ROLE        LEV.  STATE        STATUS        PROGRESS
-----
```



```
40:40:22:68:D4:04 TERMINAL      0 UPGRADING   RECEIVING    712/1090
40:40:22:68:D4:01 TERMINAL      0 UPGRADING   RECEIVING     0/1090
```

```
Total listed SN: 2
```

```
PRIME-prime0/0+
```

The following FUP parameters are listed:

- **Process status:** indicates the status of the global FUP process. This status value is reported to the remote FUP application when required. The status can take the following values:
 - (a) IDLE
 - (b) RECEIVING
 - (c) RELEASING
 - (d) UPGRADING
 - (e) ACTIVATING SWITCHES
- **FUP control process status:** indicates the status of the FUP process at the PRIME PLC level. The status can take the following values:
 - (a) STOPPED
 - (b) RUNNING
- **PLC statistics:** displays several counters on the data exchanged with the PRIME modem.
- **TCP data statistics:** displays several counters on the data exchanged with the FUP application through a TCP session.
- **TCP connection statistics:** displays several counters related to the TCP sessions used by the FUP application to connect to the PRIME Gateway. It also displays, if active, some relevant information about the TCP session.
- **FUP current session configuration:** displays the configuration parameters received from the FUP application to perform the process. When the process is launched from the local console, the configuration parameters are always the same. This information is only displayed if the FUP process is running or said process has been previously executed.
- **FUP current session statistics:** displays statistical information of messages related to the FUP process exchanged in the PLC network. Listed message types are those defined by the PRIME standard for the FUP process.
- **Service Node included in last FUP process:** displays information related to the FUP process for each Service Node. The information reported is as follows:
 - (a) **MAC:** MAC address for the Service Node involved in the FUP process.
 - (b) **ROLE:** Service Node role in PRIME network: SWITCH or TERMINAL.
 - (c) **LEV:** level on PRIME network topology for Service Node.
 - (d) **STATE:** indicates the state of the FUP process for each Service Node. This status value is reported to the remote FUP application when required. It can take the following values: IDLE, CONFIGURED, UPGRADING, UPGRADED, KILLED, ERROR, TIMEOUT, REJECTED and ABORTED.
 - (e) **STATUS:** indicates the status of the FUP process for each Service Node. This value represents the status of the FUP received from the Service Node, in accordance with the PRIME standard. It can take following values: IDLE, RECEIVING, COMPLETE, COUNTDOWN and UPGRADE.
 - (f) **PROGRESS:** displays the firmware packets transferred, and the total packets to be transferred, to each Service Node.



Note

- There is no need for this command when the PRIME Gateway is configured in Service Node mode.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

3.2.3.6 PHY-LAYER-EXTENSION

The PHY-LAYER-EXTENSION list option displays information related to the PRIME PHY layer extension over UDP (Ticket#65). Through this command, the state of the PHY layer extension communication can be monitored.

The PHY layer extension feature is operative for the Base Node and Service Node modes.

In Base Node mode, when the PHY layer extension feature is enabled, the PRIME Gateway can access several Service Nodes over UDP. The Base Node sends all datagrams to the Service Nodes that have a record.

In Service Node mode, only one access to the associated Base Node is allowed. The Service Node sends all datagrams to its associated Base Node.

When it comes to the PHY layer extension feature, the PRIME Gateway keeps two communication types: one to its peer/s node/s via UDP datagrams, and another one to the internal PLC PRIME modem.

The list command option shows, separately, information for each data communication path and information about the current UDP status.

Syntax:

```
PRIME-primeX/Y+list phy-layer-extension
```

Example:

This example shows statistics and the connection state for the PHY layer extension feature:

```
PRIME-prime0/0+list phy-layer-extension

---- PRIME PHY LAYER EXTENSION OVER UDP -----
Configuration option      : ENABLED(1)
Connection status        : CONNECT.(3)
UDP local listen port    : 4567
Remote SN connection data:
  SN ID name             : REMOTE
  UDP port               : 40038
  IP address             : 192.168.213.165

---- PLC STATISTICS -----
Bytes received from PLC   : 35330344
Packets received from PLC : 1378325
Bytes sent to PLC        : 14454584
Packets sent to PLC      : 520709
Bytes received from PLC discarded : 0
Packets received from PLC discard.: 0

---- UDP STATISTICS -----
Bytes sent to UDP        : 35330362
Bytes received from UDP  : 14454584
Packets sent            : 1378325
Packets received        : 520709
Error packets received   : 0
Error bytes received     : 0
Errors or congestion detected : 0
PRIME-prime0/0+
```

The meaning of the parameters listed is as follows:

- PHY layer extension over UDP. Display the configuration and status that define UDP communications:

Configuration option: Indicates whether the PHY layer extension feature is enabled.

Connection status: Indicates if the PHY layer extension feature is running.

UDP local listen port: Displays active listening UDP port to receive incoming datagrams from the remote node/s.

Remote SN connection data: Displays remote node/s UDP configuration, to send outgoing datagrams to the remote node/s. The configured parameters for each remote node are: NAME, UDP port and IP address. For Service Node mode, only one remote Base Node can appear. For Base Node mode, several remote Service Nodes may appear.

- PLC Statistics: displays several counters on the data exchanged with the PRIME modem.
- UDP statistics: displays several counters on the data exchanged with the peer/s node/s through UDP datagrams.



Note

- The PHY-LAYER-EXTENSION operation is not available in all PRIME devices. Please contact our Technical Service for more information on the devices that support this feature.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

3.2.3.7 MODEM-DEBUG-REPORT

The MODEM-DEBUG-REPORT list option displays debugging information linked to the PLC PRIME internal module. This information is usually intended for internal debugging purposes, as it may contain code errors or debugging results. This command also shows information about PLC RAM memory and PLC ZCD (Zero Cross Detector) sensor.

It shows the RAM memory size of the PLC modem and the result of its initial test.

The ZCD sensor generates a square signal, the command shows the time for each level (high and low). The sum of the high and low times should be around 20000 microseconds.

Syntax:

```
PRIME-primeX/Y+list modem-debug-report
```

Example:

This example shows the outcome of the MODEM-DEBUG-REPORT command:

```
PRIME-prime0/0+ list modem-debug-report
```

```
Zero Cross Sensor info:
```

```
- High time: 10576 uSec
- Low time : 9327 uSec
```

```
External SRAM test:
```

```
- Test result: OK
- Detected size: 8192 KBytes
```

```
Item Date      Time      Debug code
```

```
-----
 1 2019/11/25 09:30:42 0x99da8df2
 2 2019/11/25 09:30:42 0x06f908fb
 3 2019/11/25 09:30:42 0xebff5254
 4 2019/11/25 09:30:42 0x778b6e7f
 5 2019/11/25 09:30:42 0xafe3471b
 6 2019/11/25 09:30:42 0x42d51e5b
 7 2019/11/25 09:30:42 0x09b5b4b6
 8 2019/11/25 09:30:42 0x81245c25
 9 2019/11/25 09:30:42 0x19424c58
10 2019/11/25 09:30:42 0x5d5bdfbc
11 2019/11/25 09:30:42 0xd80c0d83
12 2019/11/25 09:30:42 0xb9b0b9d1
13 2019/11/25 09:30:42 0x65e9fb14
14 2019/11/25 09:30:42 0x3916998f
15 2019/11/25 09:30:42 0x5a435353
16 2019/11/25 09:30:42 0x00002950
17 2019/11/25 09:30:42 0x0000246f
18 2019/11/25 09:30:42 0x5a435345
19 2019/11/25 09:30:42 0x45525453
20 2019/11/25 09:30:42 0x00000001
21 2019/11/25 09:30:42 0x00000000
22 2019/11/25 09:30:42 0x00800000
23 2019/11/25 09:30:42 0x45525445
```

```
PRIME-prime0/0+
```

Command history:

Release	Modification
11.00.07, 11.01.03	New command added.
11.01.08	ZCD and SRAM information added.

3.2.3.8 GLOBAL

The GLOBAL list option displays information relative to the PLC PRIME internal module. Through this command, the state of the PLC module can be monitored.

This command shows the operation mode: Service Node or Base Node.

It also shows current BN frequency channel in use.

For the PRIME module to operate properly, the PRIME MANAGEMENT COMMUNICATION status and the "Interface state" must be up.

This command shows the PRIME firmware version for the PLC module. The PRIME Gateway loads the appropriate firmware depending on the configured operation mode (Base or Service Node) or PRIME release (PRIME 1.3 or PRIME 1.4).

Syntax:

```
PRIME-primeX/Y+list global
```

Example:

This example shows the GLOBAL command results:

```
PRIME-prime0/0+list global

Node operation mode : BASE NODE
Frequency Channel   : 1
Interface State     : UP(4)
PLC firmware version : 01.03.10.04-B-F

----- PRIME INTERFACE STATISTICS -----
Bytes sent to PLC           : 147926
Bytes received from PLC    : 4707974
Packets sent to PLC        : 3071
Packets received from PLC  : 74173
CRC/LRC error packets PLC  : 0
Start frame char errors    : 1
Length error packets      : 0
Errors or congestion detected : 0

---- PRIME MANAGEMENT COMMUNICATION -----
Status                   : UP(16)
Connection drops         : 0
Management packets received : 407
Management packets sent   : 250
Network status events received : 2308
Alive status events received : 2279
PLC modem resets performed : 0

PRIME-prime0/0+
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

Release	Modification
11.01.08	New information added.

3.2.3.9 SNIFFER

The SNIFFER list option displays information relative to the PLC PRIME Sniffer protocol. Through this command, the Sniffer's communication state can be monitored.

The purpose of this command is to monitor the PRIME Sniffer connections and communication.

When it comes to the PRIME Sniffer protocol, the PRIME Gateway keeps two communications: one to the Sniffer Application via a TCP session, and another one to the internal PLC PRIME module.

Sniffer may be accessed by a Sniffer application, through an incoming TCP session, or by the SNMP protocol through an outgoing TCP session. Only one session is allowed. An SNMP session has priority over a Sniffer application session. If Sniffer is enabled and the Gateway receives an SNMP session request, the Sniffer session will be dropped.

This command shows whether the session established is SNMP.

The list command option shows, separately, information for each data communication path and information about current TCP active connections (whenever they are established).

Syntax:

```
PRIME-primeX/Y+list sniffer
```

Example:

This example shows statistics and the connection state of a Sniffer session established:

```
PRIME-prime0/0+list sniffer

---- PRIME SNIFFER MONITORING COMMUNICATION ----

---- PLC STATISTICS ----
Connection status           : CONNECT. (5)
SNMP Sniffer Tx Data        : DISABLED
SNMP Topology Tx Data       : DISABLED
SNMP Sniffer Tx Optional Data : DISABLED
Sniffer listen port for ext. tool : ENABLED
Bytes received from PLC      : 18201
Packets received from PLC    : 309
Bytes sent to PLC           : 0
Packets sent to PLC         : 0
Bytes received from PLC discarded : 0
Packets received from PLC discard.: 0

---- TCP DATA STATISTICS ----
Bytes sent to TCP           : 20167
Bytes received from TCP     : 0
Packets sent                : 311
Packets received           : 0
Error packets received      : 0
Error bytes received        : 0
Errors or congestion detected : 0

---- TCP CONNECTION STATISTICS ----
TCP listen port            : 3333
Opened sessions            : 1
Disconnects received       : 0
Disconnects transmitted    : 0

---- TCP SESSIONS INFO ----
  STATE  REMOTE IP ADDR.  REM.PORT  ESTABLISH TIME  ORIG.
-----
ESTAB    192.168.212.33  58027    09:45:18 20/06/16  remote
```

```
PRIME-prime0/0+
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

3.2.3.10 TOPOLOGY

The TOPOLOGY list option displays information on the topology of the PLC PRIME active network. The PRIME Gateway supports several commands related to PRIME network topology:

- List of firmware versions of Service Nodes.
- Statistics for topology files sent through FTP.
- Network change events stored while waiting to be saved in a topology file.
- Topological structure of the network.

Syntax:

```
PRIME-prime0/0+list topology ?
  firmware-sn      Displays the last firmware version for each SNs detected.
  ftp-statistics   Displays the statistics of sending the topology files
                  through FTP
  net-events       Display Network topology Events stored
  sn-devices       Display topology for SN devices detected
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

3.2.3.10.1 FIRMWARE-SN

The FIRMWARE-SN list option lists the PRIME Service Nodes that have an active data connection to the Base Node and, where obtained, their firmware versions. The command displays information on all connected Service Nodes, or on a specific number thereof.

This command displays the following fields:

- STATE: Indicates the Service Node's state (SWITCH or TERMINAL).
- MAC: Indicates the Service Node's MAC address.
- SERIAL/NUMBER: Indicates the Service Node's serial number.
- FW VERSION: Indicates the Service Node's PRIME firmware version.

Syntax:

```
PRIME-prime0/0+list topology firmware-sn ?
<1..749>   Max. number of SN to display
<cr>      Display all SN stored
```

Example:

This example shows a list of several Service Nodes with their PRIME firmware version:

```
PRIME-prime0/0+list topology firmware-sn

Service Nodes FW VERSION LIST:
-----
State   MAC                SERIAL/NUMBER    FW VERSION
-----
terminal 40:40:22:68:D4:03  ZIV0040424451   2.2.0.3.4559
terminal 40:40:22:68:D4:07  ZIV0040424455   9.2.0.3.4403
terminal 40:40:22:68:D4:06  ZIV0040424454   9.2.0.3.4403
terminal 40:40:22:70:58:AC  ZIV0040917164   9.2.0.3.4403
terminal 40:40:22:70:58:AD  ZIV0040917165   9.2.0.3.4403
```

```

terminal 40:40:22:68:D4:08 ZIV0040424456 9.2.0.3.4403
terminal 40:40:22:68:D4:05 ZIV0040424453 9.2.0.3.4403
terminal 40:40:22:70:58:AE ZIV0040917166 9.2.0.3.4403
terminal 00:80:E1:34:E1:5F LGZ0031458326 00-2403t
switch 00:80:E1:34:E1:AF LGZ0031458327 00-2403t
terminal 40:40:22:68:D4:01 ZIV0040424449 2.2.0.3.4403
terminal 40:40:22:68:D4:04 ZIV0040424452 2.2.0.3.4403
terminal 40:40:22:68:D4:02 ZIV0040424450 9.2.0.3.4403
terminal 00:80:E1:2F:9A:AC CIR0141604122 00-2201a
terminal 00:80:E1:2F:B0:87 CIR0141604121 00-2201a
switch 00:A0:26:92:00:0D 01.03.10.02-A-S

```

Total listed SN: 16

PRIME-prime0/0+



Note

- There is no need for this command when the PRIME Gateway is configured in Service Node mode.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.
11.01.06	The "firmware-sn" command was previously misspelled ("firware-sn") and, from now on, is shown correctly.

3.2.3.10.2 FTP-STATISTICS

This command displays detailed status and statistical information on FTP transfers of topology files.

The information obtained using this command can help detect some problems related to FTP server communication.

Syntax:

```

PRIME-prime0/0+list topology ftp-statistics ?
<cr>

```

Example:

```

PRIME-prime0/0+list topology ftp-statistics

Active configuration parameters:
File management           : Enabled
FTP server ip address     : 192.168.212.33
FTP server port           : 21
File send time            : 60 seconds
File max lines            : 100
File FTP remote path      : prime
File name prefix          : topology
FTP connection user       : admin
FTP connection password   : hsdudx

File transfer statistics:
File trans. in progress   : NOT
File in progress name     :
Waiting for Retransm.    : NOT
Retrans. remaining tries  : 0
Num. success transfers    : 2
Last success file         : topology_20160720_102553.csv
Num. of failed transfers  : 114
Last failed file          : topology_20160720_090816.csv
Last failure error cause  : 0x02 (Connection error)

PRIME-prime0/0+

```

**Note**

- There is no need for this command when the PRIME Gateway is configured in Service Node mode.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

3.2.3.10.3 NET-EVENTS

The TOPOLOGY NET-EVENTS list option displays the state changes in events waiting to be saved in a topology event file.

The current events showed will be stored in a topology event file when file timeout occurs.

This command may show all pending events or a specific number thereof.

Syntax:

```
PRIME-prime0/0+list topology net-events ?
<1..3999>   Number of Events to display
<cr>       Display all Events stored
```

Example:

This example shows a list of changes in the state of an event:

```
PRIME-prime0/0+list topology net-events
```

Item	Date	Time	SN MAC	Father MAC	SN State	Q	BN_MAC
1	2019/11/24	08:17:26	00:80:E1:34:E1:5F	00:A0:26:8C:00:15	switch	98	00:A0:26:8C:00:15
2	2019/11/24	08:19:50	40:40:22:70:58:AE	00:A0:26:8C:00:15	terminal	97	00:A0:26:8C:00:15
3	2019/11/24	08:23:12	40:40:22:70:58:AD	00:A0:26:8C:00:15	terminal	98	00:A0:26:8C:00:15
4	2019/11/24	08:23:12	40:40:22:70:58:AE	00:A0:26:8C:00:15	switch	97	00:A0:26:8C:00:15
5	2019/11/24	08:23:52	40:40:22:70:58:AC	40:40:22:70:58:AE	terminal	99	00:A0:26:8C:00:15
6	2019/11/24	08:24:13	40:40:22:68:D4:05	00:A0:26:8C:00:15	disconn.	96	00:A0:26:8C:00:15
7	2019/11/24	08:28:12	00:80:E1:34:E1:5F	00:A0:26:8C:00:15	terminal	97	00:A0:26:8C:00:15
8	2019/11/24	08:28:43	40:40:22:70:58:AC	40:40:22:70:58:AE	disconn.	99	00:A0:26:8C:00:15

```
PRIME-prime0/0+
```

**Note**

- There is no need for this command when the PRIME Gateway is configured in Service Node mode.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

3.2.3.10.4 SN-DEVICES

The TOPOLOGY SN-DEVICES list option displays the topological structure of all Service Nodes registered, at one point, in the PRIME Gateway.

The list of Nodes is organized by levels, based on the number of switches that a Service Node has in the path to access the Base Node.

This command may show all Service Nodes or a specific number thereof.

For the Service Node mode operation, this command only shows the Base Node itself and the nodes that depend on it and are operating as SWITCH. The information for this operation mode is minimal.

Syntax:

```
PRIME-prime0/0+list topology sn-devices ?
<1..749>   Max. number of SN to display
<cr>      Display all SN stored
```

Example:

In the following example, the command executed on a PRIME Gateway configured as Base Node, shows a topological list of Service Nodes:

```
PRIME-prime0/0+list topology sn-devices

BASE NODE Info:
-----
State          MAC                CHANNEL LNID    DISC UP-TIME    CNX-TIME
-----
Running        00:A0:26:96:00:06      1 0x0000    0    1:49:11    1:49:11

SERVICE NODES network topology:
-----
NETWORK LEVEL: 0
State          MAC                LNID    SID    LSID  Qlt  TxALV  RxALV  ALV-T  DISC  UP-TIME    %    CNX-TIME
-----
terminal 00:80:E1:2F:B0:87 0x1778 0x00 0xff  97   311   302   256   0    1:46:13  97.2  1:46:13
switch  40:40:22:68:D4:08 0x1777 0x00 0x06  96   314   304   256   0    1:47:05  98.0  1:47:05
switch  40:40:22:70:58:AD 0x1774 0x00 0x04  98   311   307   256   0    1:47:15  98.2  1:47:15
terminal 40:40:22:68:D4:02 0x1773 0x00 0xff  96   318   306   256   0    1:47:28  98.4  1:47:28
terminal 00:80:E1:34:E1:5F 0x1771 0x00 0xff  98   317   313   256   0    1:49:09  100   1:49:09

NETWORK LEVEL: 1
State          MAC                LNID    SID    LSID  Qlt  TxALV  RxALV  ALV-T  DISC  UP-TIME    %    CNX-TIME
-----
terminal 40:40:22:68:D4:07 0x177b 0x06 0xff  80   312   250   256   0    1:34:09  86.2  1:34:09
terminal 40:40:22:70:58:AC 0x177a 0x06 0xff  80   310   251   256   0    1:34:10  86.2  1:34:10
terminal 00:80:E1:2F:9A:AC 0x1779 0x06 0xff  83   312   261   256   0    1:37:19  89.1  1:37:19
terminal 40:40:22:70:58:AE 0x1775 0x04 0xff  77   340   263   256   0    1:40:02  91.6  1:40:02
terminal 00:80:E1:34:E1:AF 0x1772 0x06 0xff  87   308   270   256   1    1:39:06  90.7  1:32:16
terminal 40:40:22:68:D4:06 0x1776 0x04 0xff  83   345   288   256   1    1:45:49  96.9  1:33:36

Total listed SN: 11
Terminals: 9
Switches: 2
Disconnec.: 0

PRIME-prime0/0+
```

In the following example, the command executed on a PRIME Gateway configured as Service Node, shows a topological list of Service Nodes operating in SWITCH mode. The switch on level 0 represents the current PRIME Gateway:

```
PRIME-prime0/0+list topology sn-devices

BASE NODE Info:
-----
State          MAC                LNID    DISC UP-TIME    CNX-TIME
-----
Connected      00:A0:26:92:00:09 0x0000    0    119:38:39  119:38:39

Service Nodes network topology:
-----
NETWORK LEVEL: 0
State          MAC                LNID    SID    LSID  DISC  UP-TIME    CNX-TIME
-----
switch  00:A0:26:92:00:0D 0x37ac 0x00 0x01    0    119:38:40  119:38:40

NETWORK LEVEL: 1
State          LSID %    CNX-TIME
```

```

-----
switch  0x0f 58.7    70:14:07

Total listed SN: 2

PRIME-prime0/0+

```

Each field has the following meaning:

- **STATE:** Current state for a specific node. Service Nodes can have the following states: terminal, switch or disconnect. The Base Node can take the following states: stopped or running.
- **MAC:** Node MAC (Medium Access Control) address.
- **CHANNEL:** Frequency channel operation (for BN only).
- **LNID:** Local Node Identifier in PRIME network
- **SID:** Switch Identifier where the Service Node is connected. The value of this field is 0x00 for Service Nodes that are directly connected to the Base Node.
- **LSID:** Local Switch Identifier, identifies a Switch on Service Nodes that have a SWITCH role.
- **QIT:** Quality, represents a correlation between the alive frames transmitted and received. Expressed in %.
- **TxALV:** Alive frames transmitted.
- **RxALV:** Alive answer frames received.
- **ALV-T:** Amount of time in seconds that the system waits for an ALV answer message before assuming that the Service Node has been unregistered by the Base Node. Can take the following values: 32, 64, 128, 256, 512, 1024, 2048, 4096.
- **DISC:** Number of disconnections detected at the MAC layer level.
- **UP-TIME:** Total amount of time that the Node is in a connected state (Terminal or Switch).
- **%:** UP-TIME percentage regarding Base Node UP-TIME.
- **CNX-TIME:** Amount of time that the Node remains in a connected state (Terminal or Switch) in the current active connection. This time is 00:00:00 if the connection is not active.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

3.2.4 RESET

The RESET command performs a hardware reset of the PLC PRIME module. This means that the PLC module can be reset without having to reset the whole router.

The RESET command controls the hardware reset signal in the PLC module. This way, the PLC module can be completely disabled or restarted.

To restart the PLC module, please enter the RESET ON command followed by the RESET OFF one.

To disable the PLC module, enter the RESET ON command only.

Syntax:

```

PRIME-primeX/Y+reset ?
  off   Deactivate hardware reset
  on    Activate hardware reset

```

Example:

```

PRIME-prime0/0+reset on
Are you sure to activate HW reset to PLC(Yes/No)? Y

  PLC modem in reset state

PRIME-prime0/0+
PRIME-prime0/0+reset off

  PLC modem activated

```

```
PRIME-prime0/0+
```

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.

3.2.5 UPGRADE-FIRMWARE

The UPGRADE-FIRMWARE command is used to change the firmware version that is running in the internal PLC PRIME module. The PLC PRIME module firmware is independent of the one running on the PRIME Gateway. That is, it has two separate firmwares.

See [Upgrading PRIME Firmware](#) on page 56 for more detailed information.

Syntax:

```
PRIME-primeX/Y+upgrade-firmware [yes]
```

- optional parameter **yes** allows the device to run an operation without prompting the user to confirm first. If this parameter is set to **yes**, no such confirmation is required. If not, the device prompts the user for confirmation.

Example:

```
PRIME-prime0/0+upgrade-firmware
Upgrade file release detected: 01.03.10.02-A-M

Are you sure to upgrade the module(Yes/No)? y

Upgrade in progress
  Progress: End.....: 100%
Upgrade successful
PRIME-prime0/0+
```



Note

- There is no need for this command when the PRIME Gateway is configured in Service Node mode.

Command history:

Release	Modification
11.00.06, 11.01.02	New command added.
11.01.06	The "[yes]" option was added as of version 11.01.06

Chapter 4 Upgrading PRIME Firmware

4.1 Introduction

Given the ongoing optimization of PLC PRIME technology, upgrading the PLC module must be possible in order to offer the latest available features.

PRIME interfaces are equipped with a mechanism for PLC PRIME firmware upgrading.

Simply follow these steps:

- Obtain the upgraded software.
- Transfer the software to the device through FTP.
- Load it in the PLC PRIME module.

4.2 Procedure

4.2.1 Obtaining the upgrade

To carry out firmware upgrading, you need the loading file that matches the module that requires upgrading. Similarly, you also need information on the type and version of the installed module to determine which firmware versions are compatible.

The user may obtain firmware for various models of PLC modules, as well as the possible versions for each, from our Technical Service. Please contact our Technical Service and give them all the information on the module. This information can be found on the device monitoring console. There are several firmware versions for the PRIME module in base to device model: Base Node to support 30 Service Nodes, Base Node to support 150 Service Nodes, Base Node to support 750 Service Nodes, Base Node to support 2000 Service Nodes, Service Nodes compatible with PRIME version 1.36, compatible with PRIME version 1.4, etc.

Example:

```
+configuration

Teldat's Router, Regesta-Smart-PLC S/N: 914P/00101
SWL:BASE PLC_2000SN UART USB_INTERNAL
Profile: none
ID: Regesta-Smart-PLC

Boot ROM release:
  BIOS CODE VERSION: 01.07 Nov 25 2019 13:26:09 L0

System Info:
PCB:0x411 Regesta-Smart-PLC SYS:0x000B REV:0x2
CLKs: CPU=500 FBS1=250 FBS2=250 DDR(c1k)=250 LBUS=250
Watchdog:Enabled
Cache:ON Write-Back
Time Base: frequency = 250000 KHz period = 4.000 ns
CPU temperature: 43 C
BOARD temperature: 31 C

Software release: 11.01.08 Nov 22 2019 08:56:37
Compiled by integrator on ares.id.teldat.com
Loaded from primary partition

Hostname: Active user:
Date: Saturday, 01/01/00 Time: 02:13:57
Router uptime: 2h13m27s

Name Protocol
IP Internet Protocol
IPv6 IPv6
ARP Address Resolution Protocol
CFM Connectivity Fault Management
```

```

ASRT      Adaptive Source Routing Transparent Enhanced Bridge
DLS       Data Link Switching
dot1X     Extensible Authentication Protocol Over LAN
RIP       Route Information Protocol
OSPF      Open SPF-Based Routing Protocol
BGP       BGP
BFD       Bidirectional Forwarding Detection
NHRP      Next Hop Resolution Protocol
DHCP      Dynamic Host Configuration Protocol
L2TP      L2TP
SNMP      SNMP
IGMP      Internet Group Management Protocol
PIM       Protocol Independent Multicast
MSDP      Multicast Source Discovery Protocol
GW104     Gateway IEC 104/101
SIP       SIP
H323     H323
NOE       UA/NOE
SCCP      SCCP
RPNP      RPNP
OSPFv3    OSPFv3
DHCPv6    DHCPv6

9 interfaces:
Connector      Interface      MAC/Data-Link      Status
SFP-WAN        ethernet0/0    Ethernet/IEEE 802.3 Up
LAN            ethernet0/1    Ethernet/IEEE 802.3 Testing
PLC-PW         prime0/0       PRIME interface    Up
SERIAL1        uart1/0        AHDLc               Testing
SERIAL2        uart1/1        AHDLc               Testing
ANT1           cellular1/0    Async serial line   Down
ANT1           cellular1/1    NIC interface        Down
ANT1           cellular1/2    NIC interface        Down
---           direct-ip1     DirectIP interface   Down

SNMP OperStatus:
Interface      OperStatus
ethernet0/0    Up
ethernet0/1    Down
prime0/0       Up
uart1/0        Down
uart1/1        Down
cellular1/0    Down
cellular1/1    Down
cellular1/2    Down
direct-ip1     Lower layer down

Hardware Encryption Engine: LTQ-DEU xRX200 Family, Revision 5
Cellular Driver Version:

WLAN Driver Version: 9.5.0.35.1

```

Depending of the model, the PRIME Gateway should always have several firmwares loaded on its disk.

For example Regesta Compact PLC must include two firmwares: one for Service Node mode and one for Base Node mode. For Regesta Smart PLC must also include two firmwares: one for Base Node operation with PRIME 1.3 release and one for Base Node operation with PRIME 1.4 release.

When an upgrade process is performed, the PRIME Gateway loads the firmware according to the configured node mode or PRIME release. Therefore, before launching an upgrade process, care must be taken to ensure that the firmware to be upgraded is appropriate for the selected node mode or PRIME release.

Some license limits may cause an error in the upgrade process. For example, to upgrade the firmware of a Base Node that supports 2000 Service Nodes, the device must include the license to support 2000 Service Nodes.

Through the firmware version, you can identify the specific type to which it belongs. The last digit identifies the type of node and, in the case of a Base Node, the number of Service Nodes supported. The following examples show how the firmware versions are named:

- Firmware version for a Base Node mode supporting up to 30 Service Nodes (for Regesta Compact PLC only): 01.03.10.02-A-L

The "-L" character indicates that the firmware is for these type of Base Nodes.

- Firmware version for a Base Node mode supporting up to 150 Service Nodes (for Regesta Smart PLC only): 01.03.10.02-A-R

The "-R" character indicates that the firmware is for these type of Base Nodes.

- Firmware version for a Base Node mode supporting up to 750 Service Nodes(for Regesta Comact PLC only): 01.03.10.02-A-M

The "-M" character indicates that the firmware is for this type of Base Node. Note that this firmware version requires the PRIME Gateway to include the corresponding license.

- Firmware version for a Base Node mode supporting up to 2000 Service Nodes(for Regesta Smart PLC only): 01.03.10.04-B-F

The "-F" character indicates that the firmware is for this type of Base Node. Note that this firmware version requires the PRIME Gateway to include the corresponding license.

- Firmware version for Service Node mode: 01.03.10.02-A-S

The "-S" character indicates that the firmware is for this Service Node type.

The file containing the new module firmware has a *.BFW extension.

4.2.2 Transferring to the device

When it comes to upgrading the device software or loading firmware for internal devices, users have an FTP server they can transfer files to. This server is only accessible if the device has started up correctly (application executed).

Follow these steps to upgrade:

- (1) Load the upgrade file in a directory of the device where you are going to launch the FTP session.
- (2) To carry out upgrading, your device needs enough memory space to store the file.
For further information, please see Teldat manual .
- (3) Connect to the device's FTP server (**default is** user **root** and no password).
- (4) Configure the binary mode through the **bin** command.
- (5) Transfer the file containing the firmware using the **put myfmwr.bfw** command.
- (6) Once the transfer is complete, save the file in the system's disc using the **quote site savebuffer** command.
- (7) Once saving is complete, disconnect using the **bye** command.

```
C:\tmp> ftp 192.168.213.152
Connected to 192.168.213.152.
220 FTP server ready, 1 active clients of 4 simultaneous clients allowed.
Name (192.168.213.152): root
331 User name accepted, need password.
Password:
230 User login complete.
ftp> has
Hash mark printing on (1024 bytes/hash mark).
ftp> bin
200 TYPE is set to IMAGE.
ftp> put myfmwr.bfw
local: myfmwr.bfw remote: myfmwr.bfw
200 PORT is set to IP ADDR = 192.168.212.7 PORT = 49677
150 Data connection open, checked file transfer in process...
#####
226 STOR completed, 100352 bytes processed, data connection is closed.
100352 bytes sent in 0.06 secs (1629.3 kB/s)
ftp> quote site savebuffer
200 SAVEBUFFER completed O.K.
ftp> bye
221 Goodbye.
C:\tmp>
```

4.2.3 Upgrading the module

- (1) In order for the module to update as described in the chapter on monitoring, access the PRIME interface (**primeX/Y**) monitoring menu.
- (2) Execute the **upgrade-firmware** command to start loading. If you have not preloaded the upgrade file in the system's disc, you will receive an error message.

```
PRIME-prime0/0+upgrade-firmware
Upgrade file release detected: 01.03.10.02-A-M

Are you sure to upgrade the module(Yes/No)? y

Upgrade in progress
  Progress: End.....: 100%
  Upgrade successful
PRIME-prime0/0+
```

- (3) Wait until the process is complete. During said process, indications and messages appear to show the progress and state of the upgrading.



Note

Do not, under any circumstances, switch off or restart the device during this process.



Note

This process can take tens of seconds.

- (4) Check this is the correct version through the interface **list** command.

Example:

```
PRIME-prime0/0+list global

Node operation mode : BASE NODE
Frequency Channel   : 1
Interface State     : UP(4)
PLC firmware version : 01.03.10.04-A-F

----- PRIME INTERFACE STATISTICS -----
Bytes sent to PLC           : 53541
Bytes received from PLC    : 62097
Packets sent to PLC        : 1131
Packets received from PLC  : 2500
CRC/LRC error packets PLC  : 0
Errors or congestion detected : 0

---- PRIME MANAGEMENT COMMUNICATION ----
Status                   : UP(9)
Connection drops         : 0
Management packets received : 182
Management packets sent   : 0
Network status events received : 234
Alive status events received : 223
PLC modem resets performed : 0

PRIME-prime0/0+
PRIME-prime0/0+
PRIME-prime0/0+
PRIME-prime0/0+upgrade-firmware
Upgrade file release detected: 01.03.10.04-B-F

Are you sure to upgrade the module(Yes/No)? y

Upgrade in progress
  Progress: End.....: 100%
```

```
Upgrade successful

PRIME-prime0/0+
PRIME-prime0/0+list global

Node operation mode : BASE NODE
Frequency Channel   : 1
Interface State    : UP(4)
PLC firmware version : 01.03.10.02-B-M

----- PRIME INTERFACE STATISTICS -----
Bytes sent to PLC           : 53541
Bytes received from PLC    : 62097
Packets sent to PLC        : 1131
Packets received from PLC  : 2500
CRC/LRC error packets PLC  : 0
Errors or congestion detected : 0

---- PRIME MANAGEMENT COMMUNICATION -----
Status                     : UP(9)
Connection drops           : 0
Management packets received : 182
Management packets sent    : 0
Network status events received : 234
Alive status events received : 223
PLC modem resets performed  : 0

PRIME-prime0/0+
```

**Note**

Progress information presented on the router console can differ from that shown in this example.

Chapter 5 Examples

5.1 PRIME basic with Sniffer enabled

In this example, a basic configuration example for a PRIME Gateway associated with the Sniffer feature is shown. This example shows a configuration for devices that support the PRIME interface, as used typically in utilities.

The following configuration elements are set:

- (1) Cellular interface connection, through a "direct-ip" interface.
- (2) Ethernet connection.
- (3) IP basic routing for access through cellular interface.
- (4) The PRIME interface configuration (including configuration to access Sniffer data through an incoming TCP session, launched from an external application). The topology files sent through the FTP feature are included too.
 - Base Node Mode.
 - PLC signal enabled.
 - Configuration to access Sniffer data through an incoming TCP session, launched from an external application
 - Topology files sent through the FTP feature.
 - PHY layer extension.

```

log-command-errors
no configuration
set inactivity-timer disabled
add device direct-ip 1
set data-link at cellular1/0
set data-link nic cellular1/1
global-profiles dial
; -- Dial Profiles Configuration --
  profile OPERATOR default
  profile OPERATOR dialout
  profile OPERATOR 3gpp-apn operator.com
;
  exit
;
;
  network ethernet0/0
; -- Ethernet Interface User Configuration --
  ip address 192.168.1.123 255.255.0.0
;
;
  network prime0/0
; -- PRIME Interface Configuration --
  plc-signal enable
  sniffer local-tcp-port 3333
  sniffer control enable
  topology ftp-server-ip 1.1.1.1
  topology ftp-server-port 1234
  topology file-time 1200
  topology file-max-lines 1000
  topology file-path topology
  topology file-prefix prime
  topology ftp-cnx-user admin
  topology ftp-cnx-password hsdudx
  topology enable
  exit
;
  network cellular1/0
; -- Interface AT. Configuration --
  coverage-timer 10
  no register-denied-reset
  pin ciphered 0xC8155E104D247110
;

```

```
network mode automatic
network domain cs+ps
exit
;
;
network direct-ip1
; -- Generic Direct IP Encapsulation User Configuration --
ip address dhcp-negotiated
;
base-interface
; -- Base Interface Configuration --
base-interface cellular1/1 link
base-interface cellular1/1 profile OPERATOR
;
exit
;
direct-ip
; -- Direct IP encapsulator user configuration --
address dhcp
authentication sent-user EKCIDR ciphered-pwd 0x34CF78A8952A56D5
exit
;
exit
;
;
;
protocol ip
; -- Internet protocol user configuration --
route 0.0.0.0 0.0.0.0 direct-ip1
;
rule 1 local-ip direct-ip1 remote-ip any
rule 1 napt translation
;
no icmp-redirects
exit
;
;
;
;
;
feature ntp
; -- NTP Protocol user configuration --
protocol
peer address 1 130.206.0.1
exit
;
dump-command-errors
end
```

Chapter 6 Annex A. SNMP data formats

Several commands can be triggered using the SNMP protocol and force the Gateway to start some session transfers. This annex describes the data format for these transfers.

6.1 Sniffer format for SNMP managed TCP sessions

The PRIME Gateway may activate the sniffer protocol option through SNMP. This Sniffer data format is used for outgoing TCP sessions and for requests made through SNMP commands.

For this purpose, the following objects are available for read-write operations.

- Enable Sniffer – Integer (0 or 1)
- Enable Sniffer Optional Fields – Integer (0 or 1)
- Destination Address – IPAddress
- Destination Port – Integer32

When the PRIME Gateway receives a “1” value for the Enable Sniffer object, it activates the Sniffer option (sending every MAC PDU encapsulated in TCP to the destination address-port indicated by the corresponding objects). If the Enable Sniffer Optional Fields object is also set to 1, the information will include optional fields.

This command is compatible with an SNMP topology session, meaning both can be activated at the same time. Both share the destination Address and Port.

The protocol used to transmit the sniffed traffic is a custom simple binary protocol encoded in Big Endian. The protocol encapsulates messages that have a fixed message format. The header is shared with the Topology protocol. The basic message has the following format:

4 bytes	1 byte	"Length" byte
Length	Type	Payload

The meaning of the foregoing fields is as follows:

- **Length**: is the length of the payload. Messages are encoded sequentially and multiplexed using this length.
- **Type**: is the type of message. There are currently 3 types of messages: MAC PDU, reception and transmission, and topology.

The types of messages that can be carried now are the following:

Message Type	Identifier
MAC_TX	0
MAC_RX	1
TOPOLOGY	2

For MAC_TX and MAC_RX messages, the payload will have the following format:

4 bytes	5 bytes	2 bytes	2 byte	Length	--
Time Counter	Date and Time	PHY INFO	Length	PDU	Optional Fields

- **Time Counter**: is a time counter of 10 microseconds that overflows every 12 hours approximately.
- **Date and Time**: number of seconds since 00:00 (midnight) 1 January, 1970 GMT.
- **PHY Info**:

Bits	Type	Description
15	Optional Fields	1 if optional fields are present, 0 otherwise
14	Interface	1 if PLC, 0 other. If 0, SNR, Power and Encoding are not valid
10-13	Reserved	

7-9	Encoding	PDU encoding: 0: D8PSK 1: DQPSK 2: D8PSK 4: DBPSK_CC 5: DQPSK_CC 6: D8PSK_CC
4-6	SNR	Signal to Noise ratio in which this message was received (only reception) as defined in the PRIME standard: 0: # 0 dB 1: # 3 dB 2: # 6 dB 3: # 9 dB 4: # 12 dB 5: # 15 dB 6: # 18 dB 7: > 18 dB
0-3	Power	For RX: Reception power in which this message was received (only reception) as defined in PRIME: 0: # 70 dBuV 1: # 72 dBuV 2: # 74 dBuV 15: > 98 dBuV For TX: 0: Maximal output level (MOL) 1: MOL -3 dB 2: MOL -6 dB 7: MOL -21 dB

- **Length:** the length of the PDU payload.
- **PDU:** the MAC PDU buffer.
- **Optional fields:** optional information for each MAC PDU. This field can contain several fields with the following format.

1 byte	1 byte	Field length
FIELD ID	FIELD LENGTH	DATA

The following are some pre-defined optional fields:

Field ID	Length	Type	Description
0	4	PHY Rx details	Signal to Noise ratio in which this message was received

			in 0.1 dB steps. Reception power in which this message was received (only reception) in 0.1 dBuV steps
1	*	IFACE	Text representation of the interface through which this message was received/transmitted: e.g: plc1, plc3
2	6	EUI-48	MAC Address of the Service Node used for PDU transmission (if uplink) and destination (if downlink).
3	4	Duration	The duration of the PDU in 10s of microseconds.
255	*	Vendor Specific	Content of this field is vendor specific. The first two bytes in data shall contain the AppVendorId. Vendors should follow a similar field structure (entering the Field Id, Length and Data inside the Vendor Specific field).

6.2 Topology format for SNMP managed TCP sessions

The PRIME Gateway may activate a topology protocol option through SNMP. This topology data format is used for outgoing TCP sessions and for requests made through SNMP commands.

For this purpose, the following objects are available for read/write operations.

- Enable Topology – Integer (0 or 1)
- Destination Address – IPAddress
- Destination Port – Integer32

When the PRIME Gateway receives a “1” value for the Enable Topology object, it activates the topology option sending every topology change encapsulated in TCP to the destination-address port indicated by the corresponding objects.

This command is compatible with an SNMP Sniffer protocol session, meaning both can be activated at same time. Both share the destination Address and Port.

The protocol used to transmit the sniffed traffic is a custom simple binary protocol encoded in Big Endian. The protocol encapsulates messages that have a fixed message format. The header is shared with the Sniffer protocol. The basic message has the following format:

4 bytes	1 byte	"Length" byte
Length	Type	Payload

The meaning of the foregoing fields is as follows:

- **Length**: is the length of the payload. Messages are encoded sequentially and multiplexed using this length.
- **Type**: is the type of message. There are currently 3 types of messages: MAC PDU, reception and transmission, and topology.

The types of messages that can be carried now are the following:

Message Type	Identifier
MAC_TX	0
MAC_RX	1
TOPOLOGY	2

For TOPOLOGY messages, the payload will have the following format:

4 bytes	5 bytes	6 bytes	1 byte	2 bytes	1 byte	1 byte
Time Counter	Date and Time	EUI-48	SID	LNID	STATE	SSID

- **Time Counter:** is a time counter of 10 microseconds that overflows approximately every 12 hours.
- **Date and Time:** number of seconds since 00:00 (midnight) 1 January, 1970 GMT.
- **EUI-48:** MAC Address of the Service Node.
- **SID:** Switch Identifier of the parent. 0 if directly connected to the Base Node.
- **LNID:** LNID of the Service Node.
- **STATE :** State of the Service Node as defined in the PRIME Specification:
 - 0: Disconnected
 - 1: Terminal
 - 2: Switch
 - 3: Base
- **SSID:** Switch Identifier if the Service Node is in Switch mode.

Chapter 7 Annex B. Topology file

The PRIME Gateway can collect, in real time, topological data belonging to the PRIME network associated with the Base Node. This information is stored in files that can be sent to a server via FTP. These files contain the changes in state of the Service Nodes that are part of the PLC network.

This annex shows the format used to store topological events in the file.

7.1 File format

The topology event file is made up of a text file that includes several fields separated by semicolons.

The following fields shall be listed in order:

- (a) Date and Time: **yyyy/mm/dd hh:mm:ss** (note there is a blank space between date and time)
- (b) Semicolon
- (c) MAC address of Service Node
- (d) Semicolon
- (e) MAC address of Father Node (Switch or Base Node)
- (f) Semicolon
- (g) State of Service Node (disconnected, terminal or switch)
- (h) Semicolon
- (i) Connection quality (i.e., the percentage of success in keeping *alive* messages for the Service Node).
- (j) Semicolon
- (k) MAC address of the Base Node to which the Service Node is connected.

The following is an example of a topology file:

```
2013/02/05 10:28:56;40:40:22:29:14:73;40:40:22:01:9f:f0;disconnected;0;40:40:22:01:9f:f0
2013/02/05 10:28:58;40:40:22:29:14:73;40:40:22:01:9f:f0;terminal;0;40:40:22:01:9f:f0
2013/02/05 10:28:59;40:40:22:29:14:97;40:40:22:01:9f:f0;disconnected;0;40:40:22:01:9f:f0
2013/02/05 10:28:59;40:40:22:29:14:97;40:40:22:01:9f:f0;terminal;0;40:40:22:01:9f:f0
2013/02/05 10:28:59;40:40:22:3a:87:2d;40:40:22:01:9f:f0;disconnected;0;40:40:22:01:9f:f0
2013/02/05 10:28:59;40:40:22:3a:87:2d;40:40:22:01:9f:f0;terminal;0;40:40:22:01:9f:f0
2013/02/05 10:29:00;40:40:22:3a:8b:ed;40:40:22:01:9f:f0;disconnected;0;40:40:22:01:9f:f0
2013/02/05 10:29:00;40:40:22:3a:8b:ed;40:40:22:01:9f:f0;terminal;0;40:40:22:01:9f:f0
2013/02/05 10:29:14;40:40:22:29:14:73;40:40:22:01:9f:f0;switch;98;40:40:22:01:9f:f0
2013/02/05 10:29:15;40:40:22:29:14:97;40:40:22:01:9f:f0;terminal;98;40:40:22:01:9f:f0
2013/02/05 10:29:15;40:40:22:3a:87:2d;40:40:22:01:9f:f0;terminal;98;40:40:22:01:9f:f0
2013/02/05 10:29:16;40:40:22:3a:8b:ed;40:40:22:01:9f:f0;terminal;98;40:40:22:01:9f:f0
2013/02/05 10:29:30;40:40:22:29:14:73;40:40:22:01:9f:f0;terminal;100;40:40:22:01:9f:f0
2013/02/05 10:29:31;40:40:22:29:14:97;40:40:22:01:9f:f0;terminal;100;40:40:22:01:9f:f0
2013/02/05 10:29:32;40:40:22:3a:8b:ed;40:40:22:01:9f:f0;terminal;100;40:40:22:01:9f:f0
2013/02/05 10:29:51;40:40:22:3a:87:2d;40:40:22:01:9f:f0; switch;75;40:40:22:01:9f:f0
2013/02/05 10:30:02;40:40:22:29:14:73;40:40:22:01:9f:f0;terminal;99;40:40:22:01:9f:f0
2013/02/05 10:30:03;40:40:22:29:14:97; 40:40:22:3a:87:2d;terminal;99;40:40:22:01:9f:f0
2013/02/05 10:30:04;40:40:22:3a:8b:ed;40:40:22:01:9f:f0;terminal;99;40:40:22:01:9f:f0
```