

Release Notes

9.1.9

Copyright© Version 1.0, 2014 bintec elmeg GmbH

Legal Notice

Aim and purpose

This document is part of the user manual for the installation and configuration of bintec elmeg devices. For the latest information and notes on the current software release, please also read our release notes, particularly if you are updating your software to a higher release version. You will find the latest release notes under www.bintec-elmeg.com.

Liability

This manual has been put together with the greatest possible care. However, the information contained in this manual is not a guarantee of the properties of your product. bintec elmeg GmbH is only liable within the terms of its conditions of sale and supply and accepts no liability for technical inaccuracies and/or omissions.

The information in this manual can be changed without notice. You will find additional information and also release notes for bintec elmeg devices under www.bintec-elmeg.com.

bintec elmeg devices make WAN connections as a possible function of the system configuration. You must monitor the product in order to avoid unwanted charges. bintec elmeg GmbH accepts no responsibility for data loss, unwanted connection costs and damage caused by unintended operation of the product.

Trademarks

bintec elmeg trademarks and the bintec elmeg logo, bintec trademarks and the bintec logo, elmeg trademarks and the elmeg logo are registered trademarks of bintec elmeg GmbH.

Company and product names mentioned are usually trademarks of the companies or manufacturers concerned.

Copyright

All rights reserved. No part of this manual may be reproduced or further processed in any way without the written consent of bintec elmeg GmbH. The documentation may not be processed and, in particular, translated without the consent of bintec elmeg GmbH.

You will find information on guidelines and standards in the declarations of conformity under www.bintec-elmeg.com.

How to reach bintec elmeg GmbH

bintec elmeg GmbH, Südwestpark 94, D-90449 Nuremberg, Germany, Phone: +49 911 9673 0, Fax: +49 911 688 07 25

Teldat France S.A.S., 6/8 Avenue de la Grande Lande, F-33174 Gradignan, France, Phone: +33 5 57 35 63 00, Fax: +33 5 56 89 14 05

Internet: www.teldat.fr

Table of Contents

Chapter 1	Important Information	1
1.1	Preparation and update with the GUI	1
1.2	Downgrade with the GUI.	2
1.3	Supported web browsers	2
Chapter 2	New Functions	4
2.1	Available languages.	4
2.2	W1001n	5
2.3	New UMTS Stick supported	5
2.4	New LTE sticks supported	5
2.5	Display optimised for smartphone displays	5
2.6	Hardware - New LED mode available	5
2.7	Internet Assistant - New Internet Service Provider.	6
2.8	Roaming mode expanded	6
2.9	SIM data displayed	6
2.10	Extended switching contact	6
2.11	Provisioning of keys on IP1x0	7
2.12	IGMP Snooping	7
2.13	WLAN bandwidth management.	7
2.14	WLAN client mode available	7
2.15	WLAN Controller Monitoring	8
2.16	DHCP options for bintec 4Ge LE	8
2.17	Function Button (RS353 series).	8

2.18	Secure E-mails	8
Chapter 3	Changes	9
3.1	Improved login behaviour	9
3.2	UMTS/LTE adjusted	9
3.3	hybird - Parameter display language removed	9
3.4	hybird - length of the SIP provider password adjusted	9
3.5	WLAN - increased number of wireless networks	10
3.6	Routes - List sorted	10
3.7	IPSec - sorting of peer modified	10
Chapter 4	Bug Fixes	11
4.1	Sporadic Reboot (RXL Series)	11
4.2	No online help available	11
4.3	Page with Internet Explorer 8 faulty	11
4.4	ISDN - problems with B-channel	12
4.5	SIM Card - Incorrect status display for Providers	12
4.6	LTE - No connection	12
4.7	UMTS / LTE - parameters Fallback number in wrong format	12
4.8	UMTS - modem problems	13
4.9	UMTS - Stick did not work (RS Series)	13
4.10	UMTS / LTE - router not working	13
4.11	UMTS / LTE - Incorrect display of the modem name	13
4.12	UMTS / LTE - Incorrect message	13
4.13	UMTS - GSM used in error	14

4.14	GSM - ISDN login not working	14
4.15	Modem problems	14
4.16	Wizard Getting Started - IP address	14
4.17	Wizard Getting Started - Settings incompletely displayed.	15
4.18	Assistant VoIP PBX in the LAN - IP address Delete faulty	15
4.19	IP - No communication possible	15
4.20	Access Profiles - display incorrectly	15
4.21	Telephony - caller transfer faulty	16
4.22	Telephony - Multiple stack traces	16
4.23	Telephony - update not possible CS290 / CS290U	16
4.24	Server dialer not working correctly	16
4.25	WLAN - MIC failure handled incorrectly	17
4.26	WLAN - communication problems.	17
4.27	WLAN - Calculation of octets incorrect.	17
4.28	WLAN - No beacon packets sent	17
4.29	WLAN - scheduling problems.	17
4.30	WLAN - wireless bridge link error displayed	18
4.31	WLAN - wireless bridge link faulty.	18
4.32	WLAN Client faulty	18
4.33	Wireless LAN Controller - error displayed	18
4.34	Wireless LAN Controller - Different number of active clients	19
4.35	Wireless LAN Controller - Incorrect display of WLAN client.	19
4.36	Wireless LAN Controller - Management faulty	19
4.37	NAT - Incorrect entry	19

4.38	QoS - Repeated sporadic panics	20
4.39	QoS - icon missing	20
4.40	Network - entries cannot be deleted	20
4.41	IPSec - Invalid configuration stored	20
4.42	IPSec - CIDR notation not suitable for network mask	21
4.43	IPSec - Incorrect use of default route	21
4.44	IPSec - Incorrect use of loopback address	21
4.45	DNS - Misleading error message	21
4.46	DNS - Entries not displayed optimally	22
4.47	DHCP - Incorrect IP addresses used	22
4.48	DHCP - address assignment incorrect.	22
4.49	DHCP - Server did not respond.	22
4.50	Hotspot - Panic.	22
4.51	Hotspot - problems with RADIUS	23
4.52	Hotel function - call data cannot be displayed.	23
4.53	Update - No Reboot possible	23
4.54	Setup Tool - DSL modem cannot be switched off	23
4.55	Setup Tool - Fixed connection not working	23
4.56	Setup Tool - Load Balancing not working correctly	24
4.57	Setup Tool - Incorrect values displayed	24
4.58	Setup Tool - extended route cannot be configured	24
Appendix A	Extendend Information	25
A.1	From Release Notes 9.1.7	25

A.1.1	Hardware: New LED mode available	25
A.2	From Release Notes 9.1.8	26
A.2.1	Support for the provisioning of IP 1x0 function keys	26
A.3	From Release Notes 9.1.9	32
A.3.1	WLAN Bandwidth Control	32
A.3.2	WLAN Controller Monitoring	32
A.3.3	DHCP Options for bintec 4Ge-LE	38
	Index	40

Chapter 1 Important Information

1.1 Preparation and update with the GUI

Updating the system software with the Graphical User Interface (GUI) is done using a BLUP (bintec Large Update) file so as to update all the necessary modules intelligently. All those elements that are newer in the BLUP than on your gateway are updated.



Note

The result of an interrupted updating operation could be that your gateway no longer boots. Hence, do not turn your gateway off during the update.

To prepare and carry out any update to **System Software 9.1.10** using the Graphical User Interface, proceed as follows:

- (1) For the update, you'll need the file `XXXXX_b19110.xxx` where `XXXXX` stands for you device. Ensure that the file that you require for the update is available on your PC. If the file is not available on your PC, enter www.bintec-elmeg.com in your browser. The bintec-elmeg-homepage will open. You will find the required file in the download area for your gateway. Save it on your PC.
- (2) Backup the current boot configuration before updating. Export the current boot configuration using the menu **Maintenance->Software & Configuration** in the Graphical User Interface. To do this, select: **Action** = *Export configuration*, **Current File Name in Flash** = *boot*, **Include certificates and keys** = *activated*, **Configuration Encryption** = *disabled*. Confirm with **Go**. The **Open <name of gateway>.cf** window opens. Leave the selection *Save file* and click **OK** to save the configuration to your PC. The file `<name of gateway>.cf` is saved and the **Downloads** window shows the saved file.
- (3) Update to **System Software 9.1.10** via the **Maintenance->Software & Configuration** menu. To do this, select: **Action** = *Update system software*, **Source Location** = *Local File*, **Filename** = `XXXXX_b19110.xxx`. Confirm with **Go**. The message "System request. Please stand by. Operation in progress." or "System Maintenance. Please stand by. Operation in progress." shows that the selected file is being uploaded to the device. When the upload procedure is finished, you will see the message "System - Maintenance. Success. Operation completed successfully". Click on **Reboot**. You will see the message "System - Reboot. Rebooting. Please wait. This takes approximately 40 seconds". The device will start with the new system software, and the browser window will open.

1.2 Downgrade with the GUI

If you wish to carry out a downgrade, proceed as follows:

- (1) Replace the current boot configuration with the previous backup version. Import the saved boot configuration via the **Maintenance->Software & Configuration** menu. To do this, select: **Action** = *Import configuration*, **Configuration Encryption** = *disabled*, **Filename** = *<name of device>.cf*. Confirm with **Go**. The message "System request. Please stand by. Operation in progress." or "System Maintenance. Please stand by. Operation in progress." indicates that the selected configuration is being uploaded to the device. When the upload procedure is finished, you will see the message "System - Maintenance. Success. Operation completed successfully." Click on **Reboot**. You will see the message "System - Reboot. Rebooting. Please wait. This takes approximately 40 seconds." The device will start and the browser window will open. Log into your device.
- (2) Downgrade to the desired software version using the **Maintenance->Software & Configuration** menu.
To do this, select: **Action** = *Update system software*, **Source Location** = *Local File*, **Filename** = *RXL_Series_b19109.biq* (example). Confirm with **Go**. The message "System request. Please stand by. Operation in progress." or "System Maintenance. Please stand by. Operation in progress." shows that the selected file is being uploaded to the device. When the upload procedure is finished, you will see the message "System - Maintenance. Success. Operation completed successfully" . Click on **Reboot**. You will see the message "System - Reboot. Rebooting. Please wait. This takes approximately 40 seconds." The device will start with the new system software, and the browser window will open.

You can log into your device and configure it.

1.3 Supported web browsers

The HTML GUI supports the use of the following browsers, each in their latest version:

- Microsoft Internet Explorer
- Mozilla Firefox
-

**Important**

Ensure that you keep your browser updated to the latest version, since you need to do so to take advantage of new functions and security features. The HTML GUI does not support versions that are no longer supported by the manufacturer and supplied with software updates. If necessary, go to the software manufacturer's website to find out which versions they currently support.

Chapter 2 New Functions

System Software 9.1.10 includes a number of new functions that significantly improve performance compared with the previous version of the system software.



Note

Please note that not all the functions listed here are available for every device. Please refer, if necessary, to the current data sheet for your device or to the relevant manual.



Note

Please note that there may be a new feature for different device was introduced at different times.

2.1 Available languages

With **System Software 9.1.10** the GUI and the announcements of the voicemail box are prepared for other languages. In future, the languages German, English, Italian, Spanish, French, Portuguese and Dutch will be available.

The online help is scheduled in the languages German, English, Spanish, French and Portuguese.

The languages German and English are selectable as default in the GUI, other languages are made available on our Web sites www.bintec-elmeg.com in the download area of your device. You can download it via the GUI onto the device. Information on this can be found in your device manual.



Note

Note that each device can be operated with two languages simultaneously.

If you want to replace one of the two languages previously used by another language, please note the following:

The user of the language that is no longer to be used in the future must log out. His session must be completed and expired. Then, that user or another user can log in

and choose the desired language, if it is loaded.

2.2 W1001n

The device W1001n is supported by **System Software 9.1.10** for the first time.

2.3 New UMTS Stick supported

With **System Software 9.1.10** the UMTS-Stick ZTE MF680 is supported.

2.4 New LTE sticks supported

With **System Software 9.1.10** the sticks Telekom LTE Speed Stick III (Huawei E3276) and Alcatel L100 LTE are supported.

2.5 Display optimised for smartphone displays

The GUI has been optimised for viewing on smartphones. At low resolution, the header and the menu tree are hidden and can be displayed via the corresponding buttons with the bintec-elmeg logo.

2.6 Hardware - New LED mode available

With **System Software 9.1.10** a new LED mode is available on devices with an integrated UMTS or LTE modem.


If you want to put a device into this mode, you can see from the LEDs which wireless standard is currently in use and which signal quality is available for the wireless network. For wireless connections with an external UMTS or LTE stick the function is not available.

Detailed information can be found in the Release Notes 9.1.7 of the devices of the RS Series. The corresponding section of these Release Notes can be found in annex [From Release Notes 9.1.7](#) on page 25.

2.7 Internet Assistant - New Internet Service Provider

In the wizard **Internet Access** under **New** in the second window with the settings **Type** = *Predefined* and **Country** = *Germany* under **Internet Service Provider** the two new choices *Telekom Business* and *Telekom Business - VDSL* are made available.

2.8 Roaming mode expanded

In the menu **Physical Interfaces->UMTS/LTE->UMTS/LTE->****->Advanced Settings** the **Roaming Mode** *Unlimited* is available again.



This mode ensures optimal connectivity. It is intended for special requirements.




Note

Note that in this mode, a scan is performed on all APNs first.

2.9 SIM data displayed

The roaming data of the SIM card are read from **System Software 9.1.10** and displayed in the menu **Physical Interfaces->UMTS/LTE->UMTS/LTE->**. A **Mobile Network Provider** may possibly also be entered manually in the menu **Physical Interfaces->UMTS/LTE->UMTS/LTE->** over the field **Mobile Network Provider**. This requires you to select in the field **Roaming Mode** *Fixed Operator* and in the field **Mobile Network Provider** *Manual Selection*.

2.10 Extended switching contact

With **System Software 9.1.10** you are able to restrict the authorisation on the configuration of the switch contacts with the help of the authorisation categories. To do this, use in the menu **Numbering->User Settings->Class of Services->****->Applications** the field **Access to relay contact(s)**. Within an authorisation category, you can enable or prohibit the permission to configure a relay for each contact individually.

In the menu **Physical Interfaces->Relay->Relay Configuration** you can switch on the relay under Contact in the field **Function** via indicators for a given period with *indicators (only period)* (e.g. a door opener is on for three seconds) or the switch the relay via indicators with *indicators (only switch over)*.

2.11 Provisioning of keys on IP1x0

From **System Software 9.1.10** the transfer of the function button configuration to the devices of the IP1x0 Series for automatic provisioning is available.

Detailed information can be found in the Release Notes 9.1.8 of the devices of the hybrid Series. The corresponding section of these Release Notes can be found in annex [From Release Notes 9.1.8](#) on page 26.

2.12 IGMP Snooping

With **System Software 9.1.10** IGMP snooping is supported.

In the menu **Wireless LAN->WLAN->Wireless Networks (VSS)->New->Advanced Settings** you can **enable or disable IGMP snooping** . By default, IGMP snooping is disabled.

IGMP snooping reduces the data traffic and thus the network load, as Multicast packets from the LAN are not forwarded. Only those Multicast packets will be forwarded that are requested by the respective clients. When you enable IGMP snooping, IGMP snooping, therefore, provides the framework in which Multicast is applied.

2.13 WLAN bandwidth management

In WLAN connections, the assignment may be limited by individual clients.

For more information on WLAN bandwidth management, see the Release Notes 9.1.9 for the WLAN devices of the new generation (W1003n, W2003n, W2004n-ext). The corresponding section of these Release Notes can be found in annex [From Release Notes 9.1.9](#) on page 32. The function is now also available for other WLAN-enabled devices as well as in the Wireless LAN Controller.

2.14 WLAN client mode available

With **System Software 9.1.10** the WLAN Client Mode is available for WLAN enabled devices of the RS Series and for RV120w.

2.15 WLAN Controller Monitoring

Monitoring of the Wireless LAN Controller has been significantly expanded by a graphic display, including the utilisation of the Controller and the assignment by clients and their traffic.

For more information, see the Release Notes 9.1.9 for the WLAN devices of the new generation (W1003n, W2003n, W2004n-ext) and the RXL Series. The corresponding section of these Release Notes can be found in annex [From Release Notes 9.1.9](#) on page 32. The function is now available for all devices that support the Wireless LAN Controller.

2.16 DHCP options for bintec 4Ge LE

For the operation of a bintec 4Ge LE in a bintec device, the transfer of certain DHCP options is necessary. These can now be set during configuration of the DHCP server via the GUI.

For more information, see the Release Notes 9.1.9 for the WLAN devices of the new generation (W1003n, W2003n, W2004n-ext) and the RXL Series. The corresponding section of these Release Notes can be found in annex [From Release Notes 9.1.9](#) on page 32 under [DHCP Options for bintec 4Ge-LE](#) on page 38 .

2.17 Function Button (RS353 series)

Using the Function Button on the case of an RS353 Series device, you can trigger a Scheduler event. To do so, press this Function Button for one second.

In the menu **Local Services->Scheduling->Trigger->New** you set with **Event Type = *Function Button*** that an event on the Function Button is to be triggered.

The field **Status of the function button** indicates what state the button is in before an event is triggered.

2.18 Secure E-mails

With **System Software 9.1.10** the encryption of e-mails (SSL / TLS) is available and enabled by default. In the menu **External Reporting->Alert Service->Alert Settings** the field **SMTP Port** is preset to *25* and **SSL Encryption** is enabled.

Chapter 3 Changes

The following changes have been made in **System Software 9.1.10** :



Note

Please note that there may be a change for different device was placed at different times available.

3.1 Improved login behaviour

The login behaviour after a warm restart has been improved for several USB sticks.

3.2 UMTS/LTE adjusted

With **System Software 9.1.10** the wizard for internet access sets at **Connection Type** = *UMTS / LTE* in the MIB table **mobileSimCfgTable** the MIB variables **Dispatch** in each case to *none* and the MIB variable **Access Mode** to *umts_pref* for a UMTS modem, as well as to *lte_pref* for an LTE modem.

3.3 hybrid - Parameter display language removed

In the menu **System Management->Global Settings->System** the field **Display Language** was removed. The corresponding setting is now performed with the respective configuration of the telephone via the field **Display Language** in the menu **Terminals->elmeg System Phones->System Phone->Settings** or **Terminals->elmeg System Phones->elmeg IP1x->Settings**

3.4 hybrid - length of the SIP provider password adjusted

In the menu **VoIP->Settings->SIP Provider->New a Password** maximum of 64 characters can be entered in the field. (So far, 32 characters were possible.)

3.5 WLAN - increased number of wireless networks

In all bintec elmeg devices equipped with WLAN, the number of configurable Wireless Networks (VSS) has been increased from 8 to 16.

3.6 Routes - List sorted

With **System Software 9.1.10** in the menu **Network->Routes->IPv4 Route Configuration** in the field **Layer 4 Protocol** the list is in alphabetical order.

3.7 IPSec - sorting of peer modified

With **System Software 9.1.10** in the menu **VPN->IPSec->IPSec Peers** the peers are displayed as sorted by priority.

Chapter 4 Bug Fixes

The following bugs have been fixed in **System Software 9.1.10** :



Note

Please note that a bug fix for different device may have been made available at different times.

4.1 Sporadic Reboot (RXL Series)

ID 18468, 18204

In a scenario with two RXL 12500 as BRRP Master / Slave sporadic reboots occurred on both devices.

4.2 No online help available

ID 18446

With the Google Chrome browser, no online help could be called in the GUI for the SNMP browser.

4.3 Page with Internet Explorer 8 faulty

ID 18692

With Internet Explorer 8, in the **System Management->Configuration Access->Access Profiles-> menu New** the page was not displayed correctly, the site could only be used once, the configuration of the site was also faulty.

4.4 ISDN - problems with B-channel

ID 18643

It could happen that only three connections were available for outgoing calls for a device with two BRI interfaces, because a B-channel was reserved, when connecting to a number that had sent an ALERT package with CCNR, regardless of whether the connection was established or not.

4.5 SIM Card - Incorrect status display for Providers

ID 18395

It could happen that the status of some providers on a SIM card was displayed as "forbidden" although the card was not locked.

4.6 LTE - No connection

ID 18554

With a special APN and using a Closed User Group, it was not possible to establish an LTE connection.

4.7 UMTS / LTE - parameters Fallback number in wrong format

ID 18631, 18732

In the menu **Physical Interfaces->UMTS/LTE->UMTS/LTE->** in the field **Fallback Number** and the menu **System Management->Global Settings->System** in the fields of **International Prefix / Country Code** and **National Prefix / City Code** not only numbers but any characters could be entered.

4.8 UMTS - modem problems

18561

Several problems occurred with the Sierra Wireless MC8700 modem: After a few days, the router could no longer find a mobile network and the registration failed. It could occur that the device went in an endless loop during a reboot.

4.9 UMTS - Stick did not work (RS Series)

ID 18333

The UMTS Stick HUAWEI E3131s-2 did not work in the RS Series devices.


4.10 UMTS / LTE - router not working

ID 18803

During initialisation of the modem MC7710, the router ceased the operation.

4.11 UMTS / LTE - Incorrect display of the modem name

ID 18558

It could happen that the menu **Physical Interfaces->UMTS/LTE->UMTS/LTE->** displayed another **Modem Model** than the set one. The name of the network operator was not displayed.

4.12 UMTS / LTE - Incorrect message

18601

If in the menu **Physical Interfaces->UMTS/LTE->UMTS/LTE->**->**Advanced Settings**

with **Roaming Mode** = *Fixed Operator* and **Mobile Network Provider** = *Manual Selection* in the field **Mobile Network Provider** more than the maximum allowed six characters were entered, an incorrect error message was displayed.

4.13 UMTS - GSM used in error

ID 18485

With the setting **Preferred Network Type** = *UMTS preferred* GSM was used, even if UMTS was available.

4.14 GSM - ISDN login not working

ID 18705

ISDN Login with V.110 and 9600 bit/s did not work for incoming wireless connections via GSM. No login prompt displayed.

4.15 Modem problems

ID n/a

It could happen that the Sierra Wireless MC7710 module could no longer log in. A preferred network operator was neither configured nor could a network operator be excluded.

The login into foreign networks has been improved.

4.16 Wizard Getting Started - IP address

ID 18594

In the menu **Assistants->First steps->Basic Settings** in the field **IP Address** entered values were not checked for their plausibility. It could happen that an incorrect default route was created.

4.17 Wizard Getting Started - Settings incompletely

displayed

ID n/a

In the menu **Assistants->Internet Access->Internet Connections** the username for Business T-Online settings in the field **Login Name** was not fully visible, as only 30 characters could be displayed in this field. The maximum number of displayable characters was increased to 50.

4.18 Assistant VoIP PBX in the LAN - IP address Delete faulty

ID 18553

Under certain circumstances, it could happen that, when deleting an IP address in the menu **Assistants->VoIP PBX in LAN->VoIP PBX in LAN->New**, more IP addresses and other parameters were deleted in this menu.


4.19 IP - No communication possible

ID 18411

If in the menu **System Management->Interface Mode / Bridge Groups** for the interface *en1-0* a new bridge group was created, IP communication was no longer possible.

4.20 Access Profiles - display incorrectly

ID 18535

If in the menu **System Management->Configuration Access->Access Profiles-> New** a description was entered under **Navigation Entries** the setting **Monitoring** = *Allow All* was chosen and **OK** was clicked, after the recall of the entry with  under **Navigation Entries** the field **Monitoring** and the subordinate field **QoS** were displayed each marked with a yellow check mark and not a green check mark.

4.21 Telephony - caller transfer faulty

ID 18743

For outgoing external calls from elmeg IP1x- or elmeg DECT devices, the TAPI driver of hybrid added the sign # to the phone number. For database connections via TAPI, the number could therefore not be evaluated in some cases.

4.22 Telephony - Multiple stack traces

ID 18556

It could happen that a configured IP140, that was no longer connected to a hybrid, caused several stack traces without rebooting.

4.23 Telephony - update not possible CS290 / CS290U

ID 18716

A firmware update of the elmeg CS290 or CS290-U elmeg telephones via hybrid as external update server was not possible.

A firmware update of the other system telephones was possible.

4.24 Server dialer not working correctly

ID 18822

It was not possible to configure e.g. a hybrid with the Service Dialer tool. The tool failed to configure several menus, such as **Call Routing->Automatic Route Selection->General** , **Call Routing->Automatic Route Selection->Interfaces / Provider->New** or **Call Routing->Automatic Route Selection->Zones &Routing->New**. A script error was issued.

4.25 WLAN - MIC failure handled incorrectly

ID n/a

MIC error had no effect on a bintec elmeg Access Point, i.e. they were processed in a manner not compliant with WLAN. According to Wi-Fi specification, an Access Point should reject all authentication trials for a minute after two occurrences of an MIC error.

4.26 WLAN - communication problems

ID 18409

With the new generation of WLAN devices, problems with Intra-cell Repeating and roaming could occur.

4.27 WLAN - Calculation of octets incorrect

ID n/a

If A-MPDU frames were sent, the sum of the calculated octet was incorrect.

4.28 WLAN - No beacon packets sent

ID n/a

If five to seven wireless networks were configured per radio module, some wireless networks sent no Beacon packets.

4.29 WLAN - scheduling problems

ID 18638

If in the menu **Wireless LAN->WLAN->Radio SettingsWLAN: Operation Mode** = *Access-Point / Bridge Link Master* and **Operation Band** = *5 GHz In / Outdoor* was set and in the menu **Local Services->Scheduling->Actions** the **Command Type** *5*

GHz *WLAN Bandscan* was used, the radio module switched off.

4.30 WLAN - wireless bridge link error displayed

ID 18791

TCP packets sent over a wireless bridge link generated the error message "DEBUG / WLAN: 7500000: wlib_wblmaster_update_tx_stats - Station (...) not found".

4.31 WLAN - wireless bridge link faulty

ID 18773

A Bridge Link Client did not connect with the Master again, if the MIB variable **Txpower** of the module in the MIB table **wlanIfTable** was changed.

4.32 WLAN Client faulty

18775

If a device of the new WLAN series was operated as a WLAN client and the corresponding interface was set either with *ifconfig* to *down* or the corresponding entry in the MIB table **wlanClientTable** was deleted, the MIB variable **Opera State** in the MIB table **wlanIfTable** was not set to *false* .

4.33 Wireless LAN Controller - error displayed

ID 18805

After upgrading to Release 9.1.9 Patch 1, when selecting the menu **Wireless LAN Controller->Monitoring->WLAN Controller**, the GUI was closed, the error message "Wrong content in ajaxBodySuccess() ..." and then the login screen were displayed.

4.34 Wireless LAN Controller - Different number of active clients

ID 18736

In the menu **Wireless LAN Controller->Monitoring->Active Clients** and the menu **Wireless LAN Controller->Monitoring->Client Management**, the numbers of active clients differed from each other.

4.35 Wireless LAN Controller - Incorrect display of WLAN client

18813

The graphical display of a WLAN client was deleted in every roaming process.

4.36 Wireless LAN Controller - Management faulty

ID 18453

If on a device of the new WLAN generation the Wizard **Wireless LAN** was used so that the Wireless LAN Controller would take over the Management of its own radio module, and in the menu **System Management->Global Settings->System** the field **LED mode = Off** was set, the Wireless LAN Controller Module removed its radio module from the Management and all other radio modules were disabled.

4.37 NAT - Incorrect entry

ID 18814

In the menu **Network->NAT->NAT Configuration->New**, for outgoing traffic and symmetric NAT method, the input port field in the MIB table **ipNatOutTable** was incorrectly stored.

4.38 QoS - Repeated sporadic panics

ID 18451

It could happen that, sporadically but repeatedly, a Panic occurred when the QoS configuration was modified during operation or when changing the interface status.

4.39 QoS - icon missing

ID 18686

In the menu **Network->QoS->QoS Classification** the icon to move an item was missing in the list of existing entries.

4.40 Network - entries cannot be deleted

ID 18815

In the menu **Network->Access Rules->Interface Assignment** no entries could be deleted.

4.41 IPSec - Invalid configuration stored

ID 18690

In the menu **VPN->IPSec->IPSec Peers->New** a **Peer Address** and a **Peer ID** could be entered, under **Advanced Settings, Number of Admitted Connections = *Multiple Users*** could be set and the configuration could be saved with **OK**, even though - as described in the help text - when configuring a dynamic peer, no **Peer Address** and no **Peer ID** must be specified.

4.42 IPSec - CIDR notation not suitable for network mask

ID 18531, 18490

In the menu **VPN->IPSec->IPSec Peers->New** under **Additional Traffic Filter** and the menu **Network->Load Balancing->Special Session Handling->New** under **Source IP Address/Netmask = Network** the net mask could not be entered in CIDR notation (eg. /24).

4.43 IPSec - Incorrect use of default route

ID 18509

If in the menu **VPN->IPSec->IPSec Peers->New** under **Route Entries** no netmask or `0.0.0.0` was entered as a network mask, the default route was activated without notice.

4.44 IPSec - Incorrect use of loopback address

ID 18399

The loopback address `127.0.0.1` was used in some cases as a source IP address for IKE.

4.45 DNS - Misleading error message

ID 18467

If in the menu **Local Services->DNS->Static Hosts->New** for example **DNS Hostname = test.test.de** and **IP Address = 1.0.127.127** were set, the error message "Input error; Please enter a valid IP address when specifying a non-negative response!" was displayed.

4.46 DNS - Entries not displayed optimally

ID n/a

It could occur under certain circumstances, that the entries in the menu **Local Services->DNS->Cache** were not displayed optimally arranged.

4.47 DHCP - Incorrect IP addresses used

ID 18660

With a DHCP server for "PXE-boot clients" it could happen that DHCP Replies used an incorrect source IP address and an incorrect TFTP server IP address was submitted to PXE clients.

4.48 DHCP - address assignment incorrect

ID 18180

If a hybrid was operated with more than 30 elmeg IP1x telephones, after a reboot of the hybrid the first 30 telephones were assigned their IP address of the hybrid correctly via the DHCP server, while the other telephones received several IP addresses.

4.49 DHCP - Server did not respond

ID 18523

Under certain circumstances, it could happen that DHCP requests, which the clients had sent after approx. 50% of the **Lease Time** to their DHCP server, could not be answered by the server.

4.50 Hotspot - Panic

ID 18615

With the Hotspot application, it could happen under certain circumstances that every one to five minutes a Panic occurred and WLAN was no longer available for guests.

4.51 Hotspot - problems with RADIUS

ID 18681

If Hotspot was used together with RADIUS, problems could occur.

4.52 Hotel function - call data cannot be displayed

ID 18592

In the menu **Applications->Hotel Functions->Room Status->** with a click of the button **Print** the call data of the guest could not be displayed. A blank window was displayed.

4.53 Update - No Reboot possible

ID 18407

If in the menu **Maintenance->Software & Configuration->Options** with the setting **Action = *Updating system software*** the system software was updated and then, in the message "System - Maintenance. Success. Operation completed successfully" **Back** was clicked, no reboot could be performed through the GUI.

4.54 Setup Tool - DSL modem cannot be switched off

ID 18444

A DSL modem could not be disabled, even though the DSL mode was not active in the Setup Tool.

4.55 Setup Tool - Fixed connection not working

ID 18525

If the Setup Tool with **ISDN Switch Type** = *leased line B1 + B2 channel (64S2)* a fixed connection was configured on both B-channels, it could happen that no connection could be established.

4.56 Setup Tool - Load Balancing not working correctly

ID 18146, 18162

If Load Balancing was configured in the Setup Tool, the appropriate interfaces were not displayed. The MIB variable **GroupId** in the MIB table **ipLoadBifTable** showed an incorrect value.

The configuration of the weighing for two interfaces (e.g. 0% to 100%) did not work.

4.57 Setup Tool - Incorrect values displayed

ID 18341

If, for example, in a rollout, for multiple devices for the SIM card the same PIN or no PIN was used, the SIM card parameters were incorrectly displayed in the Setup Tool.

4.58 Setup Tool - extended route cannot be configured

ID 18448

After the first connection of an LTE WAN partner it was not possible to build an extended route with the type "WAN without transit network".

Appendix A Extendend Information

Release 9.1.10 offers a number of functions for additional product series that may have been available for other products in an earlier release. The corresponding information have been compiled in this appendix.

A.1 From Release Notes 9.1.7

A.1.1 Hardware: New LED mode available

With **Systemsoftware 9.1.7** a new LED mode is available for the devices **bintec RS232bu+**, **RS232j-4G** and **RS120wu**.

If you want to put a device into this mode, you can see from the LEDs which wireless standard is currently in use and which signal quality is available for the wireless network.

To change mode, press the Reset button down three times in a row for longer than 0.5 seconds and release it again.

Briefly press the Reset button to restore the regular mode.

Wireless standard

The following link exists between the lights of an LED and the wireless standard in use:

LED	Wireless standard
USB	GSM
UMTS	UMTS/HSxPA
BRI	LTE (where supported)

If the device has not yet locked in or has not yet found a signal, no LED lights up.

Signal quality

The following link exists between the signal quality and the lights of one or more Ethernet LEDs:

Signal strength in dBm	Number of the Ethernet LED
< -100	1

Signal strength in dBm	Number of the Ethernet LED
< -80	1, 2,
< -70	1, 2, 3
< -60	1, 2, 3, 4
>= -60	1, 2, 3, 4, 5

A.2 From Release Notes 9.1.8

A.2.1 Support for the provisioning of IP 1x0 function keys

System Software 9.1.9 supports transferring the configuration of the functions keys during the automatic provisioning of elmeg Ip 1x0 telephones. The configuration is carried out in the menu **Terminals->elmeg System Phones->elmeg IP1x->Keys**.



Note

When updating a hybrid system to **System Software 9.1.8** there may be a problem with function key configurations stored on connected telephones. Since there is no key configuration stored on the system at the moment of updating, a configuration stored on a telephone will be deleted upon the next contact between the system and the telephone if autoprovisioning is enabled. For this case, it is advisable to disconnect the hybrid from any connected telephones, apply the update and create the function key configurations on the system before reconnecting the system to the LAN.

A.2.1.1 Keys / T100

The menu **Terminals->elmeg System Phones->elmeg IP1x->Keys** displays the configuration of your system telephone's keys.



Note

You can configure the key assignment either through your **elmeg hybrid** or on the telephone itself. We recommend using your **elmeg hybrid** for this, since it overwrites the telephone configuration.

















As of **System Software 9.1.8** you can avoid the overwriting for individual keys that have already been configured on the telephone by choosing *Not configured* in the **elmeg hybrid**.

Your telephone is equipped with several function keys that allow the assignment of different functions. The functions available for programming are different across different types of telephones.

System Phone elmeg IP1x elmeg DECT

Phone: IP130 , Type: ip130 , 1st Number: 30

General **Numbers** **Keys** **Settings**

Key	Label Description	Key Type	Settings			
Key1	Dial Key 1	Dial Key (Standard)	30 (30)			
Key2						
Key3						
Key4						
Key5						
Key6						
Key7						
Key8						
Key9						
Key10						
Key11						
Key12						
Key13						
Key14						

Back Print


Fig. 2: Terminals->elmeg System Phones->elmeg IP1x->Keys

Values in the list Keys

Field	Description
Key	Displays the name of the key.
Label Description	Displays the configured key name. This appears on the labelling page (label strips).
Key Type	Displays the key type.
Settings	Displays the additional settings with a summary

Print allows you to print out a label sheet for the description field of your system phone or key extension.

Edit

Choose the  icon to edit existing entries. In the pop-up menu, you configure the func-

tions of your system telephone keys.




Fig. 3: Terminals->elmeg System Phones->System Phone->Keys-> Edit

You can use the following functions with system telephones:

- *Dial Key (Standard)*: You can store a number on each function key. External numbers have to be prefixed by the exchange code *0if no automatic outside line* has been configured for your **User Class** on the telephone.
- *Dial Key (DTMF)*: You can store a DTMF sequence on every function key.
- *Extension Key (User)*: You can set up dialling to an internal extension using a line key. After pressing the corresponding key, hands free is switched on and the internal extension entered is selected. If a call is signalled on the internal extension you have entered, you can pick this up by pressing the line key.
- *MSN Selection Key*: Assigns a specific connection (i.e. a specific SIP account) to the function key. You can use this key to initiate a call via this connection, or you can accept a call coming in via this connection. The key flashes if a call is received, it is lit if the connection is busy. Select the desired connection. All configured connections are available. Configure SIP accounts exclusively on your **elmeg hybrid**.
- *Call Forwarding (enable)*: Assigns activating or deactivating a call forwarding that has been configured on the telephone. You can only store a single call forwarding on the device; it is applied to all calls.
- *System Parking (Open Enquiry)*: The called extension enters an enquiry and dials a code. The telephone is now open for additional operations like e.g. an announcement. A

second subscriber can accept the call by picking up the receiver and dialing the code corresponding to the call. The codes are determined by the PABX, but can also be assigned to the functions keys of one or more system phones. If a call is put into open enquiry by pressing a function key, this is indicated by the flashing of the respective function key LED on all system phones with a corresponding configuration. Pressing the function key accepts the call. This function is only available if a call has been parked.

- *XML-Content*: Assigns an URL to the function key. You can, e.g., store customer-specific menus and temporarily show them on the display of your telephone. This function is currently not supported by **elmeg hybird**.
- *Next call anonymous*: For the next call the called party will no see your MSN.
- *Menu - Call Forwarding*: Assigns the menu item **Call Forwarding** in the display menu of your telephone to the function key. You can configure the call forwarding specifics.
- *Menu - Resource Directory*: Assigns the menu item **Media-Pool** in the display menu of your telephone to the function key. You can manage images used as screen saver, caller icons for phone directory entries and ring tones. Moreover, you can monitor the capacity of the pool.
- *Menu - Internet Radio*: Assigns the menu item **Internet Radio** in the display menu of your telephone to the function key. You can tune in to the last selected radio station or select a different one.
- *Not configured*: The function key is managed by the telephone itself and not by **elmeg hybird**. This options locks the key for the provisioning by your **elmeg hybird**.

The menu **Terminals->elmeg System Phones->elmeg IP1x->Keys->Edit** consists of the following fields:


Fields in the menu Telephone

Field	Description
Key name	Enter a name for the key to be used as text for the corresponding key when the ID labels are printed.
Key Type	<p>Depending on the model, telephones have seven or 14 keys that can have functions assigned to them. Optional key extension modules extend the number of available functions keys.</p> <p>Possible values:</p> <ul style="list-style-type: none"> • <i>Dial Key (Standard)</i> • <i>Dial Key (DTMF)</i> • <i>Extension Key (User)</i> • <i>MSN Selection Key</i> • <i>Call Forwarding (enable)</i>

Field	Description
	<ul style="list-style-type: none"> • <i>System Parking</i> • <i>XML-Content</i> • <i>Next call anonymous</i> • <i>Menu - Call Forwarding</i> • <i>Menu - Resource Directory</i> • <i>Menu - Internet Radio</i> • <i>Not configured</i>
Internal MSN	<p>Only for Key Type = <i>Dial Key (Standard)</i>, <i>Extension Key (User)</i>, <i>MSN Selection Key</i>, <i>Call Forwarding (enable)</i> or <i>System Parking</i></p> <p>You can select one of the internal MSNs configured in the menu Terminals->elmeg System Phones->elmeg IP1x->Numbers.</p>
Number	<p>Only for Key Type = <i>Dial Key (Standard)</i> or <i>Dial Key (DTMF)</i></p> <p>You can save a number or a DTMF sequence to any function kye. Specify the number or the characters for the DTMF sequence.</p>
Internal Number	<p>Only for Key Type = <i>Extension Key (User)</i></p> <p>Select the internal number of the subscriber that is to be called when pressing this key.</p>
Pick-Up Code	<p>Only for Key Type = <i>Extension Key (User)</i></p> <p>The code that is required for the busy lamp field to allow you picking up a call on an IP telephone when the LED is flashing.</p> <p>The default value is #0.</p>
Waiting Queue	<p>Only for Key Type = <i>System Parking (Open Enquiry)</i></p> <p>Select the waiting queue to which the current connection is to be added.</p>
URL	<p>Only for Key Type = <i>XML-Content</i></p> <p>For this function you can store the URL to a server which hosts</p>

Field	Description
	the desired information. This function is currently not supported by elmeg hybrid .

Transfer key

Select the  icon to move configured function keys.

System Phone elmeg IP1x elmeg DECT

Phone: IP130 , Type: ip130 , 1st Number: 30

General **Numbers** **Keys** **Settings**

Key	Label Description	Key Type	Settings
Key1			
Key2			
Key3			
Key4			
Key5			
Key6			
Key7			
Key8			
Key9			
Key10			
Key11			
Key12			
Key13			
Key14			

Phone: IP130 , Type: ip130 , 1st Number: 30

Key1

Key name	Dial Key 1
Key Type	Dial Key (Standard)
Settings	
Move to	
Phone	IP130
Module	gigaset-base
Key	Key 2

Apply Close

Back Print

Fig. 4: Terminals->elmeg System Phones->System Phone->Keys->Move

Fields in the menu Key

Field	Description
Key name	Displays the name of the key.
Key Type	Displays the key type.
Settings	Displays the additional settings with a summary

Fields in the menu Move to

Field	Description
Phone	Select one of the connected telephones.

Field	Description
Module	Select <i>Telephone</i> or a key extension.
Key	Select the key to which you wish to transfer the configured function.

A.3 From Release Notes 9.1.9

A.3.1 WLAN Bandwidth Control

The bandwidth available for individual clients can be restricted in receive as well as in transmit direction with the options **Rx Shaping** and **Tx Shaping** in the menu **Wireless LAN->WLAN->Wireless Networks (VSS)->Edit** or **Wireless LAN Controller->Slave AP configuration->Wireless Networks (VSS)->Edit**. The following values are available:

Fields in the menu Bandwidth limitation for each WLAN client

Field	Description
Rx Shaping	Select a bandwidth limitation in the receive direction. Possible values are <ul style="list-style-type: none"> • <i>No limit</i> (default value) • <i>0,25 Mbit/s, 0,5 Mbit/s, 1 Mbit/s up to 10 Mbit/s</i> in single Mbit/s steps, <i>15 Mbit/s, 20 Mbit/s, 30 Mbit/s, 40 Mbit/s</i> and <i>50 Mbit/s</i>.
Tx Shaping	Select a bandwidth limitation in the transmit direction. Possible values are <ul style="list-style-type: none"> • <i>No limit</i> (default value) • <i>0,25 Mbit/s, 0,5 Mbit/s, 1 Mbit/s up to 10 Mbit/s</i> in single Mbit/s steps, <i>15 Mbit/s, 20 Mbit/s, 30 Mbit/s, 40 Mbit/s</i> and <i>50 Mbit/s</i>.

A.3.2 WLAN Controller Monitoring

Systemsoftware 9.1.9 introduces significantly expanded functions for monitoring the Wireless LAN Controller.

**Note**

In order to ensure adequate timing between the WLAN Controller and the connected Slave APs, the internal time server of the WLAN Controller should be enabled.


A.3.2.1 WLAN Controller

Fig. 5: Wireless LAN Controller->Monitoring->WLAN Controller

In the **Wireless LAN Controller->Monitoring->WLAN Controller** menu, an overview of the most relevant Wireless LAN Controller parameters is displayed. The display is refreshed every 30 seconds.

Values in the Overview list



Status	Meaning
AP discovered	Displays the number of discovered access points.
AP offline	Displays the number of access points not connected to the Wireless LAN Controller.
AP managed	Displays the number of managed access points.
WLAN Controller: VSS throughput	Displays the data traffic in receive and transmit direction in bytes per second.
CPU usage [%]	Displays the percentaged CPU load over time.
Memory usage [%]	Displays the percentaged memory consumption over time.
Connected clients/VSS	Displays the number of connected clients per wireless network (VSS) over time.

A.3.2.2 Slave Access Points

[WLAN Controller](#)
[Slave Access Points](#)
[Active Clients](#)
[Wireless Networks \(VSS\)](#)
[Client Management](#)

Automatic Refresh Interval Seconds


View per page Filter in

Location	Name	IP Address	LAN MAC Address	Channel	Tx Bytes	Rx Bytes		
INY	WI2040n	10.0.0.13	00:01:cd:06:76:fa	auto (Ch.6)/man (Ch.1)	566634	60784	➕ Managed	
WNY	bintec W1002n	10.0.0.12	00:01:cd:0e:8f:04	auto (Ch.1)	4832	6111	➕ Managed	
		10.0.0.234	00:a0:f9:0b:cf:d8		0	0	⊖ Discovered	

Page: 1, Items: 1 - 3

Fig. 6: Wireless LAN Controller -> Monitoring -> Slave Access Points

LAN MAC Address

Via the  icon, you can open an summary with additional details about the **Slave Access Points**.

A.3.2.2.1 Overview

In the **Overview** menu, additional information about the selected access point is displayed. The display is refreshed every 30 seconds.



Fig. 7: Wireless LAN Controller->Monitoring->Slave Access Points->Overview

Values in the Overview list

Status	Meaning
Throughput	Displays the received and transmitted data traffic per radio module over time.
Connected clients	Displays the number of connected clients per radio module over time.

A.3.2.2.2 Radio 1

In the **Radio Module** menu, the received and transmitted data traffic per client is displayed over time. Each graph in the display is distinctly assigned to a client by its color and MAC address.




Fig. 8: Wireless LAN Controller->Monitoring->Slave Access Points->Radio

Values in the Radio list

Status	Meaning
Throughput/client	Displays the received and transmitted data traffic per client over time.

A.3.2.3 Active Clients





Fig. 9: Wireless LAN Controller->Monitoring->Active Clients

In the **Wireless LAN Controller->Monitoring->Active Clients** menu, current values of all active clients are displayed.

For each client you will see an entry with the following parameter set: **Location, Slave AP Name, VSS, Client MAC, Client IP Address, Signal : Noise (dBm) , Tx Bytes, Rx Bytes, Tx Discards, Rx Discards, Status, Uptime.**

Possible values for Status

Status	Meaning
None	The client is no longer in a valid status.
Logon	The client is currently logging on with the WLAN.
Associated	The client is logged on with the WLAN.
Authenticate	The client is in the process of being authenticated.
Authenticated	The client is authenticated.

Via the  icon, you can open a summary with additional details about the **Active Clients**.





Fig. 10: Wireless LAN Controller->Monitoring->Active Clients-> 

Value in the list WLAN Client list

Status	Meaning
Throughput	Displays the data traffic - separated into received and transmitted traffic - for the selected WLAN client over time.
Signal	Displays the signal strength of the selected WLAN client over time.

A.3.2.4 Wireless Networks (VSS)

WLAN Controller Slave Access Points Active Clients Wireless Networks (VSS) Client Management					
View	20	per page	<< >>	Filter in	None
					equal
Go					
Location	Slave AP Name	VSS	MAC Address (VSS)	Channel	Status
INY	WI2040n	Kefig	02:6f:83:69:08:90	auto (Ch.6)	+
INY	WI2040n	Kefig	02:6f:83:69:0c:58	rman (Ch.1)	+
WNY	bintec WI1002n	Kefig	02:6f:83:3a:af:98	auto (Ch.1)	+
Page: 1, Items: 1 - 3					

Fig. 11: Wireless LAN Controller->Monitoring->Wireless Networks (VSS)

In the **Wireless LAN Controller->Monitoring->Wireless Networks (VSS)** menu, an overview of the currently used AP is displayed. You see which wireless module is assigned to which wireless network. For each wireless a parameter set is displayed (**Location, Slave AP Name, VSS, MAC Address (VSS), Channel, Status**).

A.3.2.5 Client Management

WLAN Controller Slave Access Points Active Clients Wireless Networks (VSS) Client Management							
View	20	per page	<< >>	Filter in	None		
					equal		
Go							
Location	Slave AP Name	VSS	MAC Address (VSS)	Active Clients	2,4/5 GHz changeover	Denied Clients soft.hard	
INY	WI2040n	Kefig	02:6f:83:69:08:90	0	0	0/0	🗑️
INY	WI2040n	Kefig	02:6f:83:69:0c:58	0	0	0/0	🗑️
WNY	bintec WI1002n	Kefig	02:6f:83:3a:af:98	0	0	0/0	🗑️
Page: 1, Items: 1 - 3							
Apply							

Fig. 12: Wireless LAN Controller->Monitoring->Client Management


The **Wireless LAN Controller->Monitoring->Client Management** menu displays information on the client management by the access points. You can, e.g., see the number of connected clients, the number of clients that are affected by the **2,4/5 GHz changeover** and the number of rejected clients.

You can delete the values of an entry using the 🗑️ symbol.

A.3.3 DHCP Options for bintec 4Ge-LE

For the operation of **bintec 4Ge-LE System Software 9.1.9** offers additional DHCP options via the GUI.

In the menu **Local Services->DHCP Server->DHCP Configuration->Advanced Settings**, proceed as follows in order to specify the respective parameter:

- (1) Click the **Add** button in the **DHCP Options** field and choose **Option = Vendor String**.
- (2) Click the  button to edit the entry.
The window **Basic Parameters** opens.
- (3) Under **Select vendor**, select *bintec*.
- (4) Add the desired values for your **4Ge-LE** in the fields **APN** and **PIN** and click **Apply**.

Index

Connected clients 35
Internal MSN 29
Internal Number 29
Key 27, 31
Key name 29, 31
Key Type 27, 29, 31
Label Description 27
Module 31
Number 29
Phone 31
Pick-Up Code 29
Settings 27, 31
Throughput 35
Throughput/client 36
URL 29
Waiting Queue 29
AP discovered 34
AP managed 34
AP offline 34
Connected clients/VSS 34
CPU usage [%] 34
Memory usage [%] 34
Overview 34
Signal 37
Throughput 37
WLAN Controller: VSS throughput 34
Active Clients 36
Client Management 38
Keys 26
Rx Shaping 32
Slave Access Points 34
Tx Shaping 32
Wireless Networks (VSS) 38
WLAN Controller 33

R

Radio1 35

T

T100 26