

Release Notes 3.17.4

elmeg IP620 / IP630

1. What's is new?

- In the **Settings > Debugging > Reboot** menu, you can configure an automatic reboot of the phone at a specific time.
- In the **Settings > Desk phone > Display > Night Mode** menu, the display and call signaling can be deactivated for certain times.
- Playback of the ringing tone can be deactivated (e.g. when using a headset) in the **Settings > Telephony > Call settings > Tone selection > Dial-tone** tone menu.
- If the keypad is locked by a PIN (the setup takes place in the **Settings > Telephony > Phone lock** menu), it can be unlocked by pressing and holding the **#aA** key and entering the PIN. Press and hold again to lock the keypad. The keypad is automatically unlocked for incoming calls, configured emergency numbers can be dialed without unlocking.

2. Enhancements

- SIP passwords are no longer stored in clear text on the phone.
- Spelling and translations have been improved.
- The call forwarding function has been added to the display keys.

3. Bugfixes

- At the beginning of a call, voice transmission was briefly interrupted.
- After executing a key procedure that contained #, the feedback contained wrong characters.
- **IP630** did not support umlauts.
- The feedback when pressing "System parking " was not consistent between phone types.
- If the phones were set up with static IP address but without a gateway, malfunctions occurred.
- If a phone was not used for a long time, it could become unresponsive.