

### Enabling or inhibiting call waiting

\*58 or #58   
 Enable call waiting      Inhibit call waiting      Ack. signal

### Configuring call forwarding

\* 61 / 62 / 63 #   
 Call forwarding/  
 Call forwarding on no answer/  
 Call forwarding on busy      Enter destination number for call forwarding      Ack. signal

### Canceling call forwarding

# 61 / 62 / 63   
 Cancel call forwarding      Ack. signal

### Enabling or inhibiting paging

\*591 or #591   
 Erase paging      Inhibit paging      Ack. signal

### Activating station guarding (do not disturb)

\* 570 / 571 / 572   
 Prevent incoming calls for internal and external / external / internal      Ack. signal

### Deactivating station guarding

# 570   
 Ack. signal

### Login / logout inhibiting a member's phone within a team

\* / # 943 #   
 login / logout      Team number      Ack. signal

### Switching call modes for teams (Day/Night)

\* / # 93 #   
 call modes day / call mode night      Team number      Ack. signal

### Programing an appointment call (Wake-up call)

\* 72 #   
 Enter hours      Enter minutes      Ack. signal

### Canceling an appointment call

# 72   
 Ack. signal

### Activating the operator function for an internal subscriber

\* 91 or # 91   
 Activating day mode      Activating night mode      Ack. signal

### Enabling / inhibiting intercom calls

\* 590 or # 590   
 Enable intercom calling      Inhibit Intercom calling

### Modified code numbers

For the following features you can either use the code numbers you have set during configuration or the numbers set out in the operating instructions. Enter the modified code numbers in the table.

Feature	Default code number	Changed code number
Line access digit	0 (UK 9)	
Picking up calls from within the group (Pick up)	* 0	
Picking up calls for a specific subscriber*)	* 1 #	
Speed dialing from the telephone directory	* #	
Assignment of project numbers for external calls	* 5 0	
Trunk group assignment (8 code numbers)	* 8	
Open enquiry call (10 code numbers)	* 5 9 6	
Activation of a door opener (4 code numbers)	* 9 9	

\*) requires firmware 1.2 or later

# When you enter the number for dialing via an SIP provider, dialing is not performed until around 5 seconds after the last digit has been entered. Dialing is performed immediately when you press the # key after entering the number. In this case, the terminal device must also be capable of dialing into the phone system with the #.

### Call Through

This action may only be performed from an external phone.

Lift up handset      Select "Numbers in my phone system for call-through"      Dial tone      1) Enter PIN      Dialing external destination numbers

1) The configuration of the PABX system is decisive for this input (with or without PIN, with number recognition, or both).

elmeg ICT

English

